

[Manuals.plus](#) /

> [Blissun](#) /

> Blissun Umbrella Replacement Lower Pole Instruction Manual

Blissun B0DNF75T6D

Blissun Umbrella Replacement Lower Pole Instruction Manual

Model: B0DNF75T6D

1. PRODUCT OVERVIEW

This manual provides instructions for the Blissun Aluminium Patio Umbrella Extension Bottom Pole Replacement. This component is designed to replace the lower section of specific Blissun patio umbrellas, ensuring continued functionality and stability.

Important Compatibility Note:

This replacement pole is engineered to fit **only specific Blissun umbrella models**. It is not a universal fit. Please verify your umbrella's specifications against the dimensions provided in this manual to ensure compatibility before installation.



Image 1.1: The Blissun Umbrella Replacement Lower Pole, bronze color.

2. SPECIFICATIONS

The Blissun Umbrella Replacement Lower Pole is constructed from heavy-duty aluminum with a powder-coated brown finish and an elegant texture design for durability and corrosion resistance.

- **Material:** Heavy-duty Aluminum
- **Color:** Bronze (Powder-coated)
- **Overall Length:** 43.4 inches (110.2 cm)
- **Diameter at Bottom:** 1.46 inches (3.7 cm)
- **Umbrella Connection Interface Diameter:** 1.34 inches (3.4 cm)
- **Total Connection Section Length:** 3.07 inches (7.8 cm)
- **Distance from Top of Connection Section to Snap Button:** 1.3 inches (3.3 cm)
- **Distance from Snap Button to Bottom of Connection Section:** 1.42 inches (3.6 cm)
- **Weight:** Approximately 14.39 ounces



Image 2.1: Detailed measurements of the replacement lower pole, including overall length, diameters, and connection section dimensions.

Heavy-duty Aluminum

- Brown color powder-coated
- Elegant texture design



Image 2.2: Close-up view highlighting the heavy-duty aluminum construction and textured powder-coated finish.

3. COMPATIBILITY CHECK

Before attempting installation, it is crucial to confirm that this replacement pole is compatible with your existing umbrella. Please use the following chart and measurements to verify:

Compatibility Chart

Use the chart below to determine if this replacement pole is compatible with your umbrella. All conditions must be met for a successful fit.

Your Umbrella's Specs	Must Be	Compatible?
Brand	Blissun umbrella	✓ YES
	Other brand umbrella	✗ NO
Connection Interface Diameter	Exactly 1.34 inches or Larger than 1.34"	✓ YES
	Smaller than 1.34"	✗ NO
Distance from Top to Button	Exactly or Smaller than 1.3 inches	✓ YES
	Larger than 1.3"	✗ NO
Bullet Buckle	Without a Bullet Buckle	✓ YES
	With a Bullet Buckle	✗ NO

Image 3.1: Compatibility chart detailing requirements for brand, connection interface diameter, distance from top to button, and bullet buckle presence.

Compatibility Requirements

Your Umbrella's Specs	Must Be	Compatible?
Brand	Blissun umbrella	YES
	Other brand umbrella	NO
Connection Interface Diameter	Exactly 1.34 inches or Larger than 1.34"	YES
	Smaller than 1.34"	NO
Distance from Top to Button	Exactly or Smaller than 1.3 inches	YES
	Larger than 1.3"	NO
Bullet Buckle	Without a Bullet Buckle	YES

Your Umbrella's Specs	Must Be	Compatible?
	With a Bullet Buckle	NO

If your umbrella does not meet these specifications, this replacement pole may not fit correctly.

4. SETUP AND INSTALLATION

This replacement pole is designed for quick and simple installation. No special tools are typically required.

- 1. Prepare the Umbrella:** Ensure your existing umbrella is closed and secured. If replacing a damaged lower pole, carefully remove the old pole from the umbrella canopy and base.
- 2. Align the Pole:** Take the new Blissun replacement lower pole. Locate the connection point on your umbrella's upper pole section.
- 3. Insert the Pole:** Gently insert the top end of the replacement lower pole into the bottom of the umbrella's upper pole section. Ensure the bullet buckle on the replacement pole aligns with the corresponding hole in the upper pole.
- 4. Secure the Connection:** Push the pole firmly until the bullet buckle snaps into place, indicating a secure connection. This mechanism ensures stability.
- 5. Insert into Base:** Place the assembled umbrella (with the new lower pole) into your umbrella base. Tighten any securing screws or knobs on your umbrella base to hold the pole upright and stable.



Image 4.1: Visual guide demonstrating the simple process of connecting the lower pole to the umbrella's upper section.

Bullet buckle

Umbrella lower pole with bullet buckle for improved stability and easy installation



Image 4.2: Detail of the bullet buckle, which provides a secure and stable connection for the umbrella pole.

5. OPERATING INSTRUCTIONS

Once the replacement lower pole is securely installed, the operation of your Blissun umbrella remains unchanged. Ensure the pole is firmly seated in the umbrella base before opening the canopy.

- Always ensure the umbrella pole is securely fastened in its base to prevent tipping, especially in windy conditions.
- Open and close the umbrella canopy according to the original instructions provided with your Blissun umbrella.
- Do not force the pole into the umbrella or base if resistance is met. Recheck alignment and compatibility.

6. MAINTENANCE

Proper care will extend the life of your replacement pole and umbrella.

- **Cleaning:** Wipe the pole with a damp cloth to remove dirt and debris. Avoid abrasive cleaners or harsh chemicals that could damage the powder-coated finish.
- **Inspection:** Periodically inspect the pole for any signs of damage, bending, or corrosion. Ensure the bullet

buckle mechanism is functioning correctly.

- **Storage:** When not in use for extended periods, or during severe weather, it is recommended to remove the umbrella from its base and store it in a dry, protected area.

Robust Sealing Design

Ensuring both durability and strength




Image 6.1: The robust sealing design at the base of the pole helps protect against moisture and enhances durability.

7. TROUBLESHOOTING

- **Pole Does Not Fit:**
 - Re-check the compatibility chart in Section 3. Ensure your umbrella's dimensions and brand match the requirements.

- Verify that the connection interface diameter and the distance to the snap button on your umbrella's upper pole are correct.
- Confirm that your umbrella does not already have a bullet buckle in the lower pole connection area, as this replacement pole includes one.
- **Pole Feels Loose After Installation:**
 - Ensure the bullet buckle has fully engaged and snapped into place. You should hear or feel a click.
 - Check for any obstructions within the connection point of the upper pole.
 - Verify that the umbrella base is tightened securely around the lower pole.
- **Damage During Shipment:**
 - If the pole arrived bent or damaged, do not attempt to install it. Contact customer support immediately for assistance.

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Blissun Umbrella Replacement Lower Pole, please refer to the original purchase documentation or contact Blissun customer service directly. Contact details can typically be found on the Blissun official website or through your retailer.

When contacting support, please have your product model (B0DNF75T6D) and purchase date available.



© 2025 Blissun. All rights reserved.

This manual is for informational purposes only. Blissun is not responsible for any damage or injury resulting from improper installation or use.