

MONDAWE 18 Inch Fireplace + 58 Inch TV Stand

MONDAWE 18" Electric Fireplace TV Stand for 58 Inch TV Instruction Manual

1. PRODUCT OVERVIEW

The MONDAWE 18" Electric Fireplace TV Stand is a versatile entertainment center designed to accommodate TVs up to 58 inches. It features an integrated 18-inch electric fireplace heater and ample storage space. Constructed from durable Medium-Density Fiberboard (MDF), this unit combines functionality with a stylish brown finish, suitable for various living room decors.



Image 1: Front view of the MONDAWE Electric Fireplace TV Stand.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this appliance.

- Ensure the TV stand is assembled on a flat, stable surface.
- Do not overload the shelves or top surface. Refer to specifications for weight limits.

- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace heater.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions.
- Always unplug the fireplace before cleaning or maintenance.
- This product is CSA certified for safety in the USA and Canada.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware listed in the assembly guide are present and undamaged. If any components are missing or broken, do not proceed with assembly and contact customer support.




Image 2: Product dimensions and overall structure.

4. ASSEMBLY INSTRUCTIONS

Assembly of the MONDAWE Electric Fireplace TV Stand requires careful attention to detail. Follow the step-by-step instructions provided in the included manual. For a visual guide, please refer to the assembly video below. It demonstrates the general process for assembling a TV stand with an integrated fireplace, which is similar to this model.

Video 1: General assembly guide for a TV stand with an electric fireplace. Note: The video may show a slightly different model (70-inch) but the assembly principles are applicable.

Key Assembly Steps:

1. **Prepare Components:** Lay out all wooden panels and hardware on a clean, soft surface to prevent scratches.
2. **Assemble Base Frame:** Connect the bottom panels and side supports using the provided cam locks and dowels.

3. **Install Side Cabinets:** Attach the side cabinet panels to the main frame, ensuring secure connections.
4. **Insert Shelves:** Place the adjustable shelves into the side compartments and the central media compartment.
5. **Attach Top Panel:** Secure the top surface of the TV stand to the assembled frame.
6. **Install Fireplace Unit:** Carefully slide the electric fireplace insert into its designated opening.
7. **Mount Cabinet Doors:** Attach the hinges to the cabinet doors and then to the side panels. Adjust as needed for proper alignment.
8. **Final Touches:** Install any remaining hardware, such as door handles or cable management grommets.



Image 3: Illustration of the TV stand's storage compartments and weight capacities.

5. SETUP

1. **Placement:** Position the TV stand on a level surface against a wall. Ensure there is adequate clearance around the unit for ventilation and safety.
2. **Power Connection:** Plug the electric fireplace heater into a standard 120V, 60Hz grounded outlet. Do not use extension cords or power strips.
3. **TV Placement:** Carefully place your TV (up to 58 inches) on the top surface. Ensure it is centered and

stable.

4. **Cable Management:** Utilize any built-in cable management features to organize and conceal wires from your TV and media devices.



Image 4: Demonstrates TV size compatibility, fitting TVs up to 58 inches.

6. OPERATING INSTRUCTIONS

The electric fireplace heater is operated using the included remote control or the control panel on the unit.

Remote Control Functions:

- **Power Button:** Turns the fireplace heater ON or OFF.
- **Flame Settings:** Cycles through three brightness settings (high, medium, low, and off) for the flame effect.
- **Temperature Adjustment:** Adjusts the heater temperature from 62°F to 82°F (17°C to 28°C).
- **Timer Function:** Sets an automatic shut-off timer from 30 minutes to 6 hours for energy efficiency.

The heater delivers 5000 BTUs, capable of warming an area of up to 400 square feet efficiently.

TV Stand with Electric Fireplace

5000BTU, 1400W, Heating for up to 400 Sq.Ft



CSA
Certification



0.5-6
Hours Timer



62°F-82°F



3 level
Brightness



Over heating
Protection



Remote control

Image 5: Overview of key features including heating capacity, timer, temperature, brightness, overheat protection, and remote control.

Enjoy a Warmer Living Space



Image 6: Visual representation of the heating capability for up to 400 square feet.

7. MAINTENANCE

- **Cleaning:** Dust the TV stand regularly with a soft, dry cloth. For the fireplace glass, use a non-abrasive glass cleaner. Ensure the unit is unplugged before cleaning.
- **Ventilation:** Keep the air intake and exhaust vents of the fireplace clear of dust and debris to ensure proper operation and prevent overheating.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight.

8. TROUBLESHOOTING

Common Issues and Solutions:

- **Fireplace not turning on:** Check if the power cord is securely plugged into a grounded outlet. Ensure the wall switch (if applicable) is ON. Verify the remote control batteries are functional.
- **No heat, but flames are visible:** The heater may be set to a low temperature or the heat function might be off. Adjust the temperature setting.

- **Heater shuts off unexpectedly:** The unit has built-in overheat protection. Ensure vents are not blocked and allow the unit to cool down before restarting.
- **Remote control not working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace sensor.



9. SPECIFICATIONS







- **Brand:** MONDAWE
- **Model:** 18 Inch Fireplace + 58 Inch TV Stand
- **Material:** Medium-Density Fiberboard (MDF)
- **Color:** Brown
- **TV Size Compatibility:** Up to 58 inches
- **Top Surface Weight Capacity:** 65 lbs
- **Side Compartment Weight Capacity:** 36 lbs each
- **Upper Shelf (above fireplace) Weight Capacity:** 50 lbs
- **Fireplace Heater Output:** 5000 BTUs
- **Heating Area:** Up to 400 square feet
- **Power:** 120V, 60Hz, 1400W
- **Temperature Range:** 62°F to 82°F
- **Timer Settings:** 30 minutes to 6 hours
- **Safety Certification:** CSA certified (USA and Canada)

10. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the documentation included with your purchase or visit the official MONDAWE website. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - 18 Inch Fireplace + 58 Inch TV Stand

	<p>Mondawe Round Dining Table Assembly Instructions</p> <p>Step-by-step assembly instructions for the Mondawe round dining table, including parts list and assembly diagrams.</p>
	<p>Mondawe Electric Fireplace Owner's Manual and Installation Guide</p> <p>Comprehensive owner's manual and installation guide for Mondawe Electric Fireplaces (Models IF-30 through IF-72), covering essential safety information, product specifications, detailed installation procedures for both recessed and wall-mounted configurations, operation instructions via touch panel and remote control, maintenance guidelines, and troubleshooting tips.</p>

	<p>MONDAWE Umbrella Installation Guide and Parts List</p> <p>Detailed installation instructions, parts list, and assembly guide for MONDAWE outdoor umbrellas, including filling options and screw specifications.</p>
 	<p>12'x 10' Steel Double Roof Gazebo Assembly Instructions</p> <p>Comprehensive assembly instructions for the 12'x 10' Steel Double Roof Gazebo by Mondawe, including safety guidelines, parts list, and step-by-step assembly procedures.</p>
	<p>10'x20' Gazebo Assembly Manual - Mondawe</p> <p>Comprehensive assembly manual for the Mondawe 10'x20' Gazebo (Model MD-CPL-00075). Includes pre-assembly checks, parts list, detailed step-by-step instructions, and anchoring options for outdoor use.</p>
<p>ASSEMBLY INSTRUCTION 10 x 10 ft Louvered Pergola</p>  	<p>MONDAWE 10 x 10 ft Louvered Pergola Assembly Instructions</p> <p>Detailed assembly instructions for the MONDAWE 10 x 10 ft Louvered Pergola. Learn how to assemble your pergola step-by-step with clear guidance and component lists.</p>