

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [VEGER](#) /
- › [VEGER Wireless Portable Charger User Manual](#)

VEGER W0582

VEGER Wireless Portable Charger User Manual

Model: W0582 | Brand: VEGER

1. INTRODUCTION AND OVERVIEW

The VEGER Wireless Portable Charger is a versatile 6-in-1 multi-functional device designed to keep your mobile devices powered and organized. It combines a magnetic wireless charger, wired power bank, fast charging battery pack, multi-angle phone stand, secure wallet, and a built-in global tracking feature.

Its compact and durable design makes it an ideal companion for daily use, travel, and outdoor adventures.




Figure 1: The VEGER Wireless Portable Charger, showcasing its sleek design and integrated card holder.

2. PACKAGE CONTENTS AND SETUP

Upon unboxing your VEGER Wireless Portable Charger, please ensure all components are present:

- 1x 5000mAh Battery Magnetic Wireless Power Bank
- 1x 8.66-inch USB-C Cable
- 1x Eco-Friendly Fabric Bag
- 1x User Manual



- VEGER Power Bank
- Environmentally Fabric Bag
- Manual
- An 8.66-Inch USB-C Cable

Figure 2: All items included in the VEGER Wireless Portable Charger package.

Initial Setup:

- 1. Charge the Power Bank:** Before first use, fully charge the power bank using the provided USB-C cable and a compatible power adapter (not included). The oval LED indicator will turn red when charging and change color to indicate full charge.
- 2. Connect to Find My (Optional but Recommended):** For enhanced security and tracking, connect your power bank to the Apple Find My app on your iPhone. This allows you to effortlessly locate your power bank anytime, anywhere.

3. OPERATING INSTRUCTIONS

Wireless Charging:

The power bank supports 15W wireless fast charging for iPhone 16/15/14/13/12 series and other compatible wireless-charging devices. Simply align your device with the magnetic charging area on the power bank. The powerful magnetic attachment ensures stable and efficient charging.



Stronger Magnetic Connection

Magnetic attraction increased by 10% enhancing its safety.

Charge directly for iPhone 16/15/14/13



Please use a compatible case for other wireless charging phone



Note: Data based on internal tests with similar 5000mAh wireless portable chargers.

Figure 3: Demonstrating the strong magnetic connection for wireless charging.

Charge in a Snap

Power On Instantly When Connected



The Oval LED Turns Red

Showing that it's in wireless charging mode

Figure 4: The oval LED turns red, indicating wireless charging is active.

Wired Charging:

For devices requiring wired charging, use the provided USB-C cable. The power bank supports 20W wired fast charging. You can charge one device wirelessly and another via wired connection simultaneously.

Fast Charging Portable Charger



Figure 5: The power bank offers both 15W wireless and 20W wired fast charging.

Using the Multi-Angle Stand:

The integrated foldable stand supports both horizontal and vertical viewing angles. This feature is convenient for hands-free use during video calls, watching media, or working.

Serve as a Phone Stand

Charge and Watch Anytime




Figure 6: The foldable stand allows for versatile viewing angles while charging.

Hidden Card Slots:

The power bank features a discreet built-in card slot that securely holds up to 2 cards (e.g., credit cards, ID). Crafted with zinc alloy, it blocks RFID signals to protect your cards from skimming and theft.

Serve as a Wallet

Equipped with Anti-theft Features



2-in-1

POWER BANK

+

CARD CASE

*Please remove the card from the slot before using it.

Figure 7: The power bank doubles as a secure wallet with hidden card slots.

Note: Please remove the card from the slot before using it for payment or scanning.

Global Tracking with Find My:

Leverage the built-in global tracking feature by connecting the power bank to your iPhone's Apple Find My app. This allows you to locate your power bank if misplaced, and even play a sound to help find it nearby.

Your browser does not support the video tag.

Video 1: Official product video demonstrating various features including magnetic attachment, card slots, and Find My functionality.

4. MAINTENANCE

To ensure the longevity and optimal performance of your VEGER Wireless Portable Charger, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Durability:** Engineered with robust layered armor (aluminum alloy + dynamic springs), the power bank is designed to withstand drops and impacts. However, excessive force or intentional damage should be avoided.
- **Battery Care:** For optimal battery health, avoid fully discharging the power bank frequently. Recharge it when the battery level is low.

5. TROUBLESHOOTING

If you encounter issues with your VEGER Wireless Portable Charger, refer to the following common troubleshooting steps:

Problem	Possible Cause / Solution
Device not charging wirelessly.	Ensure your device is wireless charging compatible. Check for proper alignment of your device with the power bank's magnetic charging area. Remove any thick cases or metallic objects between the power bank and your device. Ensure the power bank itself is charged.
Slow charging speed.	Verify your device supports fast charging. For wired charging, ensure you are using a compatible USB-C cable and adapter. Wireless charging is generally slower than wired charging.
Power bank not charging.	Ensure the USB-C cable is securely connected to both the power bank and the power adapter. Try a different USB-C cable or power adapter.
Power bank is getting hot.	It is normal for the power bank to warm up during charging. If it becomes excessively hot, disconnect it immediately and allow it to cool down. Ensure proper ventilation.
Cannot locate with Find My.	Ensure the power bank is properly paired with your Apple Find My app. Check if the power bank's battery is completely depleted.

6. SPECIFICATIONS

Feature	Detail
Brand	VEGER
Model Number	W0582
Battery Capacity	5000 Milliamp Hours
Product Dimensions	3.04 x 1.38 x 0.97 inches
Item Weight	5.4 ounces
Connector Type	USB Type C

Feature	Detail
Wireless Charging Output	Up to 15W
Wired Charging Output	Up to 20W
Special Features	Lightweight, Slim, Fast Charging, Wireless Charging, Multi-Angle Stand, Hidden Card Slots, Global Tracking (Find My)
Material	Aluminum Alloy, Dynamic Springs (for durability), Zinc Alloy (for RFID blocking)
Airline Safe	Compliant with FAA air travel regulations

7. WARRANTY AND SUPPORT

Your VEGER Wireless Portable Charger comes with a **12-month worry-free warranty**. For any product-related inquiries, technical assistance, or warranty claims, please contact our customer service team.

We offer **7 day/24h friendly customer service** to ensure your satisfaction.

Please refer to the contact information provided in the included user manual or visit the official VEGER website for support details.