



Manuals.plus /

› **fancole** /

› FANCOLE Portable Air Conditioner User Manual

fancole DL3

FANCOLE Portable Air Conditioner User Manual

Model: DL3

INTRODUCTION

Thank you for choosing the FANCOLE Portable Air Conditioner. This evaporative air cooler is designed to provide personalized cooling and enhance your comfort. It features multiple operating modes and fan speeds to suit various preferences and environments. Please read this manual thoroughly before operating the device to ensure proper use, maintenance, and safety. Keep this manual for future reference.

SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not operate the appliance with a damaged cord or plug.
- Do not place the appliance near heat sources or in direct sunlight.
- Ensure the appliance is placed on a stable, level surface to prevent tipping.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug the appliance from the power outlet when not in use, before cleaning, or before performing any maintenance.
- Keep out of reach of children and pets.
- Do not block air inlets or outlets.
- Use only the power supply specified for this appliance.
- Do not attempt to repair or modify the appliance yourself. Contact qualified service personnel for repairs.

PRODUCT OVERVIEW



Figure 1: The FANCOLE Portable Air Conditioner in blue, shown with its remote control and four reusable ice packs. The unit features a top control panel, horizontal louvers for air output, and a visible water level indicator on the front. It is equipped with wheels for easy mobility.

Components

- 1 x Evaporative Air Cooler Unit

- 1 x Remote Control
- 4 x Reusable Ice Packs
- User Manual (this document)

Key Features

- **4 Operating Modes:** Cooling, Sleep, Normal, and Nature for versatile comfort.
- **3 Fan Speeds:** Low (4 m/s), Medium (6 m/s), and High (8.2 m/s) to customize airflow.
- **12 Cooling Combinations:** Offers a wide range of settings for optimal personal comfort.
- **Portable Design:** Equipped with wheels for easy movement between rooms.
- **Evaporative Cooling:** Utilizes water and ice packs for enhanced cooling effect.

SETUP

1. **Unpacking:** Carefully remove the air cooler and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the unit on a firm, level surface. Ensure there is adequate space around the unit for proper airflow (at least 20 cm from walls or furniture).
3. **Filling the Water Tank:**
 - Locate the water tank access point, typically at the bottom rear or side of the unit.
 - Fill the water tank with clean, cool water. Do not exceed the "MAX" fill line indicated on the water level indicator.
4. **Adding Ice Packs (Optional for Enhanced Cooling):**
 - Place the provided reusable ice packs in a freezer until completely frozen.
 - Once frozen, place the ice packs into the water tank. This will help to lower the water temperature and provide cooler air.
5. **Power Connection:** Plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

The FANCOLE Portable Air Conditioner can be operated using the control panel on top of the unit or the included remote control.

Control Panel / Remote Control Functions

- **Power Button ():** Press to turn the unit ON or OFF.
- **Mode Button (MODE):** Press to cycle through the 4 operating modes:
 - **Cooling Mode:** Provides evaporative cooling.
 - **Sleep Mode:** Operates quietly with reduced fan speed for undisturbed sleep.
 - **Normal Mode:** Standard fan operation without evaporative cooling.
 - **Nature Mode:** Simulates natural breeze by varying fan speed.
- **Speed Button (FAN SPEED):** Press to adjust fan speed: Low, Medium, High.
- **Timer Button (TIMER):** Sets the operating time before automatic shutdown (if available on model).
- **Swing Button (SWING):** Activates or deactivates the oscillation function for wider air distribution.

Initial Operation

1. Ensure the water tank is filled and the unit is plugged in.
2. Press the Power Button to turn on the unit.

3. Select your desired operating mode using the Mode Button. For cooling, select "Cooling Mode".
4. Adjust the fan speed using the Speed Button to your preferred airflow intensity.
5. Activate the Swing function for broader air circulation if desired.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air cooler. Always unplug the unit before cleaning.

Cleaning the Water Tank

- Empty the water tank regularly, especially if the unit will not be used for an extended period.
- Clean the water tank with a soft cloth and mild detergent. Rinse thoroughly with clean water.
- Allow the tank to air dry completely before reassembling or storing.

Cleaning the Air Filter

- The air filter should be cleaned every two weeks or more frequently depending on usage and air quality.
- Remove the filter from the back of the unit (refer to diagram in product manual if available).
- Rinse the filter under running water to remove dust and debris. For stubborn dirt, use a soft brush.
- Allow the filter to dry completely before placing it back into the unit.

Exterior Cleaning

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.

Storage

- If storing the unit for an extended period, ensure the water tank is empty and clean, and the filter is dry.
- Store the unit in a cool, dry place, away from direct sunlight and extreme temperatures.
- It is recommended to store the unit in its original packaging to protect it from dust and damage.

TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide for common issues.

| Problem | Possible Cause | Solution |
|------------------------|--|--|
| Unit does not turn on. | No power supply; Power cord not properly plugged in. | Check if the unit is plugged into a working outlet. Ensure the power cord is securely connected. |
| No cool air. | Water tank empty; Cooling mode not selected; Ice packs not used or melted. | Fill the water tank. Select "Cooling Mode". Add frozen ice packs to the water tank. |
| Weak airflow. | Air filter clogged; Fan speed set too low. | Clean the air filter. Increase the fan speed setting. |
| Unusual noise. | Unit not on a level surface; Obstruction in fan. | Place the unit on a stable, level surface. Check for any foreign objects obstructing the fan blades. |
| Water leakage. | Water tank overfilled; Tank not properly seated. | Do not exceed the "MAX" fill line. Ensure the water tank is correctly inserted and sealed. |

SPECIFICATIONS

| Specification | Detail |
|--------------------------------|--|
| Brand | FANCOLE |
| Model Number | DL3 |
| Color | Blue |
| Material | Plastic |
| Special Features | Adjustable Speed |
| Included Components | 1 Evaporative Air Cooler |
| Product Dimensions (L x W x H) | 32.51 x 35.56 x 65.28 cm (12.8 x 14 x 25.7 inches) |
| Item Weight | 6.5 kg (14.33 Pounds) |
| Power Source | Corded Electric (Standalone) |
| Fan Speeds | Low (4 m/s), Medium (6 m/s), High (8.2 m/s) |
| Operating Modes | Cooling, Sleep, Normal, Nature |

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the warranty card included with your purchase or contact the retailer. If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact FANCOLE customer support.

- **Customer Support:** Refer to your purchase documentation for contact details.
- **Online Resources:** Visit the official FANCOLE website for FAQs and additional support.