

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Feihe](#) /

› [Feihe 12-Inch Portable Small TV \(Model SR-116\) User Manual](#)

Feihe SR-116

Feihe 12-Inch Portable Small TV (Model SR-116) User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. INTRODUCTION

This manual provides detailed instructions for the Feihe 12-Inch Portable Small TV, Model SR-116. This device features an HD display, HDMI and USB ports, and a built-in digital ATSC tuner, making it suitable for various applications including home, kitchen, RV, and travel use. Please read this manual thoroughly before operating the television to ensure proper use and to maximize its performance.



Image 1.1: Feihe 12-Inch Portable Small TV, showing the front display, included remote control, and portable antenna.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Feihe 12-Inch Portable TV
- Remote Control
- AC Adapter (for 110-240 volts)
- Car Charger Adapter
- AV Cable
- Portable Antenna

3. PRODUCT OVERVIEW

3.1. Rear Panel Connections

The rear panel of the television provides various ports for connecting external devices and power sources.

Multiple Power Supply Methods

You can enjoy the pleasure of entertainment from anywhere



Image 3.1: Diagram illustrating the DC IN, USB, HD IN (HDMI), Earphone, AV IN, and TV IN (RF) ports on the rear of the television.

- **DC IN:** Power input port.
- **USB:** For connecting USB storage devices to play media files.
- **HD IN (HDMI):** For connecting devices such as gaming consoles, DVD players, or streaming sticks.
- **Earphone:** 3.5mm audio output for headphones.
- **AV IN:** For connecting devices using the included AV cable.
- **TV IN (RF):** For connecting the portable antenna or a standard antenna for digital TV reception.

4. SETUP

4.1. Stand Installation

To install the stand:

1. Insert the support post of the stand directly into the square base round hole.
2. Place the round post of the support column into the back case of the TV.
3. Cover the round post of the support column with the raised cover and secure it with screws.

12 Inch Small TV Dimensions And Details

NOTE: PLEASE SEE DIMENSIONS BELOW TO ENSURE FITMENY




Image 4.1: Visual guide for assembling the television stand.

4.2. Power Connection

The TV can be powered using the included AC adapter for standard outlets or the car charger adapter for vehicle use.

- **AC Adapter:** Connect the AC adapter to the DC IN port on the TV and plug it into a standard wall outlet.
- **Car Charger Adapter:** Connect the car charger adapter to the DC IN port on the TV and plug it into your vehicle's 12V power socket.

Wide Range of Connectivity Multiple Devices



Image 4.2: Illustration of the two power supply methods: AC adapter for home use and car charger adapter for portable use.

4.3. Antenna Connection

To receive local digital channels, connect the portable antenna to the TV IN (RF) port. For optimal signal reception, place the antenna near a window or outdoors if possible. Signal strength can vary based on location and proximity to broadcast towers.

FREE LOCAL HD CHANNELS

Built-In Digital ATSC Tuner



NOTE:The strength of the antenna signal depends on the strength of the local signal tower, Placing the antenna near the window or outdoors will get stronger signal reception.

Image 4.3: The portable TV connected to its antenna, indicating reception of local HD channels. Note: This TV is not compatible with network/satellite/other network providers' signals.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

Press the 'POWER' button on the TV's side panel or on the remote control to turn the TV on or off.

5.2. Initial Setup and Channel Scan

Upon first use or after a factory reset, the TV will guide you through an initial setup process. This typically includes selecting your language and performing an automatic channel scan to find available digital channels via the connected antenna.

5.3. Using the Remote Control

The included remote control is designed specifically for this Feihe 12-Inch TV. It is not compatible with universal remotes or remotes provided by cable service providers (e.g., Xfinity, Direct TV, Comcast, Verizon). Ensure a clear line of sight to the TV's IR sensor when using the remote.

Feihe 12 Inch TV ONLY WORK WITH THE INCLUDED REMOTE

Note: Because the remote control code is different, 12" TV not compatible with any cable service provided remote or universal remotes!



Image 5.1: The Feihe 12-Inch TV remote control and a visual representation of its incompatibility with other cable service remotes.

5.4. Menu Navigation

Press the 'MENU' button on the remote or TV to access the on-screen display (OSD) menu. Use the arrow buttons to navigate through options and 'OK' or 'ENTER' to confirm selections. Adjust settings such as picture, sound, and channel management here.

5.5. Input Source Selection

Press the 'SOURCE' button on the remote or TV to cycle through available input sources (TV, HDMI, USB, AV).

6. CONNECTIVITY

The Feihe 12-Inch Portable TV offers multiple connectivity options for various entertainment needs.

- **HDMI Input:** Connect external devices like gaming consoles, DVD players, or streaming devices for high-definition video and audio.
- **USB Playback:** Insert a USB drive into the USB port to view photos, play music, or watch videos stored on the drive.
- **AV Input:** Use the included AV cable to connect older devices with composite video and stereo audio outputs.
- **Headphone Output:** Connect standard 3.5mm headphones for private listening.

7. SPECIFICATIONS

Technical specifications for the Feihe 12-Inch Portable Small TV, Model SR-116.

Feature	Specification
---------	---------------

Feature	Specification
Brand	Feihe
Model Number	SR-116
Screen Size	12 Inches (11.6 inches visible display)
Display Technology	LCD
Resolution	720p
Refresh Rate	60 Hz
Aspect Ratio	16:9
Connectivity Technology	HDMI, RF, USB
Special Features	Built-In Speaker, Flat, Portable, Wide Viewing Angle
Product Dimensions	1.18"D x 11.8"W x 11.02"H
Item Weight	4.09 pounds (1.86 Kilograms)
Voltage	240 Volts (AC)
Wattage	12 watts

EASY TO INSTALL



1 Step 1: Put the support post of the stand directly into the square base round hole.



2 Step 2: Place the round post of the support column into the back case of the TV.



3 Step 3: Cover the round post of the support column with the raised cover and then lock the four holes with screws

Image 7.1: Detailed dimensions of the Feihe 12-Inch Portable Small TV.

8. TROUBLESHOOTING

This section addresses common issues you might encounter with your Feihe 12-Inch Portable Small TV.

8.1. No Power

- Ensure the power adapter is securely connected to both the TV's DC IN port and a working power outlet.
- If using the car charger, ensure the vehicle's 12V socket is active.
- Check if the power outlet is functioning by plugging in another device.

8.2. No Signal / Poor Picture Quality (Antenna)

- Verify the antenna is securely connected to the TV IN (RF) port.
- Adjust the position of the antenna, ideally near a window or outdoors, to improve signal reception.
- Perform a channel scan from the TV's menu to search for available channels.
- Signal strength for local channels can vary significantly by location. Consider a different antenna if reception remains poor.

8.3. Remote Control Not Responding

- Ensure there are fresh batteries in the remote control, inserted with correct polarity.
- Point the remote directly at the TV's IR sensor, ensuring no obstructions.
- The remote is specific to this TV model; universal remotes are not compatible.

8.4. No Picture / No Sound from External Device (HDMI/AV)

- Ensure the external device is powered on and functioning correctly.
- Verify that the correct input source (HDMI or AV) is selected on the TV.
- Check all cable connections between the TV and the external device.

9. MAINTENANCE

Proper care and maintenance will extend the life of your television.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Casing:** Use a soft, dry cloth to wipe the TV's casing.
- **Storage:** When not in use for extended periods, store the TV in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the TV to rain or moisture. Avoid placing liquids near the TV.
- **Ventilation:** Ensure the TV's ventilation openings are not blocked to prevent overheating.

10. WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or contact Feihe customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.