

[Manuals.plus](#) /

› [Outfunny](#) /

› Outfunny 2-Seater Kids Ride-On Car User Manual

Outfunny B0DNFL2FVX

Outfunny 2-Seater Kids Ride-On Car User Manual

Model: B0DNFL2FVX

Brand: Outfunny

1. PRODUCT OVERVIEW

Ride, cruise, and explore together! Our Outfunny 12V 10Ah 2-seater electric car for big kids with remote, featuring a spacious 21" seat width. Equipped with a USB interface, four-wheel shock absorption for smooth rides, front lights, and an advanced central control 2.4G remote, this 12 Volt kids electric car offers ultimate convenience and excitement. With 3-speeds adjustment and Bluetooth functionality, your little ones can enjoy personalized driving experiences. The kids utv ride on boasts mesh pocket style toolbox, a one-click installation steering wheel with music and horn buttons, and a secure three-point safety belt. The sturdy and durable body can support a maximum weight of 110 pounds. Powered by a robust 12V 10Ah Battery system with a 2WD/4WD switchable function, this electric utv tackles various terrains with ease. Get ready for endless adventures and thrilling rides with our premium 2 seater kids electric utv, the perfect choice for your kids.



The Outfunny 2-Seater Kids Ride-On Car, showcasing its vibrant green color and robust design.

2. SAFETY INFORMATION

Warning:

The child must use the product under adult supervision.

Always ensure children wear appropriate safety gear, including helmets and seatbelts, when operating the vehicle. Do not operate near roads, steep inclines, or water bodies.

3. PARTS LIST

Before assembly, verify all components are present:

- Car body
- Motor
- Lead Acid Battery
- Wheels (4)
- Seats (2) with safety belts
- Steering Wheel
- Remote Control
- Charger
- Assembly Hardware (screws, nuts, washers, pins)
- Front and Rear Roll Bars
- Shock Absorbers

- Rear Storage Net
- Front Lights
- Rear Lights
- Side Support Bars



The Outfunny 2-Seater Kids Ride-On Car, designed to comfortably fit two children for shared adventures.

4. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. Refer to the assembly video for visual guidance.

Your browser does not support the video tag.

Official assembly video for the Outfunny 2-Seater Kids Ride-On Car, demonstrating each step of the setup process.

4.1 Initial Preparation

Carefully remove all components from the packaging. Place the main car body upside down on a soft, clean surface to prevent scratches.

4.2 Installing the Front Suspension

Attach the front suspension components to the designated points on the car's chassis. Secure them using the provided bolts and nuts. Ensure all connections are tight.



Rear view of the vehicle, highlighting the robust suspension system and motor housing.

4.3 Attaching the Rear Motors and Wheels

Connect the motor assemblies to the rear axle. Ensure the electrical connections are secure. Slide the wheels onto the axles, aligning the hexagonal slots. Secure each wheel with the provided washers and nuts, then attach the decorative hubcaps.



The Outfunny 2-Seater Kids Ride-On Car with all four wheels securely attached, ready for further assembly.

4.4 Installing the Steering Wheel

Connect the steering wheel's electrical cable to the corresponding port on the dashboard. Carefully slide the steering wheel onto the steering column until it clicks into place.

4.5 Connecting the Battery

Locate the battery compartment, usually under the seat. Connect the red terminal to the positive (+) battery post and the black terminal to the negative (-) battery post. Ensure connections are firm.

4.6 Securing the Seats

Place the two-seater assembly into the car body. Align the mounting points and secure the seat with the provided screws. Ensure the safety belts are accessible and properly installed.



A close-up view of the spacious 21-inch wide two-seater, featuring individual safety belts for each child.

4.7 Attaching Roll Bars and Accessories

Install the front and rear roll bars, securing them with screws. Attach any additional accessories like the rear storage net and front lights as per the instructions.



The convenient rear storage space allows children to bring their favorite toys along for the ride.

5. OPERATING INSTRUCTIONS

5.1 Powering On

Turn the power switch to the "ON" position. The dashboard lights should illuminate.

5.2 Driving Modes

The vehicle offers two operating modes:

- **Manual Driving:** Children can operate the car using the foot pedal and steering wheel.
- **Remote Control:** Parents can use the 2.4G remote control to steer, accelerate, and brake the vehicle. This is ideal for younger children or for safety supervision.

Kids Drive & Remote Control



The dual control system allows for both child-driven fun and parental remote supervision.

5.3 Speed Adjustment

Use the speed selection button on the dashboard or remote control to switch between 3 available speeds.

5.4 2WD/4WD Function

The vehicle features a switchable 2WD/4WD function for optimal traction on various terrains. Switch to 4WD for rougher surfaces and 2WD for smoother paths to conserve battery.

5.5 Multimedia Features

The car is equipped with a built-in music player, speakers, and Bluetooth connectivity. Connect your device via Bluetooth to play your child's favorite music.



Easily connect your device via Bluetooth to stream music, enhancing the driving experience.

6. CHARGING INSTRUCTIONS

To charge the vehicle's 12V 10Ah battery:

1. Ensure the car is turned off.
2. Locate the charging port, typically near the dashboard or under the seat.
3. Plug the charger into the charging port, then plug the charger into a standard wall outlet.
4. The charging indicator light on the charger will show the charging status (e.g., red for charging, green for fully charged).
5. A full charge typically takes 8-12 hours. Do not overcharge.
6. Disconnect the charger once charging is complete.

7. MAINTENANCE

7.1 Cleaning

Wipe the car's surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.

7.2 Battery Care

Charge the battery fully after each use. If storing the vehicle for an extended period, charge the battery once a month to prolong its lifespan.

7.3 Storage

Store the vehicle in a dry, cool place away from direct sunlight and moisture.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not move	Battery low or disconnected; Power switch off; Loose wiring	Charge battery; Turn power switch on; Check all electrical connections
Remote control not working	Remote battery low; Not paired correctly	Replace remote batteries; Re-pair remote control (refer to remote manual)
Slow speed or loss of power	Low battery charge; Overloaded vehicle; Worn motor	Fully charge battery; Reduce load; Contact customer support for motor replacement
Unusual noises	Loose parts; Debris in wheels/motors	Check for loose components and tighten; Remove any obstructions

9. SPECIFICATIONS

- **Product Dimensions:** 47.24 x 31.89 x 32.68 inches
- **Item Weight:** 63.9 pounds
- **Recommended Age:** 3 years and up
- **Load Capacity:** Up to 110 pounds
- **Battery:** 12V 10Ah Lead Acid Battery
- **Motors:** 4 x 40W
- **Speed:** 1.9-3.1 MPH (3-speeds adjustment)
- **Features:** 2WD/4WD switchable, Remote Control, Bluetooth, Front Lights, Rear Searchlights, Built-in Music Player, Speakers, Mesh Pocket Style Toolbox, Three-point Safety Belt, Four-wheel Shock Absorption

Product Dimensions



Recommended age:
3-8 Years old



Load Capacity:
110 lbs



Detailed product dimensions and load capacity for the Outfunny 2-Seater Kids Ride-On Car.

10. WARRANTY AND SUPPORT

For warranty information, please refer to the product's original packaging or contact Outfunny customer support directly.

For technical assistance or replacement parts, please visit the official Outfunny website or contact their customer service team.

You can find more information and support at: [Outfunny Product Page](#)