Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TECLAST P30T

TECLAST P30T 10-inch Android 15 Tablet User Manual

Model: P30T

Introduction

This manual provides detailed instructions for setting up, operating, and maintaining your TECLAST P30T 10-inch Android 15 Tablet. Please read this manual thoroughly before using your device to ensure proper functionality and to maximize your user experience.



Image: TECLAST P30T Tablet showcasing the Android 15 interface and key features.

Package Contents

Verify that all items are present in your package:

- TECLAST P30T Tablet
- Protective Case
- Bluetooth Keyboard
- Wireless Mouse
- Stylus

- Screen Protector
- Camera Protection Film
- 3.5mm Headphones
- Tablet Stand
- Charger + Type-C Cable
- OTG Converter
- User Manual



Image: All accessories included with the TECLAST P30T tablet.

Setup

1. Initial Power On and Basic Settings

1. Press and hold the power button until the TECLAST logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. Configure basic settings such as date, time, and screen lock method (PIN, pattern, password, or face recognition).

2. Charging the Tablet

Connect the provided Type-C cable to the tablet's charging port and the other end to the charger. Plug the charger into a power outlet. The battery indicator will show charging status.



Image: The TECLAST P30T tablet highlighting its 6000mAh battery and Type-C charging port.

3. Connecting Bluetooth Accessories (Keyboard & Mouse)

To connect the Bluetooth keyboard and mouse:

1. Turn on the Bluetooth mouse/keyboard. Ensure they are in pairing mode (usually indicated by a blinking light).
2. On your tablet, go to **Settings** > **Connected devices** > **Pair new device**.
3. Select the device name (e.g., "BT5.2 Mouse" or "TECLAST K10") from the list of available devices.
4. Confirm the pairing request on both devices if prompted.



Image: Step-by-step guide for connecting the TECLAST Bluetooth mouse.



Image: Step-by-step guide for connecting the TECLAST Bluetooth keyboard.

4. Inserting Micro SD Card

The tablet supports up to 1TB Micro SD card expansion. Locate the card slot on the side of the tablet and gently insert the Micro SD card until it clicks into place.

Operating Instructions

1. Android 15 Features

Your TECLAST P30T runs on Android 15, offering enhanced privacy, improved multitasking, and a more personalized user experience. Key features include:

- **Private Space:** Create a secure, separate area for sensitive apps and data.
- **Single App Screen Recording:** Record specific app activity without capturing other screen content.
- **App Pairing:** Easily launch two apps in split-screen mode.
- **Pin-able Taskbar:** Customize your taskbar with frequently used apps.
- **64-bit App Support:** Enjoy smoother performance with optimized applications.
- **Camera Sharing:** Seamlessly share camera access with specific applications.



Image: Overview of new features in Android 15 on the TECLAST P30T tablet.

2. Display and Visuals

The P30T features a 10.1-inch TDDI In-cell IPS display with a resolution of 1280x800 pixels and 350 nits brightness. It supports a maximum touch sampling rate of 120Hz for responsive interaction.



Image: Details on the TECLAST P30T's 10.1-inch IPS display, resolution, brightness, and touch response.

3. Multitasking and Productivity

- **Split Screen:** Use two applications simultaneously by dividing the screen.
- **Floating Window:** Open apps in resizable floating windows for flexible multitasking.
- **Parallel View:** Optimized landscape mode for displaying app content side-by-side, improving information access.
- **3-Finger Screenshot:** Capture screenshots quickly by swiping down with three fingers (enable in Settings > System > Gestures).
- **Dock Bar:** Quick access to frequently used applications.
- **Widget Function:** Customize your home screen with widgets for essential information.



Image: Visual representation of multitasking features like split-screen and floating windows.




Image: Illustrations of 3-finger screenshot, Dock bar, Widget function, and screen split features.

4. Media Consumption and Entertainment

The P30T supports Widevine L1, allowing high-definition streaming from platforms like Amazon Prime Video, Netflix, Disney+, and Hulu. Enjoy immersive audio with PureSound stereo speakers and a digital amplifier chip.

- **Wireless Screen Cast:** Project your tablet's screen wirelessly to a compatible display.
- **Audio:** Dual speakers with PureSound audio and a digital amp chip for enhanced sound. Supports 3.5mm wired headphones.
- **Reading Modes:** Night Mode, Read Mode, and Dark Mode to reduce eye strain.



Image: Demonstrates wireless screen casting from the TECLAST P30T to a TV.



Image: Visual of the TECLAST P30T's stereo sound and digital amplifier chip for epic audio.




Image: Explains Night Mode, Read Mode, Dark Mode, and adjustable screen brightness for comfortable reading.

5. Navigation and GPS

The P30T supports four major satellite positioning systems (Beidou, GPS, GLONASS, GALILEO) for accurate navigation globally.



Image: Demonstrates the TECLAST P30T's precise GPS navigation capabilities in a car setting.

6. Camera Features

The tablet features a 5MP rear camera with autofocus and a 2MP front camera for HD video calls. It includes AI focus and "FaceGlam" beautification features for enhanced photos.



Image: Highlights the 5MP rear camera, 2MP front camera, and flashlight for capturing moments.

パラレルビュー

タブレットランドスケープ可用性を最大化。

Teclastは、ランドスケープモード（横向きモード）でのパラレルビュー（並列表示）を導入して、サポートアプリを改善しました。
パラレルビューは、タブレットの画面を横方向に分割して、アプリのメインメニューとコンテンツページを同時に表示することで、アプリを使いやすくし、一度に多くの情報にアクセスできるようにします。




Image: Demonstrates the "FaceGlam" beautification feature of the P30T camera.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security. Go to **Settings** > **System** > **System update**.
- **Battery Care:** To prolong battery life, avoid extreme temperatures and do not let the battery completely drain frequently.
- **Storage Management:** Periodically clear unnecessary files and apps to maintain sufficient storage space and performance.

Troubleshooting

- **Tablet not turning on:** Ensure the tablet is charged. Connect it to the charger and wait a few minutes before attempting to power it on again.
- **Slow performance:** Close unused applications, clear cache, or restart the tablet. Consider uninstalling large or unnecessary apps.
- **Wi-Fi connection issues:** Restart your Wi-Fi router and the tablet. Forget the network and reconnect. Ensure you are within range of the Wi-Fi signal.
- **Bluetooth pairing issues:** Ensure both devices are in pairing mode and within range. Restart Bluetooth on both devices.
- **Screen unresponsive:** Restart the tablet. If the issue persists, perform a factory reset (backup data first).

Specifications

Feature	Detail
Brand	TECLAST
Model Series	P30T
Operating System	Android 15

Processor	Unisoc T606 Octa-core
RAM	12 GB (4GB + 8GB Expansion)
Internal Storage	128 GB
Expandable Storage	Up to 1 TB Micro SD
Display Size	10.1 inches
Display Resolution	1280x800 pixels
Brightness	350 nits
Touch Refresh Rate	Max 120Hz
Battery Capacity	6000 mAh
Rear Camera	5 MP (Autofocus)
Front Camera	2 MP (HD Video Calls)
Wireless Connectivity	Dual-band Wi-Fi (2.4G+5G), Bluetooth 5.0
GPS	Beidou, GPS, GLONASS, GALILEO
Biometric Authentication	Face Recognition
Weight	442g
Thickness	8.8mm




Image: Detailed comparison of TECLAST P30T specifications with previous models.

Warranty and Support

Warranty Information

TECLAST provides a **12-month manufacturer's warranty** for the P30T tablet. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.



Image: Information regarding TECLAST's one-year quality assurance and customer support.

Customer Support

If you have any questions or encounter issues with your TECLAST P30T tablet, please contact customer support:

1. **Before Ordering:** On the product page, click on the store name**[TECLAST Official Store]** below the "Add to Cart" button, then click "Contact Seller" in the upper right corner to send an email.
2. **After Ordering:** Go to your Amazon account > Order History > Select the relevant order > Contact Seller.

Customer support is available Monday to Friday, 10:00 AM to 7:00 PM (Japan time). Inquiries received after 7:00 PM or on holidays will be answered on the next business day. We aim to respond to emails within 24-72 hours.



Image: Details on how to contact TECLAST customer support and their response times.

© 2024 TECLAST. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNFPGJ1B

More documents and user manuals: **https://manuals.plus/**