



cARTICA

# User Manual: Compatible Remote Control for ARTICA Air Conditioners

Model: cARTICA

## INTRODUCTION

---

This manual provides comprehensive instructions for the setup, operation, and maintenance of your new compatible remote control for ARTICA air conditioning units. This remote control is designed to offer the same functionalities as your original ARTICA remote, ensuring seamless control over your air conditioner's various modes and settings.

Please read this manual carefully before first use to ensure proper functionality and to maximize the lifespan of your device. Keep this manual for future reference.

## PACKAGE CONTENTS

---

- 1 x Compatible Remote Control for ARTICA Air Conditioners
- 2 x AAA Batteries
- 1 x Adhesive Wall Holder
- 1 x User Manual (this document)



This image illustrates the remote control, the included AAA batteries, and the adhesive holder for convenient storage.

## SETUP

---

### 1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert the two included AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

# PILAS INCLUIDAS GRATIS



The remote control requires two AAA batteries, which are supplied with the product.

## 2. Mounting the Adhesive Holder

The included adhesive holder allows for convenient storage of your remote control. Choose a clean, dry, and smooth surface near your air conditioning unit for optimal accessibility.

1. Clean the desired mounting surface thoroughly to ensure good adhesion.
2. Peel off the protective backing from the adhesive strip on the holder.
3. Press the holder firmly onto the chosen surface for at least 30 seconds.
4. Allow the adhesive to set for a few hours before placing the remote control in the holder.

## 3. Initial Configuration (Pairing with ARTICA AC Unit)

This remote control requires a simple configuration process to pair with your ARTICA air conditioning unit. This process must be performed directly in front of the air conditioner.

1. Ensure your ARTICA air conditioning unit is powered on and in standby mode.

2. Point the remote control directly at the infrared receiver on your ARTICA air conditioner.
3. Press and hold the "SET" or "CODE" button (refer to the remote's button layout if different) until the numbers on the remote's LED screen start flashing or a code search begins.
4. Release the button. The remote will now automatically cycle through various codes. Observe your air conditioner for a response (e.g., a beep, a change in display, or the unit turning on/off).
5. Once your air conditioner responds, immediately press any button (e.g., "ON/OFF" or "OK") on the remote to confirm and save the code.
6. Test all functions of the remote control to ensure proper operation. If some functions do not work, repeat the configuration process.

**Important Note:**

- This remote is compatible with ARTICA Split-type air conditioners (wall-mounted units).
- It is **NOT VALID** for portable or centralized duct ARTICA air conditioning systems.

## OPERATING INSTRUCTIONS

---

Your compatible remote control provides full functionality for your ARTICA air conditioner. The remote features an LED screen for clear display of settings.

# TODAS LAS FUNCIONES DE SU MANDO ORIGINAL



The remote supports both cooling and heating functions, indicated by snowflake and sun icons.

## Key Functions:

- **Temperature Regulation:** Adjust the desired temperature using the temperature up/down buttons.
- **Cool/Heat Change:** Switch between cooling and heating modes (and other modes like Fan, Dry, Auto) using the "MODE" button.
- **Speed Regulation:** Control the fan speed (e.g., Low, Medium, High, Auto) using the "FAN SPEED" button.
- **Air Direction Regulation:** Adjust the air swing/louver direction using the "AIR SWING" button.
- **Timed On/Off Programming:** Set specific times for the air conditioner to turn on or off automatically using the "TIMER" or "SET" buttons in conjunction with time adjustment buttons. Refer to your original ARTICA AC manual for specific timer programming steps if needed.
- **LED Screen:** Displays current temperature, mode, fan speed, and other active settings.

## General Operation Tips:

- Ensure there are no obstructions between the remote control and the air conditioner's infrared receiver.

- Point the remote directly at the air conditioner for optimal signal transmission.
- The effective range of the remote control is typically up to 8 meters (26 feet) without obstacles.

## MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the surface or internal components.
- **Battery Replacement:** If the remote control's range decreases or the LED screen dims, it's time to replace the batteries. Always replace both AAA batteries at the same time with new ones. Dispose of used batteries responsibly according to local regulations.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage and potential damage to the remote control. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote control from physical shocks and drops, which can damage internal circuitry.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead or incorrectly inserted.	Replace batteries with new ones, ensuring correct polarity.
Remote control not responding to AC unit.	Not properly configured/paired with the AC unit. Obstruction between remote and AC. Remote out of range.	Repeat the "Initial Configuration" steps. Remove any obstructions. Ensure you are within effective range (approx. 8 meters).
Some functions not working after configuration.	Incorrect code saved during configuration.	Repeat the "Initial Configuration" process. Ensure you press "OK" or any button immediately when the AC unit responds to save the correct code.
LED screen is dim or flickering.	Low battery power.	Replace batteries.

If you continue to experience issues after attempting these solutions, please contact customer support.

## SPECIFICATIONS

<b>Brand</b>	Generic
<b>Model Name</b>	compatible ARTICA
<b>Product Model Number</b>	cARTICA
<b>Compatible Devices</b>	ARTICA Split-type Air Conditioners (wall-mounted)
<b>Connectivity Technology</b>	Infrared
<b>Special Feature</b>	Ergonomic design
<b>Power Source</b>	2 x AAA Batteries (included)
<b>Product Dimensions</b>	5 x 2 x 10 cm (Length x Width x Height)
<b>Color</b>	Cream White
<b>Maximum Supported Devices</b>	Up to 6 (This remote is pre-programmed for ARTICA compatibility)

## WARRANTY INFORMATION

---

This product comes with a guaranteed availability of spare parts in the EU for a period of 3 years from the date of purchase. This warranty covers manufacturing defects and material faults under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims, please retain your proof of purchase and contact customer support.

## CUSTOMER SUPPORT

---

For any questions, assistance with configuration, or troubleshooting, our technical support team is available to help you. You can reach us via WhatsApp for quick assistance, including video support for setup guidance.

# ATENCIÓN AL CLIENTE 24H

QUEREMOS AYUDARTE



# 622822020



Contact our customer support via WhatsApp for assistance.

**WhatsApp Support: +34 622 822 020**

We aim to provide prompt and helpful support to ensure your satisfaction with the product.

