

[Manuals.plus](#) /

› [Promixx](#) /

› Promixx PRO Shaker Bottle New Edition Instruction Manual

Promixx PRO-VM-PRO-P-GO-12-V3

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

[Submit question](#)

Promixx PRO Shaker Bottle New Edition Instruction Manual

MODEL: PRO-VM-PRO-P-GO-12-V3

1. Product Overview

The PROMIXX PRO Shaker Bottle is engineered for superior performance and functionality. This rechargeable mixer features advanced technology for smooth protein and supplement shakes. It includes industry-leading seals, impact and odor-resistant materials, and a detachable motor unit for easy cleaning. The design offers a premium, durable finish, making it a reliable choice for athletes and fitness enthusiasts.







PromiXX PRO Shaker Bottle in Graphite Gray, demonstrating the powerful vortex mixing action.

2. Key Features

- **Effortless Mixing:** Patented X-Blade technology ensures super-smooth protein and supplement shakes without lumps.
- **Durable & Easy-to-Clean:** Constructed from tough, odorless, BPA/DEHP-free materials. The detachable motor unit allows for simple cleaning by adding warm water and detergent, then activating the mixer.
- **Integrated Supplement Storage:** Features a NUTRiPOD (4.5oz/130ml) for convenient on-the-go supplement storage, complete with a through-flow lid for use as a water bottle.
- **Powerful Rechargeable Battery:** A long-lasting battery provides many workouts on a single charge. Recharging is done via a supplied USB cable by removing the base.



THE ORIGINAL ELECTRIC SHAKER BOTTLE

A beautifully engineered electric shaker bottle designed to meet the demands of your lifestyle.

🇬🇧 Designed in the UK by **PROMiXX**



Collage showcasing the PromiXX PRO Shaker Bottle in various settings, emphasizing its design and origin.

3. Package Contents

- Promixx PRO Shaker Bottle (20oz/600ml)
- Detachable Motor Unit with X-Blade
- Integrated NUTRiPOD Supplement Storage
- USB Charging Cable



All components of the Promixx PRO Shaker Bottle, including the main cup, detachable motor, integrated NUTRiPOD storage, and USB charging cable.

4. Setup

1. **Initial Charging:** Before first use, fully charge the detachable motor unit. Remove the base, plug in the supplied USB cable, and wait for the indicator light to turn green.
2. **Assembly:** Ensure the motor unit is securely twisted onto the bottom of the main bottle.
3. **NutriPod Installation (Optional):** If using, place the NUTRiPOD into the top opening of the bottle before screwing on the main lid.



DETACHABLE MOTOR



USB-C
2-hour
quickcharge



Battery life
>1 month



Over
30 blends
per charge

Detailed view of the detachable motor unit, showing the USB-C charging port and battery life indicators.

5. Operating Instructions

1. **Add Liquid:** Pour your desired liquid (e.g., water, milk) into the shaker bottle.
2. **Add Powder:** Add your protein or supplement powder. For best results, add liquid first, then powder.
3. **Secure Lid:** Ensure the main lid is tightly screwed onto the bottle and the flip-top cap is securely closed to prevent leaks.
4. **Activate Mixing:** Press the power button on the detachable motor unit to activate the vortex mixer. The patented X-Blade technology will create a powerful vortex to blend your ingredients smoothly.
5. **NutriPod Use:** If you have supplements stored in the NUTRiPOD, you can pour them into the main bottle when ready to mix. The through-flow lid allows you to drink water from the bottle while keeping supplements dry in the NutriPod.

Important: Do not use the shaker bottle for solid foods or ice, as this may damage the motor or blades. For solid items, refer to specialized blenders.



THE POWER
IS IN THE
X-BLADE®

*Experience
a new definition
of **smooth...***

Illustration of the patented X-Blade technology at the base of the bottle, responsible for smooth mixing.

6. Maintenance and Cleaning

1. **Easy Cleaning:** After use, add warm water and a drop of detergent to the bottle. Secure the lid and activate the mixer for a few seconds to self-clean. Rinse thoroughly.
2. **Detachable Motor Unit:** The motor unit is detachable for easy cleaning of the main bottle.
3. **Dishwasher Safe Components:** The main bottle and lid are dishwasher safe.
4. **Motor Unit Care:** The detachable motor unit is **not** dishwasher safe and should **not** be submerged in water. Wipe clean with a damp cloth.
5. **Thorough Cleaning:** Regularly inspect all parts, especially rubber seals and crevices, for any residue buildup to prevent mold or odors. Remove and clean seals as needed.

7. Troubleshooting

- **Mixer Not Activating:** Ensure the motor unit is fully charged. The indicator light should be green when fully charged. Check that the motor unit is securely attached to the bottle.

- **Lumps in Shake:** Ensure liquid is added before powder. For very thick powders, try mixing for a longer duration or adding more liquid.
- **Leaking:** Verify that the lid is tightly screwed on and the flip-top cap is securely closed. Check that all seals are properly seated and free from damage.
- **Unusual Odor/Mold:** Disassemble all parts, including removable seals, and clean thoroughly with warm soapy water. Ensure all parts are completely dry before reassembly and storage.

8. Specifications

Attribute	Detail
Brand	Promixx
Model Name	PRO
Item Model Number	PRO-VM-PRO-P-GO-12-V3
Color	Graphite Gray
Capacity	600 Milliliters (20oz)
Material	Acrylonitrile Butadiene Styrene
Product Dimensions	3.5"W x 9"H
Item Weight	0.56 Kilograms (1.23 pounds)
Battery	1 Lithium Polymer battery (included)
Special Features	Effortless Mixing, Patented X-Blade Technology, Integrated Supplement Storage
Product Care Instructions	Dishwasher Safe (bottle and lid only)

9. Warranty and Support

The Promixx PRO Shaker Bottle comes with a **1-year warranty**. For any questions, support, or warranty claims, please contact Promixx customer service directly. Refer to the product packaging or the official Promixx website for contact details.