

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lionelo](#) /

› [Lionelo Mell Baby Bouncer Instruction Manual](#)

Lionelo LO-MELL

Lionelo Mell Baby Bouncer Instruction Manual

MODEL: LO-MELL

1. SAFETY INFORMATION

WARNING: This product contains a button cell battery. Danger if swallowed - refer to instructions. The product is suitable for children until they attempt to sit up. Complies with standard: EN 12790-1:2023.

- Always use the 5-point safety harness to secure your child.
- Never leave your child unattended in the bouncer.
- Do not use the bouncer if any components are broken or missing.
- Ensure the bouncer is placed on a flat, stable surface.
- Do not lift or carry the bouncer with the child in it.
- Keep away from open flames and other strong heat sources.

2. PRODUCT OVERVIEW

The Lionelo Mell baby bouncer is designed for comfort and safety, offering multiple features to soothe and entertain your baby. It is suitable from birth up to 9 kg.

Mell

Plage de poids :
Dès la naissance jusqu'à 9 kg



BALANCELLE ÉLECTRIQUE BÉBÉ

Image: Lionelo Mell Baby Bouncer, showing its design and indicating a weight range from birth up to 9 kg.

Key Features:

- **Ergonomic Design:** Spacious seat with a bamboo cushion for proper posture.
- **Adjustable & Versatile:** 3 recline positions and 5 rocking speeds.
- **360° Rotation:** Seat rotates for multi-directional movement.
- **Maximum Safety:** 5-point harness and anti-slip pads.
- **Music & Relaxation:** 12 melodies, 2 natural sounds, and Bluetooth connectivity.
- **Convenient Control:** Control panel, remote control, and automatic movement detection.
- **Easy Maintenance:** Removable and machine-washable cover.

3. SETUP AND ASSEMBLY

The Lionelo Mell bouncer requires minimal assembly. Follow these steps to ensure proper setup:

1. Unpack all components and verify against the parts list (not provided in this manual, refer to packaging).
2. Attach the seat frame to the base unit, ensuring it clicks securely into place.
3. Install the toy bar by inserting it into the designated slots on the seat frame.

4. Place the bamboo cushion and seat cover onto the seat, ensuring the harness straps are correctly threaded through the openings.
5. Connect the power adapter to the bouncer and a suitable power outlet.

Mell

Plage de poids :
Dès la naissance jusqu'à 9 kg



BALANCELLE ÉLECTRIQUE BÉBÉ

Image: The Lionelo Mell Baby Bouncer fully assembled, ready for use.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Rocking Functions

- Press the power button on the control panel to turn the bouncer on or off.
- Use the speed buttons to select one of the 5 rocking speeds. Indicators on the panel will light up to show the current speed.



- DÉTECTION AUTOMATIQUE DES MOUVEMENTS
- PANNEAU DE CONTRÔLE ET TÉLÉCOMMANDE
- MINUTERIE 15/30 MIN

Image: Close-up of the bouncer's control panel and a remote control, highlighting the ease of managing settings.

4.2 Recline Positions

The seat offers 3 recline positions for your baby's comfort. Adjust the recline by pressing the adjustment button (usually located on the side or back of the seat) and moving the seat to the desired position. Ensure it locks securely.



Image: The Lionelo Mell Baby Bouncer illustrating its three adjustable recline positions for optimal baby comfort.

4.3 360° Rotation

The bouncer seat can rotate 360 degrees, allowing you to easily change your baby's orientation without moving the entire unit. Gently rotate the seat to the desired direction.



Image: A visual representation of the Lionelo Mell Baby Bouncer's 360-degree rotation capability.

4.4 Music, Sounds, and Bluetooth

- Use the music buttons on the control panel or remote to cycle through 12 melodies and 2 natural sounds.
- To connect via Bluetooth, activate Bluetooth on your device and select "Lionelo Mell" from the available devices. You can then play music directly from your phone or tablet.



Image: A baby resting comfortably in the Lionelo Mell bouncer, with musical notes indicating the sound features.

4.5 Timer Function

The bouncer includes a timer function for 15 or 30 minutes. Activate the timer using the dedicated button on the control panel or remote control. The bouncer will automatically stop after the set time.

4.6 Automatic Movement Detection

The bouncer can detect your baby's movements and automatically activate the rocking function to soothe them. This feature can be enabled or disabled via the control panel or remote.

5. MAINTENANCE

5.1 Cleaning the Seat Cover

The seat cover is removable and machine-washable for easy cleaning. Follow these steps:

1. Unfasten all harness straps and remove the seat cover from the bouncer frame.
2. Machine wash the cover on a gentle cycle with mild detergent. Refer to the care label for specific temperature recommendations.
3. Do not bleach, tumble dry, or iron the cover. Air dry thoroughly before reattaching.
4. Reattach the clean, dry cover to the seat frame, ensuring all harness straps are correctly re-threaded.



● COUSSIN RESPIRANT EN BAMBOU
HOUSSE AMOVIBLE ET LAVABLE

Image: A close-up showing the breathable bamboo cushion and the ease of removing the cover for washing.

5.2 Cleaning the Frame and Base

Wipe the bouncer frame and base with a damp cloth and mild soap. Dry thoroughly. Do not use abrasive cleaners or solvents.

6. TROUBLESHOOTING

- **Bouncer not turning on:** Ensure the power adapter is securely connected to both the bouncer and a working power outlet. Check if the outlet is functional.
- **Rocking function not working:** Verify that the bouncer is powered on and a speed setting is selected.

Ensure no obstructions are preventing movement.

- **No sound from music/Bluetooth:** Check the volume settings on both the bouncer and your connected Bluetooth device. Ensure Bluetooth is correctly paired.
- **Remote control not working:** Check the battery in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the bouncer's sensor.

7. SPECIFICATIONS

Feature	Detail
Model Number	LO-MELL BEIGE SAND
Dimensions (L x W x H)	56 x 78.8 x 80 cm
Weight	5.73 kg
Material	Steel, Plastic, 100% Polyester (cover), 100% Polyester & Bamboo fabric (cushion)
Weight Capacity	Up to 9 kg
Recline Positions	3
Rocking Speeds	5
Melodies/Sounds	12 melodies, 2 natural sounds
Connectivity	Bluetooth Integrated
Timer Settings	15/30 minutes
Safety Harness	5-point
Special Features	360° Rotational Movement, Automatic Movement Detection, Anti-slip Base, Anti-allergenic Cushion
Compliance	EN 12790-1:2023



Image: Diagram showing the dimensions of the Lionelo Mell Baby Bouncer: 82 cm height, 72 cm depth, 55 cm width.

8. PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video demonstrating the features and use of the Lionelo Mell Baby Bouncer, including rocking motions, music, and interaction with a baby.

9. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the official Lionelo website or contact their customer service. Keep your proof of purchase for any warranty claims.

Manufacturer: Lionelo

