

[Manuals.plus](#) /

> [Lovskoo](#) /

> Lovskoo Mini Projector M200 User Manual

Lovskoo M200

Lovskoo Mini Projector M200 User Manual

Model: M200

1. INTRODUCTION

Thank you for purchasing the Lovskoo Mini Projector M200. This portable projector is designed for home entertainment and educational purposes, offering a clear viewing experience with versatile connectivity options. This manual provides essential information for setting up, operating, and maintaining your projector.

The M200 features LED diffuse reflection imaging, supporting 1080p HD decoding and on-screen connection. It is compatible with various devices and offers a long service life.



Image 1.1: Front view of the Lovskoo Mini Projector M200, showcasing its compact design and lens.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x Lovskoo Mini Projector M200
- 1 x USB Power Cable
- 1 x Remote Control
- 1 x Instruction Manual (this document)

3. PRODUCT OVERVIEW

3.1. Dimensions

The projector features a compact design for portability.



Image 3.1: Diagram illustrating the dimensions of the Lovskoo Mini Projector M200 (approximately 4.96 x 3.35 x 1.85 inches).

3.2. Interfaces

The projector is equipped with multiple input interfaces for broad compatibility.



Image 3.2: Diagram showing various devices that can connect to the projector, including mobile phones, tablets, laptops, computers, DVDs, game consoles, U-disks, and stereo systems. The projector features HDMI, USB, AV, and memory card input ports.

4. SETUP

4.1. Power Connection

1. Connect the provided USB power cable to the projector's 5V-2A USB power input port.
2. Plug the other end of the USB power cable into a compatible 5V-2A USB power adapter (not included) or a power bank.
3. Ensure the power source provides sufficient current (5V-2A) for optimal performance.

4.2. Placement

Place the projector on a stable, flat surface. For best results, position the projector directly in front of the projection screen or wall. The optimal projection distance ranges from 39 to 79 inches, yielding a viewing size of approximately 60 inches.

SMALL IN SIZE, BUT LARGE IN SCREEN IT CAN PROJECT FROM 32 TO 100 INCHES



Image 4.1: Illustration demonstrating various projection sizes (60, 80, 100 inches) achievable with the Lovskoo Mini Projector M200 at different distances.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

- To power on, press the power button on the projector or the remote control.
- To power off, press the power button again.

5.2. Connecting Devices

The projector supports various input sources:

- **HDMI:** Connect a laptop, DVD player, game console, or set-top box using an HDMI cable.
- **USB:** Insert a USB flash drive for direct media playback.
- **AV:** Use an AV cable to connect older devices.
- **Memory Card:** Insert a TransFlash (TF) card for media playback.

- **On-Screen Connection:** Supports wired phone same-screen playback. Refer to your phone's specific instructions for wired screen mirroring.

5.3. Focus Adjustment

To achieve a clear image, adjust the focus ring located on the projector lens.



Image 5.1: Depiction of the focus adjustment process on the Lovskoo Mini Projector M200, showing a blurry image becoming sharp after adjustment.

5.4. Source Selection

After connecting a device, use the remote control or the projector's buttons to select the correct input source (HDMI, USB, AV, Memory Card) from the on-screen menu.



Image 5.2: The Lovskoo Mini Projector M200 displaying various media content, indicating its multi-source playback capability.

6. MAINTENANCE

6.1. Cleaning the Lens

Use a soft, lint-free cloth or lens cleaning paper to gently wipe the projector lens. Avoid using abrasive materials or harsh chemicals.

6.2. Cleaning the Projector Body

Wipe the exterior of the projector with a soft, dry cloth. Do not use liquid cleaners directly on the device.

6.3. Ventilation

Ensure the projector's ventilation openings are not blocked to prevent overheating. The built-in constant temperature fan is designed to maintain stable system operation and keep noise levels below 30 dB.

6.4. Storage

When not in use, store the projector in a cool, dry place, away from direct sunlight and excessive dust.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No image on screen	<ul style="list-style-type: none">• Power cable not connected.• Incorrect input source selected.• Source device not powered on or connected properly.	<ul style="list-style-type: none">• Ensure power cable is securely connected and power adapter is 5V-2A.• Select the correct input source (HDMI, USB, AV, Memory Card).• Check connections and power of the source device.
Image is blurry	<ul style="list-style-type: none">• Focus not adjusted.• Projector too close or too far from screen.	<ul style="list-style-type: none">• Adjust the focus ring on the lens.• Adjust projection distance for optimal clarity.
No sound	<ul style="list-style-type: none">• Volume too low or muted.• Audio cable not connected (for AV).• Source device audio settings.	<ul style="list-style-type: none">• Increase volume on projector or remote.• Ensure audio cables are properly connected.• Check audio output settings on the source device.
Remote control not working	<ul style="list-style-type: none">• Batteries are dead or incorrectly inserted.• Obstruction between remote and projector.	<ul style="list-style-type: none">• Replace batteries and ensure correct polarity.• Remove any obstructions and point remote directly at the projector's IR receiver.

8. SPECIFICATIONS

Feature	Detail
Model	M200
Resolution	600*480P / 320*240p (Supports 1920*1080p decoding)
Voltage	USB interface 5V2A
Projection Size	20-80 inches (Optimal viewing size: 60 inches)
Input Interface	USB / U disk / HDMI / AV / Memory Card (TF Card)
Projection Distance	39-79 inches
Service Life	30,000+ hours

Feature	Detail
Power	24W
Product Dimensions	12.6 x 8.5 x 4.7 cm (4.96 x 3.35 x 1.85 inches)
Item Weight	425g (15 ounces)
Noise Level	Less than 30 dB
Special Features	Portable, HDR high trends display technology, Built-in speaker, Multi-language support

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided at the point of purchase or visit the official Lovskoo website. Keep your purchase receipt as proof of purchase for warranty claims.

