Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ENGFYADSY YD03

ENGFYADSY Wireless Earbuds User Manual

Model: YD03

Introduction

Thank you for choosing the ENGFYADSY Wireless Earbuds. These true wireless earphones are designed for daily use, sports, and gaming, offering a seamless audio experience. They feature a digital display for battery levels, touch operation, and IPX7 waterproof functionality for enhanced durability.

What's in the Box

- Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- User Manual

Product Overview



Figure 1: The ENGFYADSY Wireless Earbuds and their charging case, showcasing the prominent digital battery display on the case.



Figure 2: Close-up of the charging case's intelligent digital display, showing individual battery percentages for the left (L) and right (R) earbuds, along with the charging case's own battery level.



Figure 3: The earbuds placed within the open charging case, highlighting Bluetooth connectivity and IPX7 waterproof rating. The case also features a digital display.

Key Features:

- **Multi-Functional Digital Display:** Provides real-time battery levels for both the charging case and individual earbuds. The mirror-like surface of the case is specially processed.
- **Ergonomic Design:** Silicone earplugs ensure a stable and comfortable fit, suitable for extended wear and during physical activities.
- **Immersive Audio:** High-quality sound unit with graphene diaphragm delivers powerful stereo effects for an immersive listening experience.
- **One-Step Pairing:** Earbuds automatically power on and connect to each other upon removal from the charging case. First-time pairing with your device is required.
- **Intelligent Touch Control:** Convenient touch-sensitive areas on the earbuds allow for various operations including call management (answer/reject/hang up), voice assistant activation, music playback (play/pause, previous/next track), and volume adjustment (swipe).
- **IPX7 Waterproof:** Designed to withstand splashes and sweat, making them suitable for sports and outdoor activities.

Setup

Charging the Earbuds and Case:

Before first use, fully charge the earbuds and the charging case. The digital display on the case will show the charging status and battery levels.




Figure 4: The charging case with its micro-USB charging port, indicating where to connect the charging cable.

1. Place the earbuds into the charging case, ensuring they are correctly seated. The earbuds will begin charging automatically.
2. Connect the provided USB charging cable to the micro-USB port on the charging case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The digital display on the case will illuminate and show the charging progress. When fully charged, the display will indicate 100%.

Pairing with Your Device:

The earbuds feature one-step pairing for convenience.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and remove both earbuds. They will automatically power on and attempt to pair with each other.
3. On your device (smartphone, tablet, laptop), go to the Bluetooth settings and search for available devices.
4. Select "YD03" (or similar name) from the list of found devices to complete the pairing process.

5. Once successfully paired, the earbuds will automatically connect to your device whenever they are removed from the case and Bluetooth is enabled on your device.

Operating Instructions

Intelligent Touch Controls:

The earbuds are equipped with touch-sensitive areas for easy control of various functions. The controls are generally mirrored on both earbuds unless specified.

Action	Function
Single Tap	Play/Pause Music; Answer/End Call
Double Tap (Left Earbud)	Previous Track
Double Tap (Right Earbud)	Next Track
Triple Tap	Activate Voice Assistant
Long Press (2 seconds)	Reject Call
Swipe Up (on earbud)	Increase Volume
Swipe Down (on earbud)	Decrease Volume

Maintenance

Cleaning:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.

Storage:

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures and direct sunlight.

Water Resistance (IPX7):

The earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. However, this rating does not apply to the charging case. Do not submerge the charging case in water. Ensure earbuds are dry before placing them back into the charging case to prevent damage.

Troubleshooting

Problem	Solution
Earbuds not pairing with device.	Ensure earbuds are fully charged. Turn off and on Bluetooth on your device. Forget "YD03" from your device's Bluetooth list and re-pair. Place earbuds back in the case, close, wait a few seconds, then remove and try pairing again.

Problem	Solution
Only one earbud has sound.	Ensure both earbuds are charged. Place both earbuds back into the charging case, close the lid, then open and remove them simultaneously to force re-connection. Check if the earbud's speaker mesh is blocked by debris.
Charging case display is off or not charging.	Ensure the charging cable is securely connected to both the case and the power source. Try a different USB cable or power adapter. Clean the charging port on the case.

Specifications

Feature	Detail
Model Name	YD03
Brand	ENGFYADSY
Connectivity Technology	Wireless (Bluetooth 5.3)
Color	Black
Item Weight	3.84 ounces (approx. 108.87 grams)
Package Dimensions	3.23 x 3.23 x 1.46 inches (approx. 8.2 x 8.2 x 3.7 cm)
Waterproof Rating	IPX7 (earbuds only)
UPC	760752913699



Figure 5: Diagram illustrating the dimensions of the charging case: 7.98cm/3.14inch in length, 5.49cm/2.16inch in width, and 3.0cm/1.18inch in height.

Customer Support

Should you have any questions about the product after delivery, please reach out to us by message. We are committed to providing a solution within 24 hours.
For further assistance, please refer to the contact information provided with your purchase or visit the official ENGFYADSY support page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNJ2JBTY

More documents and user manuals: **https://manuals.plus/**