

[Manuals.plus](#) /

› [Wentronic](#) /

› Wentronic Y01 Wireless Noise Canceling Headphones User Manual

Wentronic Y01

Wentronic Y01 Wireless Noise Canceling Headphones User Manual

Model: Y01

INTRODUCTION

Thank you for choosing the Wentronic Y01 Wireless Noise Canceling Headphones. These headphones are designed to provide a superior audio experience with advanced active noise canceling technology, high-fidelity sound, and a comfortable, foldable design. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: Wentronic Y01 Wireless Noise Canceling Headphones in Green.

WHAT'S IN THE BOX

- 1 x Wentronic Y01 Wireless Noise Canceling Headphones
- 1 x 3.5mm Audio Cable
- 1 x USB-C Charging Cable
- 1 x User Manual

In the box

Y01 ANC wireless headphones

USB-C charging cable

3.5mm audio cable

User manual




Image: The package contents, including the headphones, charging cable, audio cable, and user manual.

PRODUCT OVERVIEW

Noise Canceling & Hi-Res Sound

The Y01 headphones feature powerful 40mm dynamic drivers and advanced Active Noise Canceling (ANC) technology. This combination effectively blocks unwanted background noise while delivering crystal-clear audio with deep bass and detailed highs for an immersive listening experience.



Active Noise Cancellation

Reduce unwanted ambient sounds, creating a peaceful listening environment.

Image: Illustration of Active Noise Cancellation technology in Wentronic Y01 headphones.

Multipoint Connection & Clear Hands-Free Calls


Equipped with Bluetooth 5.3, the Y01 ensures a faster, more stable connection with lower latency and extended range. The multipoint connection feature allows simultaneous connection to two Bluetooth devices, enabling easy switching. A built-in microphone provides crystal-clear voice quality for calls and online meetings.



Image: Visual representation of Bluetooth 5.3 connectivity.

All-Day Comfort & Foldable Design


Crafted for extended wear, these over-ear headphones feature ultra-soft protein leather earcups with memory foam cushioning. The adjustable headband and 90° rotating earcups ensure a customized fit. The foldable design allows for convenient storage and portability.



Skin Friendly Soft Protein Earcups

Protect your ear for long listening sessions without feeling discomfort

Image: Detail of the skin-friendly earcups for enhanced comfort.



Foldable Design

Allows for easy storage and transport, making them ideal for travel or commuting

Image: The headphones folded for compact storage and portability.

Extended Playtime & Dual Modes

Enjoy up to 48 hours of continuous playtime on a single charge. When the battery is low, simply plug in the included 3.5mm audio cable to switch seamlessly from wireless to wired mode, ensuring uninterrupted music.



Non-stop music, less time charging

Keep the music going non-stop for 48. No need to worry about running out of Power your soundtrack lasts as long as you do.

Image: Visual indicating 48 hours of battery life.

SETUP

Charging the Headphones

1. Locate the USB-C charging port on the right earcup.
2. Connect the included USB-C charging cable to the headphones and a compatible USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator will show charging status. A full charge provides up to 48 hours of playtime.

All-Day Power

Enjoy up to 48 hours of continuous playback on a full charge



Image: The USB-C charging port and 3.5mm audio jack on the right earcup.

Bluetooth Pairing

1. Ensure the headphones are charged.
2. Press and hold the Power button on the right earcup until the LED indicator flashes blue and red, indicating pairing mode.

3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "Wentronic Y01" from the list.
5. Once connected, the LED indicator will show a solid blue light.

Wired Connection (Aux Mode)

1. Locate the 3.5mm audio jack on the right earcup.
2. Connect one end of the included 3.5mm audio cable to the headphones.
3. Connect the other end to your audio source's 3.5mm output.
4. The headphones will automatically switch to wired mode.

OPERATING INSTRUCTIONS

Button Functions

- **Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **ANC/Transparency Mode Button:** Short press to toggle between Active Noise Canceling (ANC) mode, Transparency mode, and normal mode.

Cloud-soft Leather Ear Cushions

Ergonomically designed leather ear cushions, cloud-soft and breathable for all-day comfort.





Image: The control buttons located on the right earcup for power, volume, and ANC/Transparency mode.

Wearing the Headphones

1. Adjust the headband to fit comfortably over your head.
2. Ensure the earcups fully cover your ears for optimal sound and noise canceling performance. The earcups are marked 'L' for left and 'R' for right.



Crystal-Clear Calls

Y01 headphones feature upgraded microphones, delivering crystal-clear audio for calls and ensuring a smooth, high-quality communication experience.

Image: A person wearing the Wentronic Y01 headphones, demonstrating proper fit.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.

- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** These headphones are not water-resistant. Avoid exposure to liquids.

TROUBLESHOOTING

- **No Power:** Ensure the headphones are fully charged.
- **Cannot Pair via Bluetooth:** Make sure the headphones are in pairing mode (LED flashing blue/red). Check your device's Bluetooth settings and ensure it's discoverable. Try restarting both devices.
- **Poor Sound Quality:** Check the audio source. If using Bluetooth, ensure you are within range. If wired, check the cable connection.
- **Noise Canceling Not Working:** Ensure ANC mode is activated. Check for proper fit of the earcups over your ears.
- **Microphone Issues:** Ensure the headphones are properly connected and selected as the audio input device on your system.

SPECIFICATIONS

Feature	Detail
Model Name	Y01
Brand	Wentronic
Connectivity Technology	Wireless (Bluetooth 5.3) / Wired (3.5mm Jack)
Noise Control	Active Noise Cancellation
Audio Driver Size	40 Millimeters
Battery Life	Up to 48 Hours
Material	Leather (earcups)
Special Features	Adjustable Headband, Foldable, Microphone Included, Multipoint Pairing
Compatible Devices	Cellphones, Desktops, Laptops, Tablets (iOS, Android, PC)
Control Type	Button Control
Item Weight	13.7 ounces (0.39 Kilograms)

© 2024 Wentronic. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DNJ7DZVY>

More documents and user manuals: <https://manuals.plus/>