

[manuals.plus](#) /

› [CKLMMC](#) /

› [CKLMMC Oversized Loveseat Chaise Lounge Instruction Manual](#)

CKLMMC B0DNJMBCK6

CKLMMC Oversized Loveseat Chaise Lounge Instruction Manual

Model: B0DNJMBCK6

1. INTRODUCTION

Thank you for choosing the CKLMMC 86.5" Oversized Loveseat Chaise Lounge. This versatile piece of furniture is designed to provide comfort, functionality, and style to your living space. Equipped with convenient features such as two USB ports and two cup holders, it enhances your relaxation experience. Crafted with a sturdy frame and soft corduroy upholstery, this sofa offers a modern aesthetic and comfortable seating for two, easily converting into a sleeper sofa for temporary use.



Figure 1.1: The CKLMMC Oversized Loveseat Chaise Lounge, showcasing its spacious design and integrated features.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep all packaging materials away from children to prevent choking hazards.
- Ensure all bolts and screws are securely tightened before using the sofa. Periodically check and re-tighten as necessary.
- Do not stand or jump on the sofa.
- Do not exceed the maximum weight capacity of 550 lbs (249 kg).
- Avoid placing hot items directly on the fabric or armrests.
- Use caution when converting the sofa to a sleeper position to avoid pinching fingers or other body parts.
- Keep the sofa away from open flames and direct heat sources.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Sofa Base Sections (2)
- Backrest Cushions (2)
- Seat Cushions (2)
- Throw Pillows (2)
- Legs (Black Plastic Legs + Birch Middle Legs)
- Assembly Hardware (Bolts, Washers, Allen Wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required and typically takes 10-20 minutes with the included accessories and instructions. It is recommended to have two people for easier assembly.

4.1. Preparation

1. Unpack all components and lay them out on a clean, soft surface to prevent scratching.
2. Identify all parts against the package contents list.
3. Ensure you have the included Allen wrench ready.

4.2. Step-by-Step Assembly

1. **Attach Legs:** Carefully turn each sofa base section upside down. Attach the black plastic legs and birch middle legs to the designated points on the bottom of each base section using the provided hardware. Ensure they are tightened securely.
2. **Connect Sofa Sections:** Place the two sofa base sections side-by-side. Align the connecting brackets on the inner sides of the sections and slide them together until they lock securely.
3. **Place Cushions:** Place the large seat cushions onto the sofa base. Ensure they are properly aligned and seated.
4. **Add Backrest Cushions:** Position the backrest cushions against the back of the sofa. The backrests are removable for versatility.
5. **Arrange Throw Pillows:** Place the two throw pillows as desired for added comfort and style.

SIZE: INCH




Figure 4.1: Product dimensions for assembly reference.



Figure 4.2: Front view of the assembled sofa.

5. OPERATING INSTRUCTIONS

5.1. Using the USB Charging Ports

The chaise lounge sofa is equipped with two built-in USB charging ports located on the armrests. These ports allow you to conveniently charge your electronic devices while relaxing on the sofa.

- Locate the USB ports on the side of the armrests.
- Plug your device's USB charging cable into the port.
- Ensure the sofa is connected to a power source (if applicable, though typically these are passive and draw power from the device or require an internal power bank, which is not specified here, so assuming standard USB power).

5.2. Utilizing the Cup Holders

Two convenient cup holders are integrated into the armrests to securely hold your beverages, preventing spills and keeping your drinks within easy reach.

- Place your cup or bottle into the designated cup holder.
- Ensure the beverage container fits snugly to prevent tipping.

Details



Two Cup Holders

Ensure your drinks stay securely in place while you relax, so you can enjoy your beverage without worrying about spills.



Two USB Ports

Eliminate the need for extra chargers or extension cords, reducing clutter and keeping your living space tidy.



Thick Cushions

Extra-thick 8" cushions provide you with the ultimate comfort.

Figure 5.1: Details of USB ports, cup holders, and cushion thickness.

5.3. Converting to Sleeper Sofa

This versatile chaise lounge can be configured for both seating and temporary sleeping arrangements.

- To convert to a sleeper position, ensure the backrest cushions are removed or adjusted to allow for a flat surface.
- The design allows for an extended lounging area, suitable for temporary sleeping.

Versatile Sofa




Figure 5.2: Sofa configured for day use and as a sleeper for night use.

6. MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your CKLMMC Oversized Loveseat Chaise Lounge.

- **Cleaning Corduroy Fabric:** For general cleaning, vacuum regularly with an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub. For stubborn stains, use a mild fabric cleaner specifically designed for corduroy, testing on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading of the fabric. Position your sofa away from direct sunlight or use curtains/blinds.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or strong detergents, as these can damage the fabric and frame.
- **Legs and Frame:** Periodically check and tighten all screws and bolts to ensure stability. Wipe legs with a damp cloth if needed.

7. TROUBLESHOOTING

If you encounter any issues with your sofa, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Sofa feels wobbly or unstable.	Loose legs or connecting hardware.	Check and tighten all leg screws and connecting brackets between sofa sections.
USB ports are not charging devices.	No power supply to the sofa or faulty cable/device.	Ensure the sofa's power cord (if any) is plugged in. Test with a different USB cable and device.
Cushions feel too soft or too firm.	Normal wear or personal preference.	Cushions are designed with high-density foam and pocket springs for medium-firm support. Allow time for break-in.
Difficulty connecting sofa sections.	Misalignment of brackets.	Ensure brackets are perfectly aligned before pushing sections together. Lift slightly if needed.

8. SPECIFICATIONS

Feature	Detail
Product Type	Sofa Bed / Chaise Lounge
Overall Dimensions (D x W x H)	86.5" x 62" x 34.5"
Seat Height (Floor to Seat)	17.5"
Seat Depth (Front to Back)	53"
Backrest Height (Seat to Top)	19"
Seat Cushion Thickness	8"
Pillow Size	17" x 17"
Product Weight	127.87 lbs
Weight Capacity	550 lbs
Upholstery Material	Corduroy Fabric
Frame Material	Pine + Plywood + Iron Frame
Seat Construction	Foam + Pocket Springs
Leg Material	Black Plastic Legs + Birch Middle Legs
Foam Density	1.75 lbs./cu.ft
Assembly Required	Yes (Approx. 10-20 minutes)
Special Features	Two USB Ports, Two Cup Holders, Two Throw Pillows, Reversible Backrest Cushion

Feature	Detail
Room Type	Living Room, Bedroom, Office

9. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please do not hesitate to contact our customer service team. We are committed to providing support and ensuring your satisfaction with your CKLMMC product.

Please refer to your purchase documentation for specific contact information or visit the CKLMMC brand page on Amazon.