

## Zevemomo 1119GrillFP4SB

# Zevemomo 4 Burner Gas Grill with Side Burner User Manual

Model: 1119GrillFP4SB

## INTRODUCTION

---

This manual provides detailed instructions for the safe assembly, operation, maintenance, and troubleshooting of your Zevemomo 4 Burner Gas Grill with Side Burner. Please read this manual thoroughly before using the grill and retain it for future reference.

The Zevemomo 4 Burner Gas Grill is designed for outdoor cooking, featuring a dual-sided frying plate, four main stainless steel burners, and one side burner, providing a total heat output of 47,000 BTU/hr. Its durable construction includes a steel firebox with high-temperature resistant powder coating, ensuring longevity. The grill offers ample cooking space with a 331 sq.in grilling area and a 108 sq.in warming rack.

## SAFETY INFORMATION

---

### WARNING:

- For outdoor use only. Do not operate indoors.
- Read all instructions before assembly and use of this grill.
- Keep children and pets away from the grill at all times.
- Ensure proper ventilation.
- Do not store flammable materials near the grill.
- Always check for gas leaks before each use.
- Use heat-resistant gloves when handling hot surfaces.

## PRODUCT COMPONENTS

---

Familiarize yourself with the main components of your gas grill:

- **Main Burners (4):** Stainless steel burners for primary grilling.
- **Side Burner (1):** Ideal for cooking with pots and pans.
- **Dual-sided Frying Plate:** Versatile cooking surface for various foods.
- **Warming Rack:** Keeps cooked food warm.
- **Built-in Thermometer:** Monitors internal grill temperature (100°F-800°F).
- **Control Knobs:** Push-and-turn ignition and flame control.
- **Side Tables:** Provide convenient workspace.
- **Storage Space:** Large bottom cabinet for grill tools and propane tank.
- **Pull-out Oil Drip Tray:** Stainless steel for easy cleaning.
- **Casters (Wheels):** For easy mobility, including two lockable casters.
- **Bottle Opener:** Integrated for convenience.
- **Side Hooks:** For hanging grilling tools.

# All Kinds of Food Can be Cooked

## Cast Iron Grill Mesh & Grill Plate



Figure 1: Detailed view of grill components.

## SETUP AND ASSEMBLY

Assembly is required for this grill. Please follow the included assembly instructions carefully. Ensure all parts are present before beginning assembly.

- Unpack all components and verify against the parts list.
- Assemble the main frame and attach the casters, ensuring the two lockable casters are positioned correctly for stability.
- Install the main burner assembly and side burner.
- Attach the side tables and lid.
- Connect the gas lines securely. Ensure all connections are tight to prevent leaks.
- Place the dual-sided frying plate and warming rack onto the grill.
- Position the propane tank in the designated storage area.



Figure 2: Product dimensions for assembly planning.

**Important:**

Before first use, perform a leak test on all gas connections using a soapy water solution. Bubbles indicate a leak. Do not use the grill if a leak is detected.

## OPERATING INSTRUCTIONS

---

### Igniting the Main Burners:

1. Ensure the grill lid is open.
2. Turn on the gas supply at the propane tank.
3. Push in and turn one main burner control knob to the HIGH position.
4. Listen for the igniter click and observe the burner flame. If it doesn't ignite within 5 seconds, turn the knob off, wait 5 minutes, and repeat the process.
5. Once ignited, you can adjust the flame intensity by turning the knob between HIGH and LOW.
6. Repeat for additional main burners as needed.

### Igniting the Side Burner:

1. Ensure the side burner lid is open.
2. Push in and turn the side burner control knob to the HIGH position.
3. Observe the flame. If it doesn't ignite, turn the knob off, wait 5 minutes, and repeat.



Figure 3: Burner operation and heat output.

### Using the Dual-sided Frying Plate:

The dual-sided frying plate allows for versatile cooking. One side is typically ribbed for grilling, and the other is flat for frying. Simply place it on the grill grates over the desired burners. Ensure it is properly heated before placing food on it.

# BBQ Grill Detailed Display



Figure 4: Versatile cooking with the dual-sided frying plate.

## Shutting Down the Grill:

1. Turn all burner control knobs to the OFF position.
2. Turn off the gas supply at the propane tank.

## MAINTENANCE AND CARE

Regular maintenance ensures the longevity and safe operation of your grill.

- **Cleaning Grill Grates:** After each use, once the grill has cooled, brush off any food residue from the grates. For stubborn residue, use warm soapy water.
- **Cleaning the Drip Tray:** The pull-out oil drip tray should be emptied and cleaned regularly to prevent grease fires.
- **Exterior Cleaning:** Wipe down exterior surfaces with a damp cloth and mild detergent. Avoid abrasive

cleaners.

- **Burner Maintenance:** Periodically check burner ports for blockages (e.g., spider webs, food debris). Clean with a wire brush if necessary.
- **Storage:** When not in use for extended periods, store the grill in a dry, protected area. Consider using a grill cover to protect it from the elements.



Figure 5: Easy cleaning and storage features.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner fails to ignite	No gas flow; clogged burner port; faulty igniter.	Check propane tank connection and gas level. Clean burner ports. Contact customer support if igniter is faulty.

Problem	Possible Cause	Solution
Low flame or uneven heating	Low gas pressure; clogged burner ports; regulator issue.	Ensure propane tank valve is fully open. Clean burner ports. Check regulator for damage.
Grease fire	Accumulation of grease in drip tray or firebox.	Turn off all burners and gas supply. Do NOT use water. Allow fire to burn out. Clean grill thoroughly before next use.
Gas odor	Gas leak.	Immediately turn off gas supply. Perform a leak test. Do not use grill until leak is resolved.

## SPECIFICATIONS

---

- **Model:** 1119GrillFP4SB
- **Color:** Black + Silver
- **Grilling Area:** 331 sq.in
- **Warming Rack Area:** 108 sq.in
- **Total Burning Capacity:** 47,000 BTU/hr (4 Main Burners + 1 Side Burner)
- **Material:** Cast Iron (grates) + Stainless Steel (burners, handle, frame) + Steel (firebox)
- **Dimensions (L x W x H):** 48.1" x 19.1" x 45.6"
- **Fuel Type:** Gas (Propane)
- **Thermometer Range:** 100°F-800°F
- **Item Weight:** 50 pounds
- **UPC:** 810152797679

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Zevemomo website. Keep your proof of purchase for warranty claims.

For technical assistance or replacement parts, please contact Zevemomo customer service. Contact details can typically be found on the product packaging or the brand's official website.