Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CIRCLE JOY KYMQ-64A-BS

Instruction Manual for CIRCLE JOY Electric Salt and Pepper Grinder Set

Model: KYMQ-64A-BS
Brand: CIRCLE JOY

1. Product Overview

The CIRCLE JOY Rechargeable Electric Salt and Pepper Grinder Set offers an effortless way to season your meals. This automatic mill grinder set features a sleek design, adjustable coarseness settings, and a built-in white LED light for precise seasoning. Designed for convenience, it includes a charging base and is easily refillable.



Image: The CIRCLE JOY Electric Salt and Pepper Grinder Set, featuring two black grinders on a clear charging base, with a USB-C cable shown to the side.

2. What's in the Box

Please check the package contents to ensure all items are present:

- 2 x Electric Salt and Pepper Grinders
- 1 x Charging Base
- 1 x USB-C Charging Cable (Adapter not included)
- 1 x Cleaning Brush
- 1 x User Manual (this document)



Image: The individual components of the grinder set, including the two grinders, the charging base, USB-C cable, and cleaning brush.

3. Setup

3.1 Charging the Grinders

Before first use, fully charge the grinders. A 5-minute quick charge provides power for daily use, while a full charge

delivers over 20 minutes of continuous grinding.

1. Place the grinders into the charging base.
2. Connect the USB-C charging cable to the charging port on the base and plug the other end into a compatible USB power adapter (not included).
3. A white reminder light will illuminate on the grinder during charging.



Image: A close-up view of the Type-C charging port on the grinder, with a glowing white light indicating charging status.

3.2 Filling the Grinders

The grinders feature a top-loading design for easy and mess-free refilling.

1. Gently twist and pull the top section of the grinder to open the spice chamber.
2. Pour your desired salt crystals or peppercorns directly into the 110ml capacity chamber.
3. Align the top section and twist it back into place until it clicks securely.



Image: An illustration demonstrating the top-filling design of the grinder, showing spices being poured into the open

chamber.

4. Operating Instructions

4.1 Grinding Spices

The grinders operate with a simple one-touch mechanism.

1. Hold the grinder over your food or dish.
2. Press and hold the button on the top of the grinder to activate the grinding mechanism. A white LED light will illuminate the area below, allowing you to monitor the amount of spice being dispensed.
3. Release the button to stop grinding.



Image: A hand holding the electric grinder over a piece of meat, demonstrating its single-handed operation and the illuminated LED light during grinding.

4.2 Adjusting Coarseness

Customize the grind size from fine powder to coarse grains using the adjustable ceramic grinding core.

1. Locate the adjustment dial at the bottom of the grinder.
2. Rotate the dial clockwise for a finer grind.

3. Rotate the dial counter-clockwise for a coarser grind.
4. Test the grind size and adjust as needed for your culinary preferences.



Image: A diagram illustrating the adjustable coarseness mechanism at the bottom of the grinder, showing rotation for fine to coarse settings, with examples of different grind sizes.

5. Maintenance and Cleaning

To ensure optimal performance and longevity of your grinders, follow these cleaning guidelines:

- Always ensure the grinders are turned off and disconnected from the charging base before cleaning.
- Use the included cleaning brush to remove any residual spice particles from the grinding mechanism and the interior of the chamber.
- Wipe the exterior of the grinders and the charging base with a soft, damp cloth. Do not immerse the grinders or base in water.
- Do not use abrasive cleaners or harsh chemicals, as these may damage the food-grade, BPA-free materials.
- Ensure all parts are completely dry before reassembling or storing.

6. Troubleshooting

If you encounter any issues with your CIRCLE JOY Electric Grinder Set, please refer to the following common solutions:

Problem	Possible Cause	Solution
Grinder not operating.	Low battery; spice chamber empty; mechanism jammed.	Charge the grinder; refill spices; clear any blockages with the cleaning brush.
LED light not illuminating.	Low battery; internal fault.	Charge the grinder. If the issue persists, contact customer support.
Grinding is inconsistent or too slow.	Low battery; incorrect coarseness setting; spice type.	Charge the grinder; adjust coarseness setting; ensure you are using appropriate spices (salt crystals, peppercorns).
Grinder not charging.	Cable or adapter fault; improper connection.	Ensure the USB-C cable is securely connected to both the base and the power adapter. Try a different USB-C cable or adapter.

7. Specifications

Feature	Detail
Model Number	KYMQ-64A-BS
Capacity	110 Milliliters (3.38 oz)
Material	Acrylic, Ceramic, Plastic
Operation Mode	Automatic
Power Source	Rechargeable Lithium Ion Battery (included)
Charging Type	USB-C
Light	White LED Light
Item Weight	1.45 pounds
Package Dimensions	7.68 x 4.69 x 3.58 inches

8. Warranty and Support

For detailed warranty information and customer support, please refer to the warranty card included in your product

packaging or visit the official CIRCLE JOY website. You may also contact their customer service team directly for assistance with product inquiries, troubleshooting, or replacement parts.

Contact Information:

Web: Visit the CIRCLE JOY Store on Amazon

Email: Refer to product packaging or official website for specific email address.

Phone: Refer to product packaging or official website for specific phone number.

© 2025 CIRCLE JOY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNKCGYLD

More documents and user manuals: **https://manuals.plus/**