

[Manuals.plus](#) /

> [Orestree](#) /

> Orestree 240W Laptop Charger User Manual for Dell Alienware m15 R7 (Model AD195123)

## Orestree AD195123

# Orestree 240W Laptop Charger User Manual

For Dell Alienware m15 R7 P109F005/P109F006 Laptops

## 1. INTRODUCTION

---

This manual provides essential instructions for the safe and effective use of your Orestree 240W Laptop Charger. Please read this manual thoroughly before using the product.

### Package Contents:

- 1 x Orestree 240W Power Adapter
- 1 x AC Power Cord



**Image 1.1:** The Orestree 240W laptop charger, featuring the main power adapter unit with its integrated DC output cable and a separate AC input power cord. The DC cable is coiled around the adapter, and the AC cord is neatly bundled.

## 2. SETUP

---

Follow these steps to properly connect your Orestree 240W Laptop Charger to your device.

1. **Connect the AC Power Cord:** Insert the female end of the AC power cord firmly into the AC input port on the Orestree 240W power adapter.
2. **Connect to Power Outlet:** Plug the male end of the AC power cord into a standard wall power outlet (100-240V AC, 50-60Hz).
3. **Connect to Laptop:** Insert the DC output connector (7.4mm x 5.0mm) from the power adapter into the charging port of your Dell Alienware m15 R7 laptop. Ensure a secure connection.

*Note:* Ensure the power outlet is easily accessible to allow for quick disconnection if needed.

## 3. OPERATING INSTRUCTIONS

---

Once connected, the charger will automatically begin supplying power to your laptop and charging its battery.

## Safety Guidelines:

- Use only with compatible Dell Alienware m15 R7 P109F005/P109F006 laptops.
- Do not expose the charger to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the charger to strong impacts.
- Do not attempt to disassemble or modify the charger.
- Ensure adequate ventilation around the charger during use to prevent overheating.
- Unplug the charger from the wall outlet when not in use for extended periods.

## 4. MAINTENANCE

---

Proper care will extend the lifespan of your charger.

- **Cleaning:** Disconnect the charger from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables to prevent damage.
- **Cable Inspection:** Regularly inspect the power cords and adapter for any signs of damage, such as fraying or exposed wires. Discontinue use if damage is found.

## 5. TROUBLESHOOTING

---

If you encounter issues with your charger, refer to the following common problems and solutions.

- **Charger Not Supplying Power:**
  - Ensure all cables are securely connected to the power outlet, adapter, and laptop.
  - Verify that the wall outlet is functional by testing it with another device.
  - Check for any visible damage to the adapter or cables.
- **Laptop Not Charging:**
  - Confirm that the charger's specifications (voltage, amperage) match your laptop's requirements.
  - Ensure the laptop's charging port is clean and free of debris.
  - If the laptop battery is completely depleted, it may take a few minutes for the charging indicator to appear.
- **Charger Overheating:**
  - Ensure the charger is placed in a well-ventilated area and not covered by objects.
  - If overheating persists, discontinue use and contact customer support.

*If problems persist after following these steps, please contact Orestree customer support.*

## 6. SPECIFICATIONS

---

<b>Model Number</b>	AD195123
<b>Input Voltage</b>	100-240V AC, 50-60Hz
<b>Output Voltage/Current</b>	19.5V DC, 12.3A

<b>Wattage</b>	240W (compatible with 180W, 130W)
<b>Connector Size</b>	7.4mm x 5.0mm
<b>Compatible Devices</b>	Dell Alienware m15 R7 P109F005/P109F006 Laptops
<b>Special Features</b>	Automatic Off, Fast Charging
<b>Color</b>	Black
<b>Item Weight</b>	8 ounces

## 7. WARRANTY AND SUPPORT

---

Your Orestree 240W Laptop Charger comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external factors. For warranty claims or technical support, please contact Orestree customer service through your retailer or the official Orestree website. Please have your purchase receipt and product model number (AD195123) available when contacting support.