

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [akimart](#) /
- › [Akimart 15.6 inch Wall Planner Digital Calendar & Chore Chart User Manual](#)

akimart 15.6 inch Wall Planner Digital Calendar & Chore Chart

Akimart 15.6 inch Wall Planner Digital Calendar & Chore Chart User Manual

Model: 15.6 inch Wall Planner Digital Calendar & Chore Chart

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Akimart 15.6 inch Wall Planner Digital Calendar & Chore Chart. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your experience with its features. This interactive display is designed to help organize family schedules, manage chores, plan meals, and serve as a digital picture frame.

SAFETY INFORMATION

- Ensure the device is placed on a stable surface or securely mounted to a wall to prevent accidental falls.
- Keep the device away from water, moisture, and extreme temperatures.
- Use only the provided power adapter.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.
- Keep out of reach of small children to prevent damage or injury.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Akimart 15.6 inch Digital Calendar Display
- Power Adapter
- Desk Stand (pre-attached or separate)
- Wall Mounting Hardware (if applicable)
- User Manual (this document)

PRODUCT OVERVIEW

The Akimart 15.6 inch Digital Calendar is an interactive touchscreen display designed for family organization and digital photo display.




Figure 1: Front view of the Akimart 15.6 inch Digital Calendar displaying a weekly schedule with color-coded events and tasks.

15.6" Full HD Touch Screen





Figure 2: The Akimart 15.6 inch Digital Calendar with its approximate dimensions of 15.8 inches width and 9.9 inches height, highlighting its Full HD touchscreen.

SETUP

1. Physical Installation

- **Desk Stand:** If using the desk stand, ensure it is securely attached to the back of the device. Place the device on a flat, stable surface.
- **Wall Mounting:** For wall mounting, use the provided hardware and follow standard wall mounting procedures. The device supports both landscape and portrait orientations.



Auto-Rotating And Wall-Mounted




Figure 3: The digital calendar can be auto-rotated and wall-mounted, allowing for flexible placement in either landscape or portrait orientation.

2. Power Connection

Connect the power adapter to the device's power port and then plug it into a standard electrical outlet. The device will power on automatically.

3. Wi-Fi Connection

Upon first startup, the device will guide you through the initial setup process, including connecting to your Wi-Fi network. Select your network and enter the password.

4. Software Update

It is recommended to update the software to the latest version for optimal performance and access to all features. Navigate to **Settings > About > Version > Check for updates**.

Free eCalendar App

Everyone's up to date all of the time, no matter where they are.




Figure 4: The device offers easy setup, allowing users to mount it, plug it in, connect to Wi-Fi, and sync calendars for a unified family schedule.

OPERATING INSTRUCTIONS

1. Calendar Features

- **Calendar Syncing:** The device can synchronize with various online calendars including Google Calendar, iCloud Calendar, Outlook Calendar, Cozi, and Yahoo. Access the settings to link your accounts.
- **Adding Events and Chores:** Events and chores can be added directly on the device's touchscreen or through the free mobile application.
- **Family Member Assignment:** Assign unique colors to each family member to easily identify their respective events and tasks on the calendar display.

Seamlessly auto-syncs events with:



Apple



Cozi



Google



Yahoo



Outlook



Figure 5: The Akimart Digital Calendar seamlessly auto-syncs events with popular services like Apple, Cozi, Google, Yahoo, and Outlook.

All-in-One Organization

Calendar Syncing ✓

Custom lists ✓

Routines ✓

Chore Chart ✓

Meal Planning ✓

Free App Access ✓




Figure 6: The device offers all-in-one organization features including calendar syncing, custom lists, routines, chore charts, meal planning, and free app access.

Chore Chart

Transform routine tasks into rewarding accomplishments.



Figure 7: The free eCalendar app allows everyone to stay updated on schedules and tasks, regardless of their location, with real-time synchronization.

2. Chore Chart

Create and manage household chores for family members. The system allows for assigning chores and tracking completion. A reward system can be integrated to motivate task completion.

Digital Picture Frame



Photos



Video




Figure 8: The chore chart feature helps transform routine tasks into rewarding accomplishments, visible on the digital calendar.

3. Meal Planning & Recipes

Utilize the device to create meal plans, access various recipes, and view cooking tutorials directly on the screen.

4. Digital Picture Frame

The device functions as a digital picture frame. Use the companion mobile application to send photos and videos to the display, sharing cherished moments with family and friends from any location.

Lighten Your Mental Load



Easy Setup

Simply mount it on the wall or install the stand, then plug it in and connect to WiFi.



On The Same Page

Sync and display everyone's calendars and tasks in one place..



Peace Of Mind

Use the touchscreen or app to keep the whole family up to date, all the time.




Figure 9: The built-in digital picture frame allows sharing photos and videos via a free app, displaying precious moments on the screen.

5. Smart Home Integration

Access compatible smart home applications directly from the touchscreen to control other smart devices in your home.

6. Settings and Customization

- **Auto-Brightness:** The display features an auto-brightness function that adjusts screen illumination based on ambient light conditions.
- **Sleep Mode:** Configure sleep and wake times to conserve energy and prevent disturbance during resting hours.
- **Orientation Options:** Switch between landscape and portrait display modes as desired.
- **Weather Display:** The device can show current weather conditions and forecasts for upcoming events.

MAINTENANCE

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the touchscreen. For stubborn smudges, slightly

dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals.

- **Software Updates:** Regularly check for and install software updates to ensure optimal performance, security, and access to new features.
- **Power Cycle:** If the device becomes unresponsive, disconnect the power adapter, wait 10 seconds, and then reconnect it to perform a power cycle.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on	Power adapter not connected or faulty outlet.	Ensure power adapter is securely connected and the outlet is functional. Try a different outlet.
Cannot connect to Wi-Fi	Incorrect password, out of range, or network issue.	Verify Wi-Fi password. Move device closer to router. Restart router.
Calendar not syncing	Incorrect account credentials or network connectivity issues.	Check linked calendar account settings. Ensure stable Wi-Fi connection. Manually refresh sync.
Touchscreen unresponsive	Temporary software glitch.	Perform a power cycle (disconnect and reconnect power).
Photos/videos not appearing	App not connected, incorrect frame ID, or network issue.	Ensure the mobile app is correctly linked to the device. Check Wi-Fi connection on both devices.

SPECIFICATIONS

Feature	Detail
Product Dimensions	9.99 x 15.8 x 0.99 inches
Item Weight	3.74 pounds
Screen Size	15.6 inches (39.6 Centimeters)
Resolution	1080p (Full HD 1920x1080 IPS)
Color	White
Compatible Devices	Smartphone (for app control)
Connectivity	Wi-Fi

WARRANTY & SUPPORT

This Akimart product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official Akimart website. For technical support, troubleshooting assistance, or any inquiries regarding your device, please contact Akimart customer service through their official channels. Contact information can typically be found on the product packaging or the Akimart brand store on Amazon.

Online Support: [Visit the Akimart Store on Amazon](#)

