

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CACHOO](#) /

› [CACHOO Small 1.25Qt Electric Hot Pot Instruction Manual](#)

## CACHOO KE3098

# CACHOO Small 1.25Qt Electric Hot Pot

Model: KE3098 - User Instruction Manual

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your CACHOO Electric Hot Pot. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage of your power outlet matches the rating label on the appliance. Do not immerse the power base, cord, or plug in water or other liquids.
- **Intended Use:** This appliance is designed for boiling, stewing, and blanching. It is **not suitable for frying or sautéing**. Using it for unintended purposes may cause damage or hazards.
- **Placement:** Always place the hot pot on a stable, flat, heat-resistant surface, away from edges and out of reach of children.
- **Handling:** Use the cool-touch handle when moving the hot pot. The pot and its contents will be hot during and after operation.
- **Water Level:** Do not fill above the maximum fill line or below the minimum fill line to prevent boil-dry or overflow.
- **Supervision:** Do not leave the appliance unattended while in use. Close supervision is necessary when any appliance is used by or near children.
- **Maintenance:** Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.

## 2. PRODUCT OVERVIEW

The CACHOO Small 1.25Qt Electric Hot Pot (Model KE3098) is a versatile and compact cooking appliance designed for convenience and efficiency. It features a durable stainless steel interior and precise temperature control.



The CACHOO Small 1.25Qt Electric Hot Pot, showcasing its turquoise exterior, stainless steel pot, and glass lid. The control knob is visible at the front.

# Food-Grade Stainless Steel

Durable, healthy, and ideal for every meal



Odor-Free



No Coating



Easy Cleanup



A close-up view of the hot pot's interior, highlighting its food-grade SUS 304 stainless steel construction, which is odor-free, coating-free, and easy to clean.

## Key Features:

- **Food-Grade Stainless Steel:** Durable, non-coated, and easy to clean interior.
- **1.25-Quart Capacity:** Ideal for single servings or small meals.
- **Precise Temperature Control:** Adjustable knob for various cooking needs, from simmering to boiling.
- **Keep Warm Function:** Maintains food temperature for extended periods.
- **Rapid Heating:** 900W power for quick heat-up.
- **Detachable Base:** Allows the pot to be used as a serving bowl, enhancing portability.
- **Safety Features:** Equipped with Boil-Dry Protection and Overheat Protection.
- **Cool-Touch Handle:** Ensures safe handling during and after cooking.
- **Transparent Glass Lid:** Allows monitoring of cooking progress.

## 3. SETUP AND FIRST USE

### Unpacking:

1. Carefully remove all packaging materials from the hot pot and its accessories.
2. Inspect the appliance for any signs of damage. Do not use if damaged.

### Initial Cleaning:

1. Wash the stainless steel pot and glass lid with warm, soapy water. Rinse thoroughly and dry completely.
2. Wipe the exterior of the power base with a damp cloth. Do not immerse the power base in water.

### Placement:

1. Place the power base on a dry, stable, and heat-resistant surface.
2. Ensure there is adequate ventilation around the appliance.
3. Keep the appliance away from flammable materials and heat sources.

## Convenience in Every Detail

Removable base and heat-resistant handles  
for effortless handling and safe mobility.



The hot pot features a detachable base for easy lifting and serving, highlighting its convenience.

# Safety Assured

Thermostatic technology ensures reliable cooking every time



Boil-Dry Protection



Overheat Protection



An illustration demonstrating the boil-dry and overheat protection mechanisms, ensuring safe operation.

## 4. OPERATING INSTRUCTIONS

### Basic Operation:

1. Place the hot pot securely onto its power base.
2. Add desired ingredients and liquid to the pot. Ensure the liquid level is between the MIN and MAX marks.
3. Place the glass lid on the pot.
4. Plug the power cord into a suitable electrical outlet.
5. Turn the control knob to the desired temperature setting. The indicator light will illuminate.
  - **OFF:** Appliance is off.
  - **KEEP WARM:** Maintains a low temperature to keep food warm.
  - **MIN to MAX:** Adjusts heating power from low to high for simmering, boiling, etc.
6. Once cooking is complete, turn the knob to OFF and unplug the appliance.

7. Carefully remove the pot from the base using the cool-touch handle to serve.

## Precise Cooking

Adjust heat with ease for perfect cooking results.



**900W**  
Fast Heat-up



**Keep Warm**  
for Hours



The control knob allows for precise temperature adjustment and activation of the keep-warm function.

# Versatile Cooking in One Pot

Perfect for boiling, stewing, blanching



Beef Stew



Corn Chowder



Tomato Soup



Oatmeal



Instant Noodles



Hot Pot



Examples of versatile cooking options, such as beef stew, corn chowder, tomato soup, oatmeal, instant noodles, and hot pot.

## Tips for Best Results:

- For even cooking, stir ingredients periodically, especially when cooking thicker foods.
- Adjust the heat setting as needed. High heat is for rapid boiling, while lower settings are for simmering or keeping warm.
- The 900W power ensures quick heating, so monitor your food closely to prevent overcooking.

## 5. CLEANING AND MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your electric hot pot.

### Cleaning:

1. Always unplug the hot pot from the power outlet and allow it to cool completely before cleaning.
2. Remove the pot from the power base.

3. Wash the stainless steel pot and glass lid with warm, soapy water using a soft sponge or cloth. For stubborn food residue, you may use a non-abrasive scrubber.
4. Rinse the pot and lid thoroughly under running water and dry completely.
5. Wipe the exterior of the power base with a damp cloth. Do not use abrasive cleaners or scouring pads on the exterior.
6. **IMPORTANT: Never immerse the power base, cord, or plug in water or any other liquid.**

### Storage:

- Ensure the appliance is clean and completely dry before storing.
- Store the hot pot in a cool, dry place, away from direct sunlight and moisture.
- Do not wrap the power cord tightly around the appliance, as this can damage the cord over time.

## 6. TROUBLESHOOTING

If you encounter any issues with your CACHOO Electric Hot Pot, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hot pot does not heat up.	Not plugged in; power outlet malfunction; control knob set to OFF; boil-dry protection activated.	Ensure the appliance is securely plugged in. Check if the power outlet is working. Turn the control knob to a heating setting (MIN-MAX). Add more liquid if the boil-dry protection has activated.
Food burns or sticks to the bottom.	Heat setting too high; insufficient liquid; lack of stirring.	Reduce the heat setting. Ensure adequate liquid for the type of food being cooked. Stir food frequently, especially thicker ingredients.
Appliance suddenly stops heating.	Boil-dry protection or overheat protection activated.	Unplug the appliance and allow it to cool down. Check liquid levels. If the issue persists after cooling and adding liquid, contact customer support.
Indicator light is off but pot is heating.	Indicator light malfunction.	The appliance may still be functional, but for safety, it is recommended to contact customer support for inspection.

If the problem persists after trying these solutions, please contact CACHOO customer support.

## 7. SPECIFICATIONS

- **Model:** KE3098
- **Capacity:** 1.25 Quarts (approximately 1.2 liters)

- **Material:** Polypropylene (exterior), Stainless Steel (interior)
- **Color:** Turquoise
- **Product Dimensions:** 6.29"D x 6.29"W x 5.9"H
- **Item Weight:** 2.05 pounds
- **Power:** 900W
- **Features:** Temperature Control, Keep Warm Function, Detachable Base, Boil-Dry Protection, Overheat Protection

## 8. WARRANTY AND SUPPORT

CACHOO is committed to providing high-quality products. For specific warranty information, please refer to the warranty card included with your product packaging or visit the official CACHOO website.

If you have any questions, require technical assistance, or need to report a problem with your appliance, please contact CACHOO customer support:

- **Website:** [www.cachoo.com](http://www.cachoo.com) (Example, please refer to actual manufacturer website)
- **Email:** [support@cachoo.com](mailto:support@cachoo.com) (Example, please refer to actual manufacturer contact)
- **Phone:** 1-800-XXX-XXXX (Example, please refer to actual manufacturer contact)

Please have your model number (KE3098) and purchase date ready when contacting support.