

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Nillkin](#) /

› Nillkin CamShield Pro Case for Samsung Galaxy S25 Ultra Instruction Manual

## Nillkin CamShield Pro Series

# Nillkin CamShield Pro Case for Samsung Galaxy S25 Ultra Instruction Manual

Model: CamShield Pro Series

## 1. PRODUCT OVERVIEW

---

The Nillkin CamShield Pro Case is designed specifically for the Samsung Galaxy S25 Ultra (6.86 inch, 5G model). It provides robust protection while maintaining a slim profile and enhancing usability. This case is not compatible with other phone models such as the S25 or S25+.

### Key Features:

- **Slide Camera Cover:** Protects the camera lenses from scratches and maintains privacy.
- **Slim and Comfortable Design:** Features a lightweight profile with a premium matte finish and non-slip bars on both sides for a secure grip.
- **Wireless Charging Friendly:** Designed to support wireless charging without needing to remove the case.
- **Enhanced Protection:** Made from environmentally friendly TPU and PC material, offering anti-fingerprint properties, upgraded impact-resistant bumpers, and corner protection.
- **Precise Cutouts:** Ensures easy access to all ports, buttons, and the S Pen.



Figure 1: Front and back view of the Nillkin CamShield Pro Case.




Figure 2: Compatibility information, confirming the case is exclusively for the Samsung Galaxy S25 Ultra (6.86 inch).

## 2. INSTALLATION INSTRUCTIONS

---

- 1. Prepare Your Device:** Ensure your Samsung Galaxy S25 Ultra is clean and free of dust or debris. This prevents scratches and ensures a snug fit.
- 2. Align the Case:** Gently align the phone with the case, starting with the top or bottom edge. Ensure the camera module aligns with the case's camera cutout.
- 3. Snap into Place:** Apply gentle, even pressure to snap the phone fully into the case. Verify that all edges are securely seated and buttons align correctly with the case's button covers.
- 4. Check Fit:** Confirm that the case fits snugly around your device and that all ports (charging, S Pen) are accessible.

### 3. OPERATING THE SLIDE CAMERA COVER

---

The Nillkin CamShield Pro features a unique slide cover to protect your phone's camera lenses and enhance privacy.

- **To Open:** Gently slide the camera cover horizontally across the camera module until it clicks into the open position. This exposes the camera lenses for use.
- **To Close:** Slide the camera cover back over the camera module until it clicks into the closed position. This protects the lenses from scratches and dust when not in use.

The cover is designed to provide a secure fit, preventing accidental opening or closing.




Figure 3: Illustration of the slide camera cover mechanism for lens protection.

### 4. MAINTENANCE AND CARE

---

To ensure the longevity and appearance of your Nillkin CamShield Pro case, follow these simple care instructions:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth to remove dust, fingerprints, and smudges. For tougher stains, a mild soap solution can be used, followed by wiping with a clean, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the case material and finish.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.

### 5. TROUBLESHOOTING

---

- **Camera Slide Cover is Stiff:** If the camera slide cover feels stiff or difficult to move, ensure there is no debris trapped in the sliding mechanism. Gently clean the area. Over time, with regular use, the mechanism may become smoother.
- **Wireless Charging Issues:** While the case is designed to be wireless charging friendly, ensure your phone is correctly centered on the wireless charger. If issues persist, try removing the case to confirm it is not interfering with your specific charger.
- **Screen Protector Compatibility:** Some screen protectors, particularly those with thicker edges or

full-coverage designs, may interfere with the case's fit. Ensure your screen protector is compatible with phone cases to avoid lifting or bubbling.

## 6. SPECIFICATIONS

---

Feature	Detail
Product Dimensions	5.91 x 3.15 x 0.67 inches
Item Weight	3.84 ounces
Item Model Number	Nillkin CamShield Pro Series
Material	PC + Soft Silicon
Compatible Phone Models	Samsung Galaxy S25 Ultra / Samsung Galaxy S25 Ultra 5G
Special Features	Built-in Camera Protector, Slim Fit, Lightweight, Anti-Slip, Anti-Yellowing, Dustproof, Flexible, Heavy Duty Protection, Anti-Fingerprint, Scratch Resistant, Shock-Absorbent, Wireless Charging Compatible

## 7. WARRANTY AND SUPPORT

---

Specific warranty information for this product is not provided in the available documentation. For any product-related inquiries, technical support, or warranty claims, please contact Nillkin customer service directly or visit the official Nillkin store.

You can find more information and contact details on the official Nillkin website or through their official store on Amazon: [Nillkin Official Store](#)