



Manuals.plus /

- › SOKA /
- › SOKA 2-Handle Bathroom Sink Faucet (Model SK18001AJ) Instruction Manual

SOKA SK18001AJ

SOKA 2-Handle Bathroom Sink Faucet

Model: SK18001AJ

Brand: SOKA

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your SOKA 2-Handle Bathroom Sink Faucet, Model SK18001AJ. Please read these instructions carefully before beginning installation and retain this manual for future reference.

PRODUCT FEATURES

- **Precise Water Adjustment:** Two handles allow for independent control of hot and cold water temperature and flow. Handles rotate 90° forward for installation in tighter spaces.
- **Premium Material Construction:** Features a durable ceramic disc cartridge, hybrid underbody, stainless steel spout and body, and nylon braided water supply lines. Conforms to low lead requirements.
- **Easy Installation:** Designed for 3-hole sinks or counters. Includes step-by-step instructions for straightforward setup.
- **ABS Pop-Up Drain:** Includes an ABS pop-up drain with a quick-connect fitting hose for convenience. The stainless steel faucet body ensures durability and easy cleaning.
- **Modern Design:** Metallic Grey finish provides a sleek, contemporary look suitable for various bathroom styles.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

SOKA 2 Handles 4" Centerset Bathroom Faucet



Figure 1: Included components of the SOKA 2-Handle Bathroom Sink Faucet.

- SOKA 2-Handle Faucet Assembly
- Deck Plate
- Hot and Cold Water Supply Lines (Nylon Braided)
- ABS Pop-Up Drain Assembly
- Mounting Hardware
- Instruction Manual

SPECIFICATIONS

SOKA 2 Handles 4" Centerset Bathroom Faucet



Figure 2: Product Dimensions.

Feature	Detail
Brand	SOKA
Model Name	SK18001AJ
Recommended Uses	Bathroom
Mounting Type	Deck Mount (Protruding)
Finish Type	Brushed Metallic Grey
Material	Stainless Steel
Number of Handles	2
Hole Count	3
Special Feature	Pop Up Drain
Style	Goose Neck
Product Dimensions	14.96"D x 3.15"W x 12.6"H
Item Weight	3.39 pounds (1.54 Kilograms)

INSTALLATION INSTRUCTIONS

Before you begin, ensure you have all necessary tools and that the main water supply to your bathroom is turned off. This faucet is designed for 3-hole sinks or counters.

Step-by-Step Guide:

- 1. Prepare the Sink:** Clean the faucet mounting area on your sink or countertop. Ensure the three holes are clear and correctly spaced for a 4-inch centerset faucet.
- 2. Install the Faucet:** Place the faucet body and deck plate onto the sink holes. Secure it from underneath the sink using the provided washers and mounting nuts. Tighten securely but do not overtighten.
- 3. Connect Water Supply Lines:** Attach the hot and cold water supply lines to the corresponding inlets on the faucet body. The lines are typically color-coded (red for hot, blue for cold). Connect the other ends to your hot and cold water supply valves. Ensure all connections are hand-tightened, then use a wrench for a quarter turn more.
- 4. Install the Pop-Up Drain:** Follow the specific instructions provided with the ABS pop-up drain assembly. Typically, this involves placing the drain body into the sink drain hole, securing it with gaskets and nuts from underneath, and connecting the quick-connect fitting hose.
- 5. Test for Leaks:** Once all connections are made, slowly turn on the main water supply. Check all connections for any signs of leaks. If leaks occur, gently tighten the connections until they stop.

OPERATING INSTRUCTIONS

Your SOKA 2-Handle Bathroom Sink Faucet offers precise control over water flow and temperature.



Cold & Hot Water Precise Control

Smooth & Steady Water Flow

Figure 3: Faucet handles and swivel spout.

- **Water Flow Control:** Turn the handles upwards to open the water flow. The further you turn them, the greater the flow.
- **Temperature Adjustment:** The left handle controls hot water, and the right handle controls cold water. Adjust both handles to achieve your desired water temperature.
- **Spout Rotation:** The gooseneck spout can swivel 360 degrees, providing maximum access and flexibility for various sink tasks.
- **Pop-Up Drain Operation:** Press the center of the pop-up drain to close it and retain water in the sink. Press it again to open the drain and allow water to flow out.



SOKA Bathroom Sink Faucets

304 Stainless Steel

Ceramic Valve

PET Pipe

Leak Free

Figure 4: Honeycomb Aerator for water saving and splash-free flow.

MAINTENANCE

Proper care will ensure the longevity and appearance of your SOKA faucet.

- **Cleaning the Finish:** Clean the faucet regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the brushed metallic grey finish. Mild soap and water are recommended.
- **Aerator Maintenance:** If water flow decreases or becomes erratic, the aerator may be clogged. Unscrew the aerator from the tip of the spout, clean any debris or mineral deposits, and rinse thoroughly before reattaching.

- **Pop-Up Drain Cleaning:** Periodically remove the pop-up drain stopper and clean any hair or debris that may have accumulated to ensure proper drainage.
- **Ceramic Cartridge:** The ceramic disc cartridge is designed for long-lasting, leak-free performance. If leaks occur from the handles, the cartridge may need inspection or replacement.

TROUBLESHOOTING

If you encounter issues with your faucet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed supply valves.	Clean the aerator. Ensure hot and cold water supply valves are fully open.
Leaking from Spout	Worn ceramic cartridge.	Contact customer support for a replacement cartridge.
Leaking from Handle Base	Loose mounting nut; worn O-rings or cartridge.	Tighten mounting nut. Inspect and replace O-rings or cartridge if necessary.
Water Temperature Issues	Incorrect handle adjustment; issues with water heater.	Adjust both hot and cold handles. Check your water heater settings.
Pop-Up Drain Not Sealing/Draining	Debris in drain; improper installation.	Clean debris from the drain. Re-check drain assembly installation.

WARRANTY AND SUPPORT

The SOKA 2-Handle Bathroom Sink Faucet (Model SK18001AJ) comes with **lifetime warranty**, ensuring peace of mind regarding its quality and durability.

For technical assistance, warranty claims, or to order replacement parts, please contact SOKA customer support through the retailer where the product was purchased or visit the official SOKA website for contact information.