

[Manuals.plus](#) /

› [AILINKE](#) /

› AILINKE MFS-JSQ-2303P Plant and Reptile Humidifier User Manual

AILINKE MFS-JSQ-2303P

AILINKE MFS-JSQ-2303P Plant and Reptile Humidifier User Manual

Model: MFS-JSQ-2303P

1. PRODUCT OVERVIEW

The AILINKE MFS-JSQ-2303P is a versatile humidifier designed for maintaining optimal humidity levels in environments for plants, reptiles, and other specialized habitats. It features smart controls, an expandable hose system, and a large capacity water tank for extended operation.



Image: AILINKE MFS-JSQ-2303P Humidifier in a home environment.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Main Humidifier Unit
- Water Tank
- User Manual
- Remote Control
- Cleaning Cloth
- Sensor Probe
- Flexible Hoses (Short and Long)
- 3-Way Nozzle
- Hose Clamps (x5)

- Screwdriver
- Tool Bag
- Straps (x3)



Image: Complete package contents.

3. SETUP INSTRUCTIONS

3.1 Connecting the Water Pump and Main Unit

Connect the two ends of the water pipe to the water pump and the main unit's inlet. Ensure a secure connection.

Your browser does not support the video tag. This video demonstrates how to connect the water pipe between the pump and the main humidifier unit.

Video: Connecting the water pipe to the humidifier.

3.2 Assembling the Humidifier

Place the main unit onto the water tank, ensuring it is seated correctly.

3.3 Water Refilling

The humidifier offers two refilling options: top-filling or by removing the water tank. The 8L (2.1 Gal) tank allows for continuous operation for up to 48 hours.



Image: Simplified design illustrating top-filling, tank-filling, and essential oil diffuser.

3.4 Hose Installation

Attach the flexible hoses and 3-way nozzle using the provided stainless steel hose clamps and screwdriver. Ensure all connections are secure to prevent leaks.




Image: Hose Usage Instructions.

3.5 Placement for Grow Tents/Terrariums

For grow tents or terrariums, place the humidifier unit outside the enclosure. Position the other end of the extension tube inside the tent or terrarium to effectively distribute moisture where needed. Use the provided straps to secure the hoses.

Humidifiers for Plants & Reptiles

Smart controls and expandable hoses provide precise mist for optimal plant growth and ideal reptile habitats.



Image: Humidifier setup for plants and reptiles.

4. OPERATING INSTRUCTIONS

4.1 Control Modes

The humidifier can be controlled via the touch panel on the unit or the included remote control.




Image: Touch Panel and Remote Control features.

4.2 Mist Levels

Select from three mist levels: Low, Medium, or High, to suit your specific humidity requirements.




Image: 3-Level Adjustable Mist.

4.3 Humidity Control

Set a target humidity level between 35% and 95% in 5% increments. The humidifier will automatically stop misting when the preset level is reached and resume when humidity drops.

4.4 Timer Function

Utilize the 1-12 hour timer to customize operation duration.

4.5 Sleep Mode

Activate sleep mode to turn off all display lights for undisturbed use.

4.6 Auto Restart

The humidifier retains previous settings and automatically resumes operation after a power outage.



Image: Auto Restart After Power Outage.

4.7 Aroma Diffuser

Add 1-2 drops of essential oils to the designated tray at the back of the unit for a pleasant aroma.

4.8 Sensor Probe

The sensor probe accurately monitors ambient temperature and humidity levels, providing real-time data for precise humidification adjustments.

Precision Monitoring for Optimal Plant Care

Sensor temp range :

0 – 99°F

Sensor humidity range :

0 – 99%



Timer set range :

1-12H

Humidity set range :

35%-95%



Image: Precision Monitoring for Optimal Plant Care.

5. MAINTENANCE

5.1 Cleaning

The humidifier is designed with a detachable water pump and suction pipe for easy cleaning. Regularly clean these components to ensure optimal performance and prevent mineral buildup.

5.2 Water Tank Care

The top-filling design simplifies refilling and reduces the risk of leaks. Periodically clean the water tank to maintain hygiene.

6. TROUBLESHOOTING

6.1 Red Blinking Indicator

If the red light on the display is blinking, follow these steps:

1. Check if the water tank is empty. Refill if necessary.
2. Check the water pump: Ensure the hose and inlet port are not cracked or damaged. Verify both ends of the hose are connected to the water pump's inlet and the main unit's inlet up to the root. Confirm that any packing material has been removed from the water pump.
3. Remove the cover and check the unit: Ensure the float is floating in the water. Turn on the power and check if water is pumping from the water tank to the upper head. Verify the atomizer is working properly.

Your browser does not support the video tag. This video provides troubleshooting steps for a blinking red light indicator.

Video: Troubleshooting for Red Blinking.

6.2 Weak Mist or No Mist Output

If the humidifier produces little to no mist, perform the following checks:

1. Remove any packaging bag from the water pump.
2. Check the water pump: Ensure the hose and inlet port are not cracked or damaged. Verify both ends of the hose are connected to the water pump's inlet and the main unit's inlet up to the root. Confirm that any packing material has been removed from the water pump.
3. Check the upper part: Press to turn the humidifier on. Open the upper cover and take out the filter. Check if water can be sucked up. Under normal circumstances, water will come out of the water outlet.

Note: For first-time use, it may take about 60 seconds to generate mist. If the ambient humidity exceeds the set value, the humidifier will stop spraying mist automatically.

7. SPECIFICATIONS

- **Brand:** AILINKE
- **Model Name:** MFS-JSQ-2303P
- **Capacity:** 8L (2.1 Gallons)
- **Mist Levels:** 3 (Low, Medium, High)
- **Adjustable Humidity Range:** 35-95% (in 5% increments)
- **Timer Setting:** 1-12 hours
- **Noise Level:** Below 35dB
- **Power:** 25 watts
- **Voltage:** 120 Volts
- **Product Dimensions:** 5.1"D x 5.7"W x 27"H
- **Item Weight:** 4.8 Pounds
- **Special Features:** Adjustable Humidity Control, Aroma Diffuser, Auto Shut Off, Digital Display, Humidistat, Expandable Hose, Remote Control

8. WARRANTY & SUPPORT

The product comes with a 1-YEAR warranty. You can apply for a 6-month extended warranty by registering on our website.

For any inquiries or support, please contact us via the order details page or email us at service@keecocon.com.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DNPNZ5TK>

More documents and user manuals: <https://manuals.plus/>