

Kircuit 5V AC/DC Adapter (ASIN: B0DNPT1Q2N)

Kircuit 5V AC/DC Adapter Instruction Manual

Model: Compatible with Wockoder KD-2008, KD-2008BL Turntables

INTRODUCTION

This manual provides instructions for the safe and effective use of your Kircuit 5V AC/DC Adapter. This adapter is designed to power compatible devices, specifically Wockoder KD-2008 and KD-2008BL 3-Speed Portable LP Phonograph Record Players. Please read this manual thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Use this adapter only with devices that require a 5V DC input and a current draw of 1.5A or less. Using it with incompatible devices may cause damage.
- Do not expose the adapter to water, moisture, or high humidity.
- Keep the adapter away from heat sources, direct sunlight, and flammable materials.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- Do not attempt to open, modify, or repair the adapter. Refer all servicing to qualified personnel.
- The adapter features Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.

PACKAGE CONTENTS

- 1 x Kircuit 5V AC/DC Adapter

SETUP INSTRUCTIONS

Follow these steps to connect your Kircuit AC/DC Adapter:

1. **Identify Device Power Port:** Locate the DC power input port on your Wockoder KD-2008 or KD-2008BL turntable. This is typically a circular port.
2. **Connect Adapter to Device:** Carefully insert the barrel connector of the Kircuit 5V AC/DC Adapter into the power input port of your turntable. Ensure a snug fit.
3. **Plug into Wall Outlet:** Insert the AC prongs of the adapter into a standard 100-240V AC electrical wall outlet.



Image: Front and back view of the Kircuit 5V AC/DC Adapter, highlighting its compact design and input/output labels.



Image: The Kircuit 5V AC/DC Adapter with its integrated power cord, illustrating the 6.5 ft length for flexible placement.

OPERATING INSTRUCTIONS

Once the adapter is correctly connected to both the wall outlet and your Wockoder turntable, it will begin supplying power. Ensure the power switch on your turntable is set to the 'ON' position to operate the device.



Image: The Kircuit 5V AC/DC Adapter plugged into a power strip on a desk, demonstrating a typical usage scenario.

CARE AND MAINTENANCE

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cord too tightly around the adapter body to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cord for any signs of damage, such as cuts, fraying, or bent prongs. Discontinue use if damage is found.

TROUBLESHOOTING

No Power to Device

- **Check Connections:** Ensure the adapter is securely plugged into both the wall outlet and your Wockoder turntable.

- **Verify Outlet:** Test the wall outlet with another device to confirm it is functional.
- **Device Power Switch:** Confirm that the power switch on your Wockoder turntable is in the 'ON' position.
- **Compatibility:** Double-check that your device model (Wockoder KD-2008 or KD-2008BL) is compatible with a 5V DC, 1.5A power supply.
- **Inspect Adapter:** Look for any visible damage to the adapter or its cord. If damaged, discontinue use.

PRODUCT SPECIFICATIONS

Brand	Kircuit
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	100-240V AC, 50/60Hz
Output Voltage	5V DC
Output Current	1.5A (1500mA)
Connector Type	Barrel
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Compatible Devices	Wockoder KD-2008, KD-2008BL 3-Speed Portable LP Phonograph Record Player

WARRANTY AND SUPPORT

For warranty information, technical support, or inquiries regarding your Kircuit 5V AC/DC Adapter, please refer to your purchase documentation or contact your retailer. You may also reach out to the manufacturer, Shenzhen Waweis Technology Co., Ltd, for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DNPT1Q2N>

More documents and user manuals: <https://manuals.plus/>