



Manuals.plus /

› LINSY HOME /

› LINSY HOME 31.5" Round Drum Coffee Table with Sliding Tambour Door (Model HT001L) - User Manual

## LINSY HOME HT001L

# LINSY HOME 31.5" Round Drum Coffee Table with Sliding Tambour Door (Model HT001L) - User Manual

Model: HT001L | Brand: LINSY HOME

## 1. INTRODUCTION

---

This manual provides essential information for the assembly, operation, and maintenance of your LINSY HOME 31.5" Round Drum Coffee Table. Please read these instructions carefully before assembly and retain for future reference.



Image: The LINSY HOME Round Drum Coffee Table, showcasing its oak finish and the unique sliding tambour door design.

## 2. SAFETY INFORMATION

---

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and retighten as necessary.
- Do not exceed the maximum weight capacity of 64 pounds (29 kg) for the tabletop.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- Avoid placing hot items directly on the table surface without protective coasters.
- This table is designed for indoor use only.

## 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop Panel
- Base Panel
- Tambour Door Assembly
- Adjustable Shelf Panels (2)
- Side Support Panels (Internal)
- Assembly Hardware (screws, dowels, shelf pins, etc.)
- Assembly Guide (Included)

## 4. SETUP AND ASSEMBLY

---

Assembly is required for this coffee table. A screwdriver is recommended for assembly. Please follow the included assembly guide carefully. Pay close attention to the orientation of each board to avoid reassembly.

### Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Refer to the parts list in the included assembly guide to identify each piece.
2. **Attach Side Supports:** Secure the internal side support panels to the base panel using the provided hardware. Ensure they are correctly aligned.
3. **Install Tambour Door:** Carefully slide the tambour door into its designated grooves on the base and side supports. Ensure it moves smoothly.
4. **Insert Adjustable Shelves:** Place the shelf pins into the desired holes on the internal side supports. Position the adjustable shelf panels onto the pins.
5. **Attach Tabletop:** Align the tabletop panel with the top edges of the side supports and tambour door assembly. Secure it using the remaining hardware.
6. **Final Check:** Verify that all connections are tight and the table is stable. Test the sliding tambour door for smooth operation.




*Image: Detailed diagram illustrating the table's dimensions (31.5" diameter, 18" height) and the internal storage layout with two adjustable tiers, each capable of holding up to 50 lbs.*

## 5. OPERATING INSTRUCTIONS

---

### Sliding Tambour Door:

The coffee table features a unique fluted tambour door that slides smoothly around the circumference of the table. To access the internal storage, gently push the door along its track. The door can be positioned to reveal any of the four storage sections, allowing flexible access and display options.



Ample Storage Space  
Adjustable Shelf

Image: A close-up of the tambour door in action, demonstrating its smooth sliding mechanism to access the storage compartments.

### Adjustable Storage Shelves:

The internal storage area includes two tiers of adjustable shelves. To adjust a shelf's height, remove any items from the shelf, lift the shelf panel, and reposition the shelf pins into the desired holes on the internal side supports. Ensure the shelf is level and securely seated before placing items on it.

### Placement and Use:

This round coffee table is suitable for various indoor settings, including living rooms, offices, or lounge areas. It can serve as a central surface for beverages and snacks, a display area for decorative items, or a convenient storage solution for books and other essentials.

## 6. MAINTENANCE

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the engineered wood finish.

- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Protection:** Use coasters under drinks and placemats under hot dishes to protect the surface from heat and moisture rings.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.

## 7. TROUBLESHOOTING

---

- **Table is Unstable/Wobbly:**
  - Ensure all assembly screws are fully tightened.
  - Verify that the table is placed on a flat, even surface.
  - Check if the anti-slip pads on the base are intact and evenly distributed.
- **Tambour Door Not Sliding Smoothly:**
  - Inspect the tracks for any obstructions or debris.
  - Ensure the door is properly seated in its grooves.
  - Confirm that the table was assembled correctly, as misaligned panels can affect door movement.
- **Parts Do Not Fit During Assembly:**
  - Double-check the assembly guide to ensure you are using the correct parts for each step.
  - Verify the orientation of the panels. Some parts may appear similar but have specific top/bottom or front/back orientations.
  - If parts are genuinely mismanufactured or damaged, contact customer support.
- **Scratches or Damage Upon Arrival:**
  - Carefully inspect all components immediately upon receipt.
  - If significant damage is present, document it with photos and contact the retailer or LINSY HOME customer support for assistance.

## 8. SPECIFICATIONS

---

<b>Brand</b>	LINSY HOME
<b>Model Number</b>	HT001L
<b>Model Name</b>	Fluted Coffee Table
<b>Dimensions (D x W x H)</b>	31.5" x 31.5" x 18" (80cm x 80cm x 45.7cm)
<b>Item Weight</b>	57 Pounds (25.85 kg)
<b>Maximum Weight Recommendation</b>	64 Pounds (29 kg)
<b>Color</b>	Oak
<b>Material Type</b>	Engineered Wood
<b>Shape</b>	Round
<b>Style</b>	Mid-Century Modern
<b>Indoor/Outdoor Usage</b>	Indoor
<b>Tools Recommended for Assembly</b>	Screwdriver

## ACCORDING TO THE COLOR

Due to different monitors, may lead to differences in product color, please prevail in kind!



LCD



RETINA



LED



IPS



PLS

## CHROMATIC ABERRATION

Under the influence of different environments, different times, different shooting equipment and other factors, there may be color differences in the pictures taken.



Studio Lighting



Natural Lighting



Indoor Lighting

*Image: Visual details of the table's construction, including the fluted tambour design, the smooth round edges, and the protective anti-slip pads on the bottom.*

## 9. WARRANTY AND SUPPORT

---

LINSY HOME products are manufactured with quality and care. While specific warranty details are not provided in this manual, most products come with a limited warranty against manufacturing defects. Please retain your proof of purchase.

For any questions regarding assembly, missing parts, product defects, or general inquiries, please contact LINSY HOME customer support. Refer to your purchase documentation or the retailer's website for the most current contact information.

You can also visit the official LINSY HOME store for more information: [LINSY HOME Store](#)

## IMPORTANT NOTE ON COLOR VARIATION

---

Please be aware that product color may vary slightly due to lighting conditions, device display settings (LCD, Retina,

LED, IPS, PLS), and other environmental factors during photography. The images provided are for reference, and the actual product color may differ.



Image: A visual guide demonstrating potential color variations of the coffee table when viewed under different lighting environments.