

MEDION S66822

MEDION S66822 Mini Portable DAB+ / FM Radio with Bluetooth User Manual

Model: S66822

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your MEDION S66822 Mini Portable DAB+ / FM Radio. Please read it thoroughly before using the device and retain it for future reference. Your new radio features DAB+ and FM reception, Bluetooth 5.3 for wireless audio streaming, a 1.47-inch dimmable color display, an integrated battery, and an alarm clock with snooze function.

2. SAFETY INSTRUCTIONS

- **Water Protection:** The device is rated IPX1, offering protection against vertically falling water drops. Do not immerse the device in water or expose it to strong jets of water. Avoid use in environments with excessive humidity.
- **Power Source:** Use only the provided USB-C charging cable and a compatible USB power adapter (not included) for charging. Ensure the power source voltage matches the device requirements.
- **Battery Safety:** The radio contains an integrated rechargeable battery. Do not attempt to replace the battery yourself. Avoid exposing the device to extreme temperatures, direct sunlight, or open flames.
- **Ventilation:** Ensure adequate ventilation around the device. Do not cover ventilation openings.
- **Cleaning:** Disconnect the device from power before cleaning. Use a soft, dry cloth. Do not use liquid or abrasive cleaners.
- **Disposal:** Dispose of the device and its battery responsibly according to local regulations.

3. PACKAGE CONTENTS

Please check that all items are present and in good condition:

- MEDION S66822 Mini Portable DAB+ / FM Radio
- USB-C Charging Cable
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the radio's components and controls.



Figure 4.1: Front view of the MEDION S66822 radio, showing the speaker grille, display, and control buttons.

The front panel features the speaker, the 1.47-inch color display, and several control buttons:

- **Power / Mode Button:** Turns the radio on/off and switches between DAB+, FM, Bluetooth, and AUX modes.
- **Preset / Menu Button:** Accesses saved presets and the main menu.
- **Volume Up (+) / Next Track:** Increases volume or skips to the next track in Bluetooth mode.
- **Volume Down (-) / Previous Track:** Decreases volume or skips to the previous track in Bluetooth mode.
- **Settings Button:** Enters the settings menu.
- **Play/Pause / OK Button:** Plays/pauses audio in Bluetooth mode, confirms selections in menus.
- **Rotary Knob:** Navigates through menus, adjusts volume, or tunes stations.

The rear of the device typically houses the telescopic antenna, USB-C charging port, and AUX-In port.

5. SETUP

5.1 Charging the Battery

Before first use, fully charge the radio's integrated battery.

1. Connect the provided USB-C charging cable to the USB-C port on the radio.
2. Connect the other end of the USB-C cable to a compatible USB power adapter (e.g., smartphone charger, computer USB port).
3. The display will indicate charging status. A full charge provides up to 6.5 hours of playback at medium

volume, depending on usage.

5.2 Initial Power On and Antenna

1. Extend the telescopic antenna for optimal radio reception.
2. Press and hold the **Power** button to turn on the radio.
3. Upon first power-on, the radio may prompt you to select a language and perform an automatic DAB+ scan. Follow the on-screen instructions.

6. OPERATING INSTRUCTIONS

6.1 DAB+ Radio Mode



Figure 6.1: The radio displaying DAB+ station and track information.

1. Press the **Power / Mode** button repeatedly until 'DAB Radio' appears on the display.
2. If it's the first time in DAB+ mode or if stations need updating, the radio will perform an automatic scan.
3. Use the **Rotary Knob** to scroll through the list of available DAB+ stations.
4. Press the **OK** button to select a station.
5. **Saving Presets:** To save a station, press and hold the **Preset** button, then use the **Rotary Knob** to select a preset number (up to 40) and press **OK**.
6. **Recalling Presets:** Briefly press the **Preset** button, then use the **Rotary Knob** to select a saved station

and press **OK**.

6.2 FM Radio Mode

1. Press the **Power / Mode** button repeatedly until 'FM Radio' appears on the display.
2. **Automatic Scan:** Press and hold the **OK** button to automatically scan for and save available FM stations.
3. **Manual Tuning:** Use the **Rotary Knob** to manually tune to a frequency.
4. **Saving Presets:** Similar to DAB+ mode, press and hold the **Preset** button, select a number, and press **OK**.
5. **Recalling Presets:** Briefly press the **Preset** button, select a saved station, and press **OK**.

6.3 Bluetooth Mode



Figure 6.2: The radio wirelessly streaming music from a smartphone via Bluetooth.

1. Press the **Power / Mode** button repeatedly until 'Bluetooth' appears on the display. The radio will enter pairing mode, indicated by a flashing Bluetooth icon.
2. On your smartphone or other Bluetooth device, enable Bluetooth and search for 'MEDION S66822'.
3. Select the radio to pair. Once connected, the Bluetooth icon will stop flashing.
4. You can now play audio from your paired device through the radio. Use the **Play/Pause**, **Volume Up (+)**, and **Volume Down (-)** buttons on the radio to control playback.

6.4 AUX Mode

1. Press the **Power / Mode** button repeatedly until 'AUX Input' appears on the display.
2. Connect an external audio device (e.g., MP3 player) to the radio's 3.5mm AUX-In port using an audio cable (not included).
3. Audio from the external device will now play through the radio. Control playback and volume from the external device.

6.5 Alarm Clock and Sleep Timer



Figure 6.3: The radio can be used as an alarm clock with snooze functionality.

The radio features an alarm clock with snooze and a sleep timer.

- **Setting Alarm:** Access the alarm settings via the **Menu** or **Settings** button. You can set multiple alarms and configure them for one-time, weekdays, weekends, or daily activation.
- **Snooze Function:** When the alarm sounds, press the **Snooze** button (often the **OK** button or a dedicated button) to temporarily silence it.
- **Sleep Timer:** Set the sleep timer (up to 120 minutes) via the **Menu** or **Settings** to automatically turn off the radio after a set period.

6.6 Display and Sound Settings

Alles im Blick dank 1,47" TFT-Farbdisplay

Dimmbar durch 3 wählbare Helligkeitsstufen



Figure 6.4: The 1.47-inch TFT color display showing radio information.

- **Display Dimmer:** The 1.47-inch TFT color display has a dimming function with 3 selectable brightness levels. Access this setting through the **Settings** menu to adjust for comfort.
- **Equalizer:** The radio includes an equalizer function to adjust sound profiles. Navigate to the **Settings** menu to select from predefined equalizer settings or customize your own.

7. MAINTENANCE

7.1 Cleaning

To clean your radio, ensure it is turned off and disconnected from any power source. Use a soft, dry, lint-free cloth to wipe the surfaces. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish or internal components.

7.2 Battery Care

To prolong the life of the integrated battery:

- Avoid fully discharging the battery frequently.
- Store the radio in a cool, dry place when not in use for extended periods.
- Charge the battery periodically if stored for a long time to prevent deep discharge.

8. TROUBLESHOOTING

If you encounter issues with your MEDION S66822 radio, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power / Radio does not turn on	Battery is discharged; Power cable not connected properly.	Charge the battery using the USB-C cable. Ensure the cable is securely connected.
Poor radio reception (DAB+/FM)	Antenna not fully extended; Weak signal area; Interference.	Fully extend the telescopic antenna. Reposition the radio to a location with better signal. Avoid sources of electronic interference.
Bluetooth pairing fails	Radio not in pairing mode; Bluetooth disabled on external device; Device already paired with another radio.	Ensure the radio is in Bluetooth pairing mode (flashing icon). Enable Bluetooth on your device. Forget previous pairings on your device and try again.
No sound in AUX mode	AUX cable not connected; Volume too low on external device or radio.	Ensure the AUX cable is securely connected to both devices. Increase volume on both the external device and the radio.
Display is too dim	Display brightness setting is low.	Adjust the display brightness in the Settings menu.

9. SPECIFICATIONS

Der ideale Begleiter

Super kompaktes Format



- USB-C Ladeanschluss (5 V, 1 A)
- AUX-In (3,5 mm Klinke)

Figure 9.1: The compact size of the MEDION S66822 radio, ideal for portability.

Feature	Detail
Brand	MEDION
Model	S66822 (MD44822)
Connectivity Technology	Bluetooth 5.3
Special Features	Integrated Battery, Bluetooth, DAB+, AUX Input, Dimmable Display, Sleep Timer, Alarm with Snooze, Equalizer, Telescopic Antenna, RDS, DRC, AMS
Compatible Devices	Headphones, Smartphone
Display	1.47-inch (3.73 cm) TFT Color Display
Power Source	Battery operated, Power cable (USB-C)
Battery Life	Up to 6.5 hours (at medium volume, depending on usage mode)

Feature	Detail
Audio Output Power	2 W RMS
Supported Radio Bands	DAB+, FM, AM
Water Protection	IPX1 (protection against vertically falling water drops)
Product Dimensions (L x W x H)	9.1 cm x 13 cm x 7.5 cm

10. WARRANTY AND SUPPORT

Your MEDION S66822 radio comes with a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official MEDION website for detailed warranty terms and conditions. For technical support, troubleshooting assistance, or service inquiries, please contact MEDION customer support. Contact information can typically be found on the MEDION website or in the product packaging.

© 2025 MEDION. All rights reserved.

Related Documents - S66822

 <p>MEDION® Handleiding Notice d'utilisation Bedienungsanleitung</p> <p>DAB+-projectiewekkerradio Radio-réveil avec projecteur DAB+ DAB+ Projektor-Uhrenradio MEDION® LIFE E66955 (MD 43955)</p>	<p><u>MEDION LIFE E66955 DAB+ Projectiewekkerradio Handleiding</u></p> <p>Gebruikershandleiding voor de MEDION LIFE E66955 DAB+ projectiewekkerradio. Leer hoe u de DAB/FM radio, wekker, en projectiefuncties instelt en gebruikt. Inclusief veiligheidsinstructies en technische specificaties.</p>
 <p>medion Bedienungsanleitung Notice d'utilisation Bedienungsanleitung</p> <p>DAB+/FM Radio Radio-DAB+FM DAB+radio Radio-DAB+FM Radio-DAB+FM DAB+FM radio MEDION S66822 (MD 44822)</p>	<p><u>MEDION S66822 (MD 44822) DAB+/FM Radio Bedienungsanleitung</u></p> <p>Umfassende Bedienungsanleitung für das MEDION S66822 (MD 44822) DAB+/FM Radio mit Bluetooth-Konnektivität. Erfahren Sie mehr über Einrichtung, Bedienung und Funktionen dieses hochwertigen Radios.</p>
 <p>medion Anleitung Notice de configuration Bedienungsanleitung</p> <p>MEDION LIFE P66538 (MD 44538)</p>	<p><u>MEDION LIFE P66538 (MD 44538) Quick Start Guide</u></p> <p>This document provides a quick start guide for the MEDION LIFE P66538 (MD 44538) retro boombox, covering setup, operation, and safety information.</p>

 <p>medion Bedienungsanleitung Notice d'utilisation Bedienungsanleitung User manual</p>	<p>Medion P66750 DAB+ Premium Kitchen Radio Quick Start Guide</p> <p>A concise guide to setting up and operating the Medion P66750 DAB+ Premium Kitchen Radio, covering basic functions, radio operation, Bluetooth connectivity, and USB playback.</p>
 <p>medion Bedienungsanleitung Notice d'utilisation Bedienungsanleitung User manual</p> <p>Internetradio Radio en ligne Internetradio Radio Internet Internet Radio MEDION LIFE IRE-1(MD 89318)</p>	<p>MEDION LIFE IRE-1 (MD 89318) Bedienungsanleitung – Einrichtung und Bedienung</p> <p>Umfassende Bedienungsanleitung für das MEDION LIFE IRE-1 (MD 89318) Internetradio, die Einrichtung, Bedienung, Funktionen wie DAB/FM-Radio, Spotify Connect, Bluetooth und Fehlerbehebung abdeckt.</p>
 <p>medion Bedienungsanleitung Notice d'utilisation Bedienungsanleitung User manual</p> <p>All-In-One Audiosystem Système audio tout-en-un Sistema audio tutto in uno Sistema de audio todo en uno Sistema audio tutto in uno All-In-One Audio System MEDION P66400 (MD 44200)</p>	<p>MEDION P66400 All-In-One Audiosystem Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für das MEDION P66400 All-In-One Audiosystem. Enthält Anleitungen zur Einrichtung, Bedienung von Internetradio, DAB/FM, CD, Bluetooth, USB und Streaming-Diensten.</p>