

Meoilkolnm H88-White-128GB

Meoilkolnm H88 Mini Body Camera User Manual

MODEL: H88-WHITE-128GB

Brand: Meoilkolnm

1. INTRODUCTION

Thank you for choosing the Meoilkolnm H88 Mini Body Camera. This compact and versatile device is designed for hands-free recording in various environments, from personal security to capturing moments during travel or pet walking. This manual provides detailed instructions to help you set up, operate, and maintain your camera for optimal performance.

2. PRODUCT OVERVIEW

2.1 Key Features

- **User Friendly:** Simple one-button operation for easy recording. Indicator light provides status feedback.
- **Thumb Size & Lightweight:** Compact dimensions (64.5 x 28 x 20mm) and light weight for discreet and portable use.
- **Hands-Free Recording:** Multiple mounting options including a magnet pendant, safety cord, and 360° adjustable back clip.
- **Universal Compatibility:** Suitable for monitoring pets, children, elderly, or for personal recording in various settings.
- **High Definition Video:** Records in FHD 1080P resolution.
- **Integrated Storage:** Includes 128GB of storage for extended recording.
- **Wi-Fi Connectivity:** Allows for live preview, playback, and file download via a dedicated mobile application.

2.2 Package Contents

Verify that all items listed below are included in your package:

- 1 x 128GB Body Camera

- 1 x Magnet Pendant
- 1 x Safety Cord
- 1 x Portable Back Clip
- 1 x USB Cable



Image: The Meoilkolnm H88 Mini Body Camera shown with its accessories, including the magnet pendant, safety cord, portable back clip, USB cable, and a 128GB Micro SD card.

3. SETUP

3.1 Charging the Camera

1. Connect the provided USB cable to the camera's charging port.
2. Plug the other end of the USB cable into a standard USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status (refer to the camera's LED indicator guide for specific colors/patterns).
4. Allow the camera to charge fully before first use.

3.2 Initial Power On

To power on the camera for the first time:

- Press and hold the home button on the front of the camera for approximately 3 seconds until the indicator light illuminates.

Magnetic Design , Easy Clip Design , Mount Anywhere

with its 360 degree easy clip and magnet pendant design , you can get creative and film angle, no other camera can handle .




Image: Visual guide for powering on, initiating quick capture, and powering off the camera using the central button.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Recording

1. **Power On:** Press and hold the home button for 3 seconds. The blue LED will turn on.
2. **Quick Capture (Start Recording):** Once powered on, simply press the home button once to start recording. The blue LED will flash to indicate recording is in progress.
3. **Stop Recording:** Press the home button once again to stop recording. The blue LED will stop flashing and remain solid.
4. **Power Off:** Press and hold the home button for 3 seconds until the LED turns off.



Quick Capture

Simply press the home button on the front of the mini camera to start / stop recording instantly, when it's on.

Image: Demonstrates the quick capture function by pressing the camera's central button.

4.2 App Connectivity (Live Preview, Playback, Download)

The camera supports Wi-Fi connectivity for advanced functions via a dedicated mobile application (available for iOS and Android).

1. **Download App:** Search for the official Meoilkolnm camera app in your device's app store.
2. **Connect to Camera:**
 - Power on the camera.
 - Enable Wi-Fi on your smartphone and connect to the camera's Wi-Fi network (SSID and password typically found in the app or camera settings).
3. **Live Preview:** Once connected, open the app to view a live feed from the camera. This allows for precise framing of shots. (Recommended to use within 32ft/10m for best connection).
4. **Playback & Download:** The app allows you to browse recorded videos and photos, play them back, and download them directly to your smartphone.



LIVE PREVIEW & Play Back & Download on App

Mount up the body cam and use App preview your shots and snap away like a pro. (Recommended to use within 32ft (10m))

Image: Live preview functionality showing the camera's view on a smartphone screen.




Image: Instant app preview and file download interface on a smartphone.

4.3 Mounting Options

The Meoilkolnm H88 offers versatile mounting solutions for hands-free recording:

- **Magnet Pendant:** Attach the camera to the magnet pendant and wear it around your neck with the safety cord for discreet, chest-level recording.
- **Portable Back Clip:** Use the 360° adjustable back clip to attach the camera to clothing, bags, or other surfaces.
- **Other Surfaces:** The camera's magnetic design allows it to be mounted on various metallic surfaces.




Image: Demonstrates the magnet pendant, easy clip, and safety cord for secure camera placement.




Image: Visual representation of the magnetic and 360-degree easy clip design for versatile mounting.

Mount it anywhere, take it everywhere.



Image: Examples of the camera mounted in diverse locations, including an RC car, birdhouse, clothing, pet collar, and sports gear.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution. Avoid abrasive materials or harsh chemicals.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. If storing for extended periods, charge the battery to about 50% every few months.
- **Data Management:** Regularly transfer important recordings to a computer or cloud storage to prevent data loss and free up camera memory.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not power on.	Low battery; camera frozen.	Charge the camera fully. If unresponsive, try resetting by holding the power button for 10-15 seconds.
Cannot record video.	Insufficient storage; camera error.	Ensure sufficient storage is available. If the issue persists, try formatting the internal storage via the app or connecting to a computer.
Poor video quality (blurry, static).	Dirty lens; low light conditions; camera movement; software glitch.	Clean the lens. Ensure adequate lighting. Minimize camera shake during recording. Update camera firmware if available.
Wi-Fi connection issues.	Out of range; incorrect password; interference.	Ensure camera and smartphone are within 10 meters (32 feet). Verify Wi-Fi password. Try reconnecting.
Files not transferring to phone/computer.	Loose cable connection; driver issues; app error.	Ensure USB cable is securely connected. Try a different USB port or cable. Restart the app or computer.

7. SPECIFICATIONS

Feature	Detail
Model Number	H88-White-128GB
Product Dimensions	0.1 x 0.16 x 0.25 inches (64.5 x 28 x 20mm approx.)
Item Weight	5.9 ounces (167g approx.)
Video Capture Resolution	1080p FHD
Photo Sensor Technology	CMOS
Flash Memory Type	Micro SD (128GB included)
Video Capture Format	MP4
Supported Audio Format	AAC, MP3
Connectivity Technology	Wi-Fi
Color	White
Batteries	1 LR44 battery (included)
Manufacturer	Meoilkolnm

1.27 oz



(35.95g)



Small & Lightweight

Tiny camera, huge potential, Mount it and take it anywhere, anytime!

Image: The camera's compact size and light weight, approximately 1.27 ounces.

The Action GH88 Camera

to film for a massive **180** minutes after fully charged (WI-FI OFF) !



Image: The camera's dimensions and approximate battery life of 180 minutes when Wi-Fi is off.

8. WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the contact details provided with your purchase documentation or visit the official Meoilkolnm website. Keep your purchase receipt as proof of purchase for any warranty claims.

Online Support: [Meoilkolnm Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question