

EMONAIR ET01

EMONAIR Mate Tracker Tags User Manual

Model: ET01
Brand: EMONAIR

1. INTRODUCTION

Welcome to the EMONAIR Mate Tracker Tags user manual. This guide provides detailed instructions on how to set up, operate, and maintain your new Bluetooth item finders. Designed to work seamlessly with the Apple Find My app, these tags help you locate your valuable items quickly and efficiently.

2. IMPORTANT SAFETY INFORMATION

- **Battery Safety:** The device uses a replaceable CR2032 coin cell battery. Do not ingest the battery; it can cause severe internal burns. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- **Water Resistance:** The EMONAIR Mate Tracker Tags are rated IP67, meaning they are resistant to water splashes, rain, and short-term submersion. However, they are not designed for prolonged submersion or high-pressure water exposure. Ensure the battery compartment is securely closed before exposure to water.
- **Operating Temperature:** Operate the device within standard environmental temperatures. Extreme temperatures can affect battery life and device performance.
- **Disposal:** Dispose of the device and batteries according to local regulations. Do not dispose of batteries in fire.

3. PACKAGE CONTENTS

Please check the package to ensure all items are present:


- EMONAIR Mate Tracker Tags (4 Pack: 2 Black, 2 White)
- CR2032 Batteries (pre-installed)
- Small Screwdriver (for battery replacement)
- Lanyard (optional attachment)
- Sticky Pad (optional attachment)

4. PRODUCT OVERVIEW

The EMONAIR Mate Tracker Tags are compact and lightweight devices designed to help you keep track of your belongings. Each tag features a single button for operation and a key ring hole for easy attachment.



The EMONAIR Mate Tracker Tags come in black and white, offering a sleek design for various items.



0.31 in


Weight: 0.02lb
CR2032 Battery installed



Detailed view of the tracker tag, highlighting its compact size (1.3 inches diameter, 0.31 inches height) and key components like the button and screw for battery access.



The lightweight design of the tracker tag makes it ideal for attaching to keys or other small items.



EMONAIR

Every Moment Of Need Always In Reach

The versatile design allows the tracker tags to be attached to a wide range of items, ensuring your valuables are always within reach.

5. SETUP

Pairing with Apple Find My App (iOS Only)

The EMONAIR Mate Tracker Tags are designed exclusively for iOS devices and work with the Apple Find My app. Ensure your iOS device is updated to the latest version.

1. **Enable Bluetooth:** Go to your iOS device's Settings, then Bluetooth, and ensure Bluetooth is turned ON.
2. **Open Find My App:** Launch the 'Find My' app on your iPhone or iPad.
3. **Activate Tracker Tag:** Press the button on the EMONAIR Mate Tracker Tag. Release the button when you hear a beep, indicating the tag has entered pairing mode.
4. **Add Item:** In the Find My app, tap on the 'Items' tab, then tap 'Add Item'.
5. **Select Other Supported Item:** Choose 'Other Supported Item' from the options.

6. **Connect:** The app will detect your EMONAIR Mate Tracker Tag. Tap 'Connect' and follow the on-screen instructions to complete the pairing process, including naming your tag.



Your browser does not support the video tag.

This video demonstrates the setup and various uses of the EMONAIR Mate Tracker Tags, including attaching them to keys and bottles, and their compatibility with the Apple Find My app.

6. OPERATING YOUR TRACKER TAGS

Finding Items

There are two primary ways to find your items using the EMONAIR Mate Tracker Tags:

- **Play Sound:** When your tag is within Bluetooth range (up to 200 feet), open the Find My app, select your tag, and tap 'Play Sound'. The tag will emit a loud sound (80-100 decibels) to help you locate it. You can also ask Siri for help.
- **Map Navigation:** If your tag is out of Bluetooth range, the Find My app will display its last known location on a map. You can use the app's navigation feature to guide you to the general area where your item was last detected by the Apple Find My network.



One-Tap Find

Locate your items by making the tags ring (with a loud 100 decibels) via the built - in speaker.

Use the 'Play Sound' feature in the Find My app to quickly locate your tag when it's nearby.

Left-Behind Remind

The 'Left-Behind Remind' feature in the Find My app provides instant notifications if you leave an item with an EMONAIR Mate Tracker Tag behind. This helps prevent accidental loss by alerting you when the tag goes out of Bluetooth range from your iOS device.

Left-Behind Remind

When an item with an EMONAIR Bluetooth tracker goes out of Bluetooth range from your iOS device, you'll get an instant phone notification.



"Keys" Left Behind

20m ago

This item is no longer detected near you. It was last seen near *****



Receive instant notifications if you accidentally leave your tagged items behind.

Lost Mode

If an item with your EMONAIR Mate Tracker Tag is lost, you can activate 'Lost Mode' in the Find My app. When in Lost Mode, if another Apple device user comes within range of your tag, you will receive an updated location. You can also add contact information so that if someone finds your tag, they can scan it and see your contact details.

Lost Mode

If you set lost mode and add contact info, nearby Apple devices can share the tag's location, giving you more ways to track your valuables.



Activate Lost Mode to leverage the Apple Find My network for locating misplaced items and to provide contact information to finders.

7. CARE AND MAINTENANCE

Battery Replacement

The EMONAIR Mate Tracker Tags use a replaceable CR2032 coin cell battery, which typically lasts between 12 to 25 months depending on usage. You can check the battery status within the Find My app.

To replace the battery:

1. Locate the small screw on the back of the tracker tag.
2. Use the provided small screwdriver to carefully open the battery compartment.
3. Remove the old CR2032 battery.
4. Insert a new CR2032 battery with the positive (+) side facing up.
5. Securely close the battery compartment, ensuring the screw is tightened to maintain water resistance.

Water and Dust Resistance

The EMONAIR Mate Tracker Tags are IP67 rated, providing protection against dust ingress and temporary immersion in water (up to 1 meter for 30 minutes). This means they can withstand splashes, rain, and brief accidental submersions. However, it is not recommended for swimming or prolonged water activities. Always ensure the battery compartment is properly sealed after replacement to maintain its water resistance.

8. TROUBLESHOOTING COMMON ISSUES

Problem	Possible Cause	Solution
Cannot pair the tag with the Find My app.	Bluetooth is off; tag not in pairing mode; low battery; interference.	Ensure Bluetooth is enabled on your iOS device. Press the tag's button to activate pairing mode (listen for a beep). Check battery level and replace if necessary. Move away from other electronic devices.
Tag sound is too low or not audible.	Low battery; tag is too far away; environmental noise.	Replace the CR2032 battery. Ensure you are within Bluetooth range (approx. 200 feet). Move to a quieter environment if possible.
Location in Find My app is inaccurate or not updating.	Tag is out of range of any Apple device; network issues.	The Find My network relies on nearby Apple devices. If the tag is in a remote area, updates may be less frequent. Ensure your own device has a stable internet connection.
Left-Behind Remind not working.	Feature not enabled in Find My app; app permissions.	Verify that 'Notify When Left Behind' is enabled for the specific tag in the Find My app settings. Check location services and notification permissions for the Find My app on your iOS device.

9. PRODUCT SPECIFICATIONS

Feature	Specification
Model Number	ET01
Dimensions (L x W x H)	0.3 x 1.3 x 1.3 inches (7.9 x 33 x 33 mm)
Item Weight	0.264 ounces (7.6 grams)
Connectivity Technology	Bluetooth
Compatibility	iOS devices only (iPhone, iPad, Mac)
Battery Type	CR2032 (included)
Battery Life	12-25 months (typical)
Water & Dust Resistance	IP67 rated

Feature	Specification
Sound Level	80-100 decibels
Material	Polycarbonate (PC), Acrylonitrile Butadiene Styrene (ABS)

10. WARRANTY AND CUSTOMER SUPPORT

For any questions, technical assistance, or warranty inquiries regarding your EMONAIR Mate Tracker Tags, please contact EMONAIR customer support through the platform where you purchased the product. Please refer to your purchase documentation for specific warranty terms and conditions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question