XTREME DIGITAL LIFESTYLE ACCESSORIES XBH9-1031

User Manual

Xtreme Wireless Bluetooth Headphones with Microphone

Model: XBH9-1031

1. Introduction

Thank you for choosing the Xtreme Wireless Bluetooth Headphones. These headphones are designed to provide a high-quality audio experience with the convenience of wireless connectivity. Featuring Bluetooth V5.0 + EDR technology, a built-in microphone, and intuitive controls, they are perfect for music, calls, and media playback on the go. This manual will guide you through the setup, operation, and maintenance of your new headphones.

2. Product Overview

2.1. Package Contents

- Xtreme Wireless Bluetooth Headphones
- Micro USB Charging Cable

2.2. Headphone Components and Controls

Familiarize yourself with the various parts and controls of your headphones for optimal use.



Image: Detailed view of the headphone controls, including volume, track skip, and power/pairing buttons.

- **Power/Multi-function Button:** Used for powering on/off, pairing, play/pause, and answering/ending calls.

- **Volume Up/Next Track Button:** Press briefly to increase volume, press and hold to skip to the next track.
- **Volume Down/Previous Track Button:** Press briefly to decrease volume, press and hold to go to the previous track.
- **Microphone:** Built-in for hands-free calling.
- **Micro SD Card Slot:** For direct audio playback from a memory card.
- **Aux-in Port:** For wired connection using a 3.5mm audio cable (cable not included).
- **Micro USB Charging Port:** For charging the internal battery.



Image: The headphones highlighting key features such as one-touch call controls, built-in microphone, foldable design, and battery life.

The headphones feature a foldable design for enhanced portability, making them easy to store and carry.



Image: The headphones shown in their folded state, illustrating their compact form factor for travel and storage.

3. Setup

3.1. Charging the Headphones

Before first use, fully charge your headphones. Connect the included Micro USB charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The LED indicator will show charging status (typically red while charging, off or blue when fully charged). A full charge provides up to 3 hours of continuous playtime.

3.2. Powering On/Off

- **To Power On:** Press and hold the Power/Multi-function Button for approximately 3 seconds until the LED indicator flashes.
- **To Power Off:** Press and hold the Power/Multi-function Button for approximately 3 seconds until the LED indicator turns off.

4. Operating Instructions

4.1. Bluetooth Pairing

To connect your headphones to a Bluetooth-enabled device:

1. Ensure the headphones are powered off.
2. Press and hold the Power/Multi-function Button for approximately 5-7 seconds until the LED indicator flashes red and blue alternately. This indicates pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for new devices.
4. Select "Xtreme Headphones" (or similar name) from the list of available devices.
5. Once paired, the LED indicator on the headphones will flash blue slowly or turn solid blue. You are now connected and ready to use your headphones within a range of up to 33 feet (10 meters).

4.2. Music Playback

- **Play/Pause:** Press the Power/Multi-function Button once.
- **Next Track:** Press and hold the Volume Up/Next Track Button.
- **Previous Track:** Press and hold the Volume Down/Previous Track Button.
- **Volume Up:** Press the Volume Up/Next Track Button briefly.
- **Volume Down:** Press the Volume Down/Previous Track Button briefly.

4.3. Phone Calls

- **Answer/End Call:** Press the Power/Multi-function Button once during an incoming call.
- **Reject Call:** Press and hold the Power/Multi-function Button for approximately 2 seconds during an incoming call.
- **Redial Last Number:** Double-press the Power/Multi-function Button.

4.4. Micro SD Card Playback

Insert a Micro SD card (not included) with your desired audio files into the Micro SD card slot. The headphones will automatically switch to Micro SD card mode and begin playing music. Use the same music playback controls (Play/Pause, Next/Previous Track, Volume) as described in section 4.2.

4.5. Aux Line-in Mode

To use the headphones with a wired connection, plug a 3.5mm audio cable (not included) into the Aux-in port on the headphones and the other end into your audio device. The headphones will automatically switch to Aux mode. Note that controls on the headphones may not function in Aux mode; control playback directly from your connected device.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.

6. Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully using the provided Micro USB cable.
Cannot pair with device.	Headphones not in pairing mode; Device Bluetooth off; Too far from device.	Ensure headphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move headphones closer to your device (within 33 feet).
No sound or distorted sound.	Volume too low; Headphones not connected; Audio source issue.	Increase volume on headphones and device. Re-pair headphones. Check audio source (e.g., try another song/app).
Micro SD card not playing.	Card not inserted correctly; Unsupported file format.	Re-insert the Micro SD card. Ensure audio files are in a supported format (e.g., MP3).

7. Specifications

Feature	Detail
Model Name	Xtreme Over the Ear Bluetooth Headphones
Item Model Number	XBH9-1031
Brand	XTREME DIGITAL LIFESTYLE ACCESSORIES
Connectivity Technology	Wireless (Bluetooth V5.0 + EDR)
Wireless Range	Up to 33 feet (10 meters)
Ear Placement	Over Ear
Form Factor	Over Ear, Foldable
Color	Black
Playtime	Up to 3 hours
Included Components	Over the Ear Bluetooth Headphones, Micro USB Charging Cable
Item Weight	12.8 ounces
Package Dimensions	8.7 x 7.5 x 3.5 inches
UPC	805106238568
ASIN	B0DNRFTVWL
Date First Available	November 21, 2024

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official XTREME DIGITAL LIFESTYLE ACCESSORIES website. Keep your proof of purchase for any warranty claims.

© 2024 XTREME DIGITAL LIFESTYLE ACCESSORIES. All rights reserved.