

Hisense WC06R25A

Hisense 6,000 BTU Window Air Conditioner WC06R25A User Manual

Model: WC06R25A

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Hisense 6,000 BTU Window Air Conditioner, Model WC06R25A. Please read this manual thoroughly before using the appliance and retain it for future reference. Proper use and maintenance will ensure optimal performance and longevity of your air conditioner.



Image: The Hisense 6,000 BTU Window Air Conditioner seamlessly integrated into a living room setting, providing cooling comfort.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.


- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the air conditioner with a damaged power cord or plug.
- Do not insert fingers or objects into the air inlet/outlet.
- Keep the air conditioner away from heat sources and direct sunlight.
- Always unplug the unit before cleaning or servicing.
- Do not attempt to repair or modify the unit yourself. Contact qualified service personnel.

3. PRODUCT OVERVIEW

The Hisense WC06R25A is a 6,000 BTU window air conditioner designed for efficient cooling of small rooms. It features user-friendly controls and multiple operational modes.

Key Features:

- **Effortless Installation:** Includes an easy-to-install window kit for quick setup.
- **Hassle-Free Maintenance:** Features a washable, removable filter for easy cleaning.
- **Dual Control Convenience:** Operable via a user-friendly control panel or included remote control.
- **Customized Airflow:** 4-way adjustable horizontal and vertical air vents for even air distribution.
- **Smart 24-Hour Timer:** Allows programming of automatic on/off times for energy efficiency.
- **Quiet Operation:** Designed for ultra-quiet performance.



Window Width (inches)	Min	Max	Window Height Min
	22 inch	37.8 inch	12.4 inch

Image: Front view of the Hisense WC06R25A Window Air Conditioner, showing the control panel and air outlet.

4. SETUP AND INSTALLATION

The Hisense WC06R25A is designed for easy window installation. Follow these general guidelines for a secure and efficient setup. Refer to the included installation kit instructions for detailed steps specific to your window type.

Installation Steps:

1. **Prepare the Window:** Ensure the window opening meets the minimum and maximum dimensions specified in the specifications section.
2. **Install the Window Kit:** Attach the side panels and top rail to the air conditioner unit as per the kit instructions.
3. **Place the Unit:** Carefully lift and place the air conditioner into the window opening, ensuring it is securely seated and tilted slightly outwards to allow for condensate drainage.
4. **Secure the Unit:** Extend the side panels to fill the window opening and secure them with screws. Install the sash lock and foam seals to prevent air leakage.
5. **Power Connection:** Plug the unit into a grounded electrical outlet.



Image: Diagram showing the Hisense WC06R25A unit with its dimensions (13.6"D x 16"W x 11.8"H) and recommended window width and height for installation.

5. OPERATING INSTRUCTIONS

Your Hisense air conditioner offers various modes and settings for personalized comfort. Controls can be adjusted using the unit's control panel or the included remote control.

Control Panel Functions:

- **Power Button:** Turns the unit on or off.
- **Mode Button:** Cycles through operating modes: Cool, Fan, Dry (Dehumidifier), Eco.
- **Temperature Up/Down Arrows:** Adjusts the desired temperature setting.
- **Fan Speed Button:** Selects fan speed: Low, Medium, High.
- **Timer Button:** Sets the 24-hour programmable timer for automatic on/off.
- **Sleep Mode:** Activates a quiet, energy-saving mode for nighttime operation.
- **Filter Light Reminder:** Illuminates to indicate when the filter needs cleaning.

Airflow Adjustment:

The unit features 4-way adjustable air vents. Manually adjust the horizontal and vertical louvers to direct the airflow as desired, ensuring even cooling throughout the room.



Image: The Hisense WC06R25A unit installed in a window, illustrating the 4-way air direction feature for optimal air distribution.

6. MAINTENANCE

Regular maintenance ensures efficient operation and extends the lifespan of your air conditioner. The washable, removable filter makes cleaning quick and easy.

Filter Cleaning:

1. **Turn Off and Unplug:** Always disconnect power to the unit before cleaning.
2. **Remove Filter:** Gently pull out the air filter from its designated slot.
3. **Clean Filter:** Wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinserting. Do not use harsh chemicals or abrasive cleaners.
4. **Reinstall Filter:** Slide the dry filter back into its slot.

The Filter Light Reminder will illuminate to prompt cleaning. After cleaning, press the Filter button to reset the reminder.

General Cleaning:

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not use water directly on the control panel.
- Periodically check the drainage area for any blockages.




Image: The Hisense WC06R25A unit with its washable, removable filter being taken out for cleaning, highlighting the easy maintenance feature.

7. TROUBLESHOOTING

Before contacting customer service, review the following common issues and solutions:

Problem	Possible Cause	Solution
Unit does not turn on	No power, tripped circuit breaker, loose plug.	Check power connection, reset circuit breaker, ensure plug is secure.
Insufficient cooling	Dirty air filter, blocked air intake/outlet, room too large, open windows/doors.	Clean air filter, clear obstructions, ensure room size is appropriate, close windows/doors.
Unit is noisy	Loose parts, unit not level, fan obstruction.	Check for loose parts, ensure unit is level, remove any fan obstructions.
Water leakage	Unit not tilted correctly, blocked drain.	Ensure unit is slightly tilted outwards, clear drain path.

8. SPECIFICATIONS

Feature	Detail
Brand	Hisense
Model Name	WC06R25A
Cooling Power	6,000 British Thermal Units (BTU)
Coverage Area	Up to 250 Square Feet
Voltage	115 Volts
Wattage	535 watts
Noise Level	51 Decibels
Product Dimensions (D x W x H)	13.6"D x 16"W x 11.8"H
Item Weight	38.6 Pounds
Window Opening Minimum Width	16 Inches
Window Opening Maximum Width	36 Inches
Window Opening Minimum Height	11.8 Inches
Filter Type	Mesh Filter
Refrigerant	R-32
Control Method	Button Control, Remote Control
Included Components	Window Installation Kit

9. WARRANTY AND SUPPORT

Your Hisense 6,000 BTU Window Air Conditioner, Model WC06R25A, is backed by a reliable 2-year manufacturer's warranty. This warranty covers defects in materials and workmanship under normal use. For warranty claims, technical support, or service inquiries, please refer to the contact information provided in your product packaging or visit the official Hisense website. Please have your model number (WC06R25A) and proof of purchase available when contacting support.

© 2026 Hisense. All rights reserved.