

[Manuals.plus](#) /

> [INFANS](#) /

> INFANS Mud Kitchen Playset with Bench - Instruction Manual (Model TP10307GR)

INFANS TP10307GR

INFANS Mud Kitchen Playset with Bench - Instruction Manual

Model: TP10307GR

1. PRODUCT OVERVIEW

The INFANS Mud Kitchen Playset is a wooden outdoor play kitchen designed for children aged 3-7 years. It features a removable sink, a swivel faucet, four pretend stoves, a chalkboard, and a dessert counter. This playset encourages imaginative play and can accommodate multiple children simultaneously. It is constructed from premium quality medium-density fiberboard (MDF) and treated with water-based paints.



Image 1: Children engaging with the INFANS Mud Kitchen Playset, showcasing its L-shaped design and integrated bench.

2. SAFETY INFORMATION

This product complies with U.S. CPSIA & ASTM safety standards for physical and chemical safety testing. Please observe the following safety guidelines:

- **Age Recommendation:** Suitable for children aged 3 to 7 years.
- **Material Safety:** Made from premium wood and water-based paints, free from BPA, PVC, Phthalates, Lead, Latex, and Formaldehyde.
- **Design Safety:** Features smooth rounded corners to prevent scratches and bumps.
- **Adult Supervision:** Always ensure adult supervision during play.
- **Placement:** For outdoor use, place the kitchen in a covered area to protect the wood from prolonged exposure to rain and direct sunlight, which can extend its lifespan.
- **Assembly:** Ensure all screws and fasteners are securely tightened before use. Regularly check for loose parts.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged:

- 1 x INFANS Mud Kitchen Playset (Wooden components)
- 1 x Removable Sink
- 1 x Swivel Faucet
- 1 x Chalkboard
- 4 x Pretend Stoves
- 4 x Pots (accessories)
- Multiple Kitchen Accessories (e.g., dessert counter items, utensils)
- Assembly Hardware (screws, bolts, etc.)
- Instruction Manual



Image 2: A selection of kitchen utensils and accessories that come with the playset, including pots, a hot pad, and dessert items.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your INFANS Mud Kitchen Playset. An electric drill is recommended for faster and more secure assembly. Refer to the assembly video for visual guidance.

4.1 Assembly Video Guide

Your browser does not support the video tag.

Video 1: Official INFANS assembly guide for the Mud Kitchen Playset. This video demonstrates the step-by-step process of putting together the wooden components and attaching accessories.

4.2 Step-by-Step Assembly Overview

1. **Prepare Components:** Lay out all wooden pieces and hardware. Identify each part using the labels (if any) and the instruction diagram.
2. **Assemble the Bench:** Connect the bench seat to its support legs using the provided screws. Ensure all connections are tight.
3. **Assemble the Main Kitchen Frame:** Begin by constructing the base frames for the kitchen unit. Attach the side panels and shelves as indicated in the manual.
4. **Install the Oven Door:** Attach the oven door using the hinges and secure the handle.
5. **Attach Countertops:** Place the stove and sink countertops onto the main frame and secure them with screws.
6. **Install Back Panels and Shelving:** Secure the back panels and any additional shelving units to the main structure.
7. **Connect the Bench to the Main Unit:** Align the bench with the main kitchen unit and secure it using the designated bolts and screws.
8. **Attach Accessories:** Install the water bucket with the faucet, place the removable sink into its slot, and hang the chalkboard.

Note: The assembly video provides a comprehensive visual guide for each step. Please refer to it for detailed instructions.

5. OPERATING INSTRUCTIONS

The INFANS Mud Kitchen is designed for interactive and imaginative play. Here's how to use its main features:

- **Removable Sink:** The spacious sink can be used for washing play food, vegetables, or as a mixing station for mud and sand. It is designed to hold water for realistic play.
- **Swivel Faucet:** Fill the yellow water bucket with water and hang it on the side. The integrated faucet allows children to dispense water into the sink, enhancing the play experience.
- **Pretend Stoves:** The four stove burners are for imaginative cooking. The stove knobs can be twisted to simulate cooking actions.
- **Chalkboard:** Use chalk (not included) to write menus, recipes, or draw pictures on the chalkboard.
- **Storage:** Utilize the bottom shelf and double storage cabinet to store play food, utensils, and other accessories.



1 FAUCET

Wash vegetables & fruits
fun experience



2 CUT VEGETABLES

Make delicious food



3 GAS RANGE

Twist the knobs to hear
realistic clicks

4 COOKING SET

Simulation stove, more realistic



Image 3: Detailed view of the functional faucet, pretend vegetable cutting area, and clickable stove knobs.

2 Ways to Play the Sink



Image 4: Illustration of the versatile sink, demonstrating its use for water play and as a sand play area.

6. MAINTENANCE

Proper maintenance will ensure the longevity of your Mud Kitchen Playset:

- **Cleaning:** The wooden surfaces and plastic accessories can be easily cleaned by wiping with a damp cloth. Avoid harsh chemical cleaners.
- **Drying:** After water play, ensure all components, especially wooden parts, are thoroughly dried to prevent mold or warping.
- **Storage:** If possible, store the playset in a covered or sheltered area when not in use, especially during inclement weather, to protect the wood.
- **Inspection:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary. Inspect for any signs of wear or damage and address them promptly.

7. TROUBLESHOOTING

If you encounter any issues with your Mud Kitchen Playset, consider the following:

- **Loose Components:** If any parts feel wobbly, check and re-tighten all screws and bolts.

- **Fading Wood:** Prolonged exposure to direct sunlight can cause wood to fade. Consider placing the playset in a shaded area or applying a child-safe wood sealant.
- **Faucet Leaks:** Ensure the faucet is correctly assembled with all washers in place and tightened securely to the water bucket.
- **Missing Parts:** If any parts were missing upon delivery, contact INFANS customer support immediately.

8. SPECIFICATIONS

Brand	INFANS
Model Number	TP10307GR
Suitable Age	3-7 years (36-84 months)
Overall Dimensions (L x W x H)	59" x 28" x 39" (149.86 cm x 71.12 cm x 99.06 cm)
Material	MDF, PP, Stainless Steel
Color	Natural with Gray Accents
Style	Natural with Bench



Image 5: Detailed product dimensions for planning placement and understanding scale.

9. WARRANTY AND SUPPORT

For any questions, concerns, or to report missing/damaged parts, please contact INFANS customer support. Refer to your purchase documentation for specific warranty details and contact information.

Manufacturer: INFANS