

KIDYWOLF KIDYKARAOKE

KIDYWOLF KIDYKARAOKE Portable Karaoke Speaker User Manual

Model: KIDYKARAOKE | Brand: KIDYWOLF

INTRODUCTION

Thank you for choosing the KIDYWOLF KIDYKARAOKE Portable Karaoke Speaker. This device is designed to provide an engaging audio experience with its integrated speaker and two wireless microphones. This manual provides essential information for the safe and efficient use of your karaoke speaker. Please read it thoroughly before operation and retain it for future reference.



Image Description: A top-down view of the KIDYWOLF KIDYKARAOKE portable speaker, featuring a teal-colored speaker grille with the KIDYWOLF logo, surrounded by a vibrant LED light ring. Two matching teal wireless microphones are positioned in front of the speaker.

PACKAGE CONTENTS

Please check the package carefully to ensure all items are present and in good condition.

- KIDYKARAOKE Speaker Unit
- 2 x Wireless Microphones
- USB-C / USB Cable
- User Manual (this document)



Image Description: A close-up of the side of the KIDYKARAOKE product box, clearly listing "PACKAGE CONTENT" which includes the KIDYKARAOKE machine, 2x microphone, and USB-C/USB cable. It also indicates "Micro-SD Card NOT INCLUDED".

PRODUCT FEATURES

The KIDYKARAOKE speaker offers a range of features for an enhanced karaoke experience:

- Portable device
- 2x Microphones
- 40W Speaker output
- Wireless Microphones
- Microphone dock plug
- Bluetooth Connection
- Micro-SD Card slot
- USB-C Plug for charging
- LED Light (Multi-color, 360° light)
- Integrated Battery (3.7V / 1800mAh / 6.6Wh)
- Voice changer function
- Water protection (indicated by a droplet icon, likely splash-proof)



Image Description: A close-up of the side of the KIDYKARAOKE product box, clearly listing "FEATURES" with icons for portable device, 2x microphones, 40W speaker, wireless microphones, microphone dock plug, Bluetooth connection, Micro-SD card slot, USB-C plug, LED light, multi-color, 360° light, integrated battery, voice changer, and water protection.

SETUP

1. **Initial Charging:** Before first use, fully charge the KIDYKARAOKE speaker using the provided USB-C cable. Connect the USB-C end to the speaker's charging port and the USB-A end to a compatible USB power adapter (not included). The charging indicator will show the charging status.
2. **Power On:** Press and hold the power button on the speaker until the LED lights illuminate and an audible prompt is heard.
3. **Microphone Pairing:** The two wireless microphones are typically pre-paired with the speaker. To use them, simply power them on. If re-pairing is needed, refer to the troubleshooting section or the full manual for specific instructions.
4. **Connecting to Audio Source (Bluetooth):**
 - Activate Bluetooth on your smartphone, tablet, or other audio device.
 - On the KIDYKARAOKE speaker, ensure Bluetooth mode is active (indicated by a specific LED pattern or voice prompt).
 - Search for "KIDYKARAOKE" in your device's Bluetooth settings and select it to pair.
 - Once connected, you can play music from your device through the speaker.
5. **Using Micro-SD Card:** Insert a Micro-SD card (not included) with pre-loaded music into the designated slot on the speaker. The speaker should automatically detect and begin playing music from the card.

OPERATING INSTRUCTIONS

Speaker Controls

- **Power Button:** Press and hold to power on/off. Short press to change modes (Bluetooth, Micro-SD).
- **Volume Controls (+/-):** Adjust the main speaker volume.
- **Light Effect Button:** Cycle through different LED light patterns or turn lights on/off.
- **Play/Pause Button:** Play or pause music playback.
- **Previous/Next Track Buttons:** Skip to the previous or next song.

Microphone Usage

- **Power On/Off:** Each microphone has its own power button. Press and hold to turn on or off.
- **Microphone Volume:** Use the volume controls on the microphone to adjust your vocal output.
- **Voice Changer:** Press the dedicated button on the microphone to cycle through available voice effects.
- **Microphone Dock:** When not in use, the microphones can be securely placed in the integrated docks underneath the speaker.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker and microphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Water Protection:** While the device has some water protection, avoid submerging it in water or exposing it to heavy rain. Wipe off any splashes immediately.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the speaker fully using the provided USB-C cable.
No sound from speaker.	Volume too low; incorrect mode; no audio source connected.	Increase volume. Ensure correct mode (Bluetooth/Micro-SD). Verify Bluetooth connection or Micro-SD card insertion.
Microphones not working.	Microphones off; low battery in microphones; not paired.	Ensure microphones are powered on. Charge microphones if they have separate charging. If not paired, power cycle both speaker and microphones, then try again.
Bluetooth connection unstable.	Device too far from speaker; interference.	Move the connected device closer to the speaker. Avoid obstacles and other wireless devices.

SPECIFICATIONS


- **Model:** KIDYKARAOKE
- **Brand:** KIDYWOLF
- **Product Dimensions:** 10.04 x 14.57 x 4.13 inches (25.5 x 37 x 10.5 cm approx.)
- **Item Weight:** 2.92 pounds (1.32 kg approx.)
- **Speaker Output:** 40W

- **Battery:** Integrated 3.7V / 1800mAh / 6.6Wh
- **Connectivity:** Bluetooth, Micro-SD Card, USB-C for charging
- **Manufacturer:** Kidywolf
- **ASIN:** B0DN7L782G
- **UPC:** 5407009181788

WARRANTY AND SUPPORT

KIDYWOLF products are manufactured with high-quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official KIDYWOLF website.
Official Website: www.kidywolf.com

Related Documents - KIDYKARAOKE

	Procedura aktualizacji KIDYKARAOKE - KIDYWOLF Szczegółowy przewodnik krok po kroku dotyczący aktualizacji oprogramowania urządzenia KIDYKARAOKE firmy KIDYWOLF. Dowiedz się, jak pobrać i zainstalować najnowszą wersję.
	KidyWolf KidyTorch Flashlight User Manual and Warranty Information Comprehensive guide for the KidyWolf KidyTorch flashlight, including operating instructions, safety precautions, and warranty details. Learn how to use and care for your KidyTorch.
	KIDYWOLF KIDYMICROSCOPE Quick Start Guide and Product Information Comprehensive guide for the KIDYWOLF KIDYMICROSCOPE, detailing features, packaging, usage instructions, and warranty information.
	KIDYWOLF K-WATCH Quick Start Guide: Setup and Usage Get started quickly with your KIDYWOLF K-WATCH. This guide provides essential setup, operation, charging, and troubleshooting information for the K-WATCH smartwatch.
	KIDYWOLF K-WATCH Smartwatch User Guide: Features and Navigation Explore the features of the KIDYWOLF K-WATCH smartwatch, including its buttons, wallpapers, main menus, settings, and application access. Learn how to navigate your device and customize its functions.



KIDYWOLF KIDYDRAWPRO Quick Start Guide

Get started with your KIDYWOLF KIDYDRAWPRO, a versatile drawing tablet featuring a reversible blackboard and glow-in-the-dark capabilities. This guide provides essential information on setup, usage, and safety.

Documents - KIDYWOLF – KIDYKARAOKE

Belgian brand

Marca belga

KIDYKARAOKE



[pdf]

KIDYWOLF EN ES DAGRNUSAD3I BAD gP8 krl 0 NESPART Marketing Product Sheet Kidykaraoke

Intro 4 1 Demo 30% Off JC Toys kidykaraoke cdn shopify s files 0684 5834 8681 v 1741946988 |||

Belgian brand Marca belga **Kidykaraoke** 14 Portable karaoke speaker Altavoz

karaoke port til The atmosphere at your parties is always guaranteed with the **KIDYKARAOKE** lighted speaker. Our portable karaoke speaker plunges you into the heart of the party with powerful sound, equipped with 2 x 20W ...

lang:es score:29 filesize: 2.38 M page_count: 2 document date: 2025-01-30

NESPART

Declaration of Conformity

We : Nespart SRL
Driest Richelle 161H
1410 Waterloo
Belgium

certify and declare under our sole responsibility that the following product:
Trade name: KIDYKARAOKE
Product name: KIDYKARAOKE



KIDYKARAOKE-GB
EAN: 046700908768

conforms with Standard:

- EN 71-1:2014+A1:2018
- EN 71-2:2020
- EN 71-3:2014+A1:2018
- 2009/18/EC Safety of Toys
- Directive 2006/96/EC
- (EU) 2012/778
- (EU) 2014/725
- (EU) 2015/1022
- EN 71-3:2015 + A1:2021

Certification realized by SGS (Report T2410333296771).

- EU RoHS Directive (EU) 2015/863

Certification realized by SGS (Report 526223000553051).

Place a date of issue: Waterloo, 28 October 2024

Gary Garnier-Guisgand
Administrator


NESPART SRL - Driest Richelle 161H 1410 Waterloo
Tel: +32 2 935 32 33 - email: info@nespart.com
RPM Number: - TVA BE0122.800.024

CLUB COUCOUN'S

sint & kerst catalogus



ontdek ons aanbod duurzame
cadeaus voor alle leeftijden



[pdf] Declaration of Conformity

Déclaration of Conformity KIDYKARAOKE Gary Garnier Guisgand Certificaat KIDYWOLF Declaration v

1738838854 cdn shopify s files 1 0879 3767 9624 |||

Declaration of Conformity We : Nespart SRL Drve Richelle 161H 1410 Waterloo

Belgium certify and declare under our sole responsibility that the following product:

Trade name: **KIDYKARAOKE** Product name: **KIDYKARAOKE** conforms with

Standard: EN 71-1:2014 A1:2018 EN 71-2: 2020 EN 71-1:2014 A1:2018 2009...

lang:en score:28 filesize: 396.21 K page_count: 1 document date: 2025-02-05

[pdf] Catalog

Sinterklaas catalogus DAGTBMDeVr0 BAET2d97eCI Roxanne Download hier Club Coucoun Harelbeke

Baby kids Geboortelijsten Speelgoed Sint en kerst gecompriemd v 173161607 cdn shopify s files 1

0618 5064 8743 1731616072 |||

CLUB COUCOUN S sint kerst catalogus ontdek ons aanbod duurzame cadeaus voor


alle leeftijden WWW.CL ... eftijd van 3 jaar, mits begeleiding.

WWW.CLUBCOUCOUN.BE CLUB COUCOUN - NAJAARS CATALOGUS

KIDYWOLF **KIDYKARAOKE** SET met 2 microfonen - 59,90

WWW.CLUBCOUCOUN.BE CLUB COUCOUN - NAJAARS CATALOGUS KIDYW...

lang:nl score:25 filesize: 17.01 M page_count: 44 document date: 2024-11-14



[Club Coucoun Sint & Kerst Catalogus: Duurzaam Speelgoed voor Alle Leeftijden](#)

Ontdek de Club Coucoun Sint & Kerst Catalogus met een breed assortiment duurzaam en open-ended speelgoed voor kinderen van alle leeftijden. Vind inspiratie voor cadeaus.

lang:nl **score:25** filesize: 2.61 M page_count: 58 document date: 2025-11-03

BonoboBox Sinterklaas Brochure 2025




[\[pdf\] Borchure Catalog](#)

Untitled Download de catalogus interactieveBonoboBox Originele geboortebboxen duurzaam speelgoed in BelgiëEindejaars 2025cdn shopify s files 1 0507 3666 0634 Eindejaars 2025 v 1761655851 |||

BonoboBox Sinterklaas Brochure 2025 Welkom bij Bonobobox Ontdek ons ruim assortiment duurzaam speelgoed voor 0-8 jaar. Duurzame, Europese merken - met oog voor kwaliteit en design. Ontdek o.a. Smartgames, CleverClix, Tikit, Learning Resources, Kidywolf, Hey Clay, Plus-Plus BIG, Invit...

lang:nl **score:22** filesize: 3.62 M page_count: 58 document date: 2025-10-28




[\[pdf\] Warranty](#)

KIDYKARAOKE Warranty EN 05 Vecto Mode d'emploi KIDYWOLF Warr X11 V BD v 1745499556 cdn shopify s files 1 0879 3767 9624 |||

...

lang:nl **score:14** filesize: 3.62 M page_count: 47 document date: 2025-04-24



[\[pdf\] Warranty](#)

KIDYKARAOKE Warranty EN 03 Vecto Berceau magique La garantie ne couvre pas les pièces autres que le lui même batterie bénéficie d'une limitée de 6 mois Tenir hors portée des kidywolf enceinte karaoke portable kidykaraoke berceaumagique support 9232 |||

...

lang:nl **score:14** filesize: 2.98 M page_count: 43 document date: 2024-09-13