

OMO Rs1003

OMO Electric Razor User Manual

Model: Rs1003

1. INTRODUCTION

Thank you for choosing the OMO Electric Razor. This manual provides essential information for the safe and effective use of your new electric shaver. Please read it thoroughly before first use and keep it for future reference. This electric razor is designed for men's facial shaving, offering both wet and dry shaving capabilities with a convenient pop-up trimmer for detailed styling.

2. IMPORTANT SAFETY INFORMATION

- Water Safety:** This appliance is IPX6 waterproof and suitable for use in the shower. However, do not immerse the charger or the shaver in water while charging.
- Children:** Keep the appliance out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Power Source:** Use only the provided USB charging cable. Ensure the power source voltage is compatible with the shaver's requirements.
- Damage:** Do not use the shaver if it is damaged in any way, including the charging cable or the shaver head. Contact customer support for assistance.
- Cleaning:** Always unplug the shaver before cleaning. Refer to the "Maintenance" section for proper cleaning instructions.
- Battery:** Do not attempt to replace the battery yourself. Dispose of the product responsibly at the end of its life, following local regulations for battery disposal.

3. PACKAGE CONTENTS

Please check the package for the following items:

- OMO Electric Razor (Model: Rs1003)
- USB Charging Cable
- User Manual

- Cleaning Brush
- Protective Cap



Image: The OMO Electric Razor shown alongside its retail packaging, illustrating the product and its box.

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your OMO Electric Razor:

- **5D Floating Shaving Head:** Adapts to facial contours for a smooth shave.
- **Power Button:** Turns the shaver on/off and activates travel lock.
- **Pop-up Trimmer:** For precise trimming of sideburns and mustaches.

- **LED Display:** Shows battery level, charging status, travel lock, and wash reminder.
- **Charging Port:** USB-A input for charging.



**5D Flexible
Floating Head**
Adapts To Every Contours

Image: A close-up view of the shaver's 5D flexible floating head, designed to adapt to facial contours for an efficient shave.



Precision Double-track Cut Blades

Excellent Shaving Speed And Effect

Image: An exploded view showing the precision double-track cut blades within the shaver head, highlighting their design for effective hair cutting.

5. CHARGING YOUR SHAVER

Before first use, fully charge your OMO Electric Razor. A full charge takes approximately 1.5 hours and provides up to 60 minutes of shaving time.

1. Ensure the shaver is turned off.
2. Insert the small end of the USB charging cable into the charging port on the shaver.
3. Connect the larger end of the USB cable to a USB power source (e.g., computer, power bank, car charger, or a wall adapter - not included).
4. The LED display will show a charging indicator and the battery percentage will increase.
5. Once fully charged, the display will indicate "full" or 100%. Disconnect the shaver from the power source.



USB-A Charging

Convenient & Fast
(wall adapter
not included)



Image: The electric razor is shown connected to a USB charging cable, with its LED display indicating charging status and battery level.

6. SETUP

Your OMO Electric Razor comes ready for use after charging. No complex assembly is required.

- **Initial Charge:** As mentioned in Section 5, ensure the shaver is fully charged before its first use to optimize battery life.
- **Travel Lock:** The shaver features a travel lock to prevent accidental activation. To activate or deactivate, press and hold the power button for 3 seconds. The LED display will show a lock icon when activated.

7. OPERATING INSTRUCTIONS

7.1 Basic Shaving

1. Ensure the shaver is charged and unlocked.

2. Press the power button once to turn on the shaver.
3. Hold the shaver at a right angle to your skin and move it in small, circular motions against the direction of hair growth.
4. Apply gentle pressure. Do not press too hard, as this can irritate the skin and reduce shaving efficiency.
5. After shaving, press the power button again to turn off the shaver.



Gentle on Skin

Comfortable and clean shaving

Image: A man is shown using the electric razor on his face, illustrating the gentle application for a comfortable shave.

7.2 Wet and Dry Shaving

Your OMO Electric Razor is designed for both wet and dry use:

- **Dry Shave:** For a quick and convenient shave, use the shaver on dry skin.
- **Wet Shave:** For a more comfortable and refreshing shave, you can use the shaver with shaving foam or gel, or even in the shower. Ensure the shaver is not connected to the charging cable when used with water.



Shave Wet or Dry

With Foam, Gel or Even in The Shower




Image: A composite image demonstrating the versatility of the shaver, with one panel showing wet shaving using foam and another showing dry shaving.

7.3 Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for shaping sideburns, mustaches, and detailing your beard line.

1. Turn on the shaver.
2. Locate the pop-up trimmer switch (usually on the back or side of the shaver) and slide it upwards to engage the trimmer.
3. Hold the trimmer perpendicular to your skin and gently guide it along the desired area.
4. Once finished, slide the trimmer switch downwards to retract it.



Pop-up Trimmer

For Mustache And Sideburns

Image: A man is depicted using the pop-up trimmer feature of the electric razor to precisely trim his sideburns.

8. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your shaver.

8.1 Cleaning the Shaver Head

Clean the shaver head after each use, especially after wet shaving with foam or gel.

1. Turn off the shaver and disconnect it from the charging cable.
2. Press the release button (if applicable) or gently twist/pull to detach the shaver head from the body.
3. Rinse the shaver head thoroughly under running tap water. You can also use the included cleaning brush to remove stubborn hair clippings.
4. Rinse the hair chamber on the shaver body.
5. Allow both parts to air dry completely before reattaching the shaver head.
6. Do not wipe the shaver head with a towel, as this can damage the delicate cutting elements.



Detachable Head

Fully washable for Easy Cleaning



Image: Hands are shown rinsing the detachable head of the electric razor under running tap water, demonstrating the easy cleaning process.

8.2 Replacing Shaving Heads

For optimal shaving performance, it is recommended to replace the shaving heads every 12 months, or sooner if you notice a decrease in performance or increased irritation.

- Replacement heads can be purchased from authorized OMO retailers or online.
- Follow the instructions provided with the replacement heads for proper installation.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is low or depleted. Travel lock is activated.	Charge the shaver. Deactivate travel lock by pressing and holding the power button for 3 seconds.

Problem	Possible Cause	Solution
Poor shaving performance.	Shaver head is dirty or clogged. Shaving heads are worn out.	Clean the shaver head thoroughly (refer to Maintenance). Replace the shaving heads.
Shaver pulls hair.	Shaver head is dirty. Shaving heads are dull.	Clean the shaver head. Replace the shaving heads. Ensure skin is clean and dry for dry shaving.
Charging indicator not working.	Charging cable or power source issue.	Try a different USB port or power adapter. Ensure the cable is securely connected.

If the problem persists after trying these solutions, please contact OMO customer support.

10. SPECIFICATIONS



Feature	Detail
Model Number	Rs1003
Brand	OMO
Power Source	Electric (USB Charging)
Charging Time	Approx. 1.5 hours
Operating Time	Up to 60 minutes
Waterproof Rating	IPX6 (Wet & Dry Use)
Special Features	5D Floating Head, Pop-up Trimmer, Travel Lock
Recommended Use	Face
Package Dimensions	7.1 x 3.8 x 2.84 inches
Item Weight	9.11 ounces

11. WARRANTY AND SUPPORT

Your OMO Electric Razor comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact OMO customer service through the retailer where you purchased the product or visit the official OMO website.

Please have your model number (Rs1003) and proof of purchase ready when contacting support.

	<p><u>OMO Independence Series Portable Power Station: Specs & Features</u></p> <p>Explore the OMO Independence Series Portable Power Station by Ozark Mountain Offgrid. Features 3840Wh capacity, 3000W pure sine wave inverter, and versatile outputs for home backup, remote work, and outdoor use.</p>
	<p><u>WS-8117 Atomic Clock with Outdoor Temperature and Moon Phase: Instruction Manual</u></p> <p>Comprehensive instruction manual for the WS-8117 Atomic Clock, detailing features, setup, settings, troubleshooting, and specifications for the atomic clock and its outdoor temperature transmitter.</p>
	<p><u>La Crosse WS-9032U Weather Station User Manual</u></p> <p>Comprehensive guide for the La Crosse WS-9032U Wireless Weather Station, covering setup, operation, features, and troubleshooting for indoor and outdoor temperature, humidity, and barometric pressure monitoring.</p>
	<p><u>La Crosse WS-8157 Atomic Clock & Weather Station User Manual</u></p> <p>Instruction manual for the La Crosse WS-8157 Atomic Clock with Wireless Outdoor Temperature and Weather Forecast. Covers setup, features, settings, troubleshooting, and specifications for accurate timekeeping and environmental monitoring.</p>
	<p><u>Van Maerlantlyceum Schoolgids 2025-2026</u></p> <p>Officiële schoolgids voor het Van Maerlantlyceum in Eindhoven voor het schooljaar 2025-2026, met informatie over onderwijs, begeleiding, veiligheid, financiën en meer.</p>
	<p><u>Examenreglement Van Maerlantlyceum 2025-2026</u></p> <p>Dit document bevat het examenreglement van Van Maerlantlyceum voor het schooljaar 2025-2026, met details over schoolexamens, centrale examens, procedures en richtlijnen voor leerlingen.</p>