

- [Manuals.plus](#) /
- › [Digiroot](#) /
 - › DIGIROOT KC2 Stylus Pen for iPad User Manual

Digiroot KC2

DIGIROOT KC2 Stylus Pen for iPad User Manual

Model: KC2

INTRODUCTION

Thank you for choosing the DIGIROOT KC2 Stylus Pen. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your stylus pen. The KC2 features a dual-tip design, palm rejection, tilt sensitivity, and fast charging, enhancing your iPad experience for writing, drawing, and navigation.



Image: The DIGIROOT KC2 Stylus Pen, showcasing its sleek black design.

PACKAGE CONTENTS

Upon opening your DIGIROOT KC2 Stylus Pen package, please ensure all the following items are included:

- 1 x DIGIROOT KC2 Stylus Pen
- 3 x Stylus Replaceable Tips (Fine Tip)
- 3 x Rubber Replaceable Tips
- 1 x Dust Plug
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

Compatible with 2018-2025 iPad



iPad Pro 12.9" (3rd/4th/5th/6th)	iPad Pro 11" (1st/2nd/3rd/4th/M4)	iPad Air(3rd/ 4th/5th/M2/M3)	iPad(11th/10th/ 9th/8th/7th/6th)	iPad Mini (5th/6th)
A1876/A2014 A1895/A1983 A2229/A2069 A2232/A2233 A2378/A2461 A2379/A2462 A2436/A2764 A2437/A2766	A1980/A2013 A1934/A1979 A2228/A2068 A2230/A2231 A2377/A2459 A2301/A2460 A2759/A2435 A2761/A2762 A2836/A2837	A2589/A2591 A2324/A2072 A2325/A2316 A2152/A2123 A2153/A2154 A2588/A2898 A2899/A2902 A2903/A3268 A3269/A3271 A3266/A3267 A3270	A1893/A1954 A2197/A2200 A2198/A2270 A2428/A2429 A2430/A2602 A2604/A2603 A2605/A2696 A2757/A2777 A3354/A3355 A3365	A2133/A2124 A2126/A2125 A2567/A2568 A2569 For iPad Pro 13" (M4) A2925/A2926

Image: All items included in the DIGIROOT KC2 Stylus Pen package.

SETUP

1. Compatibility Check

The DIGIROOT KC2 Stylus Pen is compatible with specific iPad models released between 2018 and 2024. Before use, please verify your iPad model number.

To find your iPad model number: Go to **Settings > General > About > Model Number**.

Compatible iPad Models:

- iPad 10th/9th/8th/7th/6th Generation
- iPad Air 3rd/4th/5th Generation (M2)
- iPad Pro 11-inch (2nd/3rd/4th Generation)
- iPad Pro 12.9-inch (3rd/4th/5th/6th Generation)
- iPad Pro 13-inch (M4)
- iPad Mini 5th/6th Generation



Upgraded Dual-Tip Stylus Pen for iPad

13 Mins
Charging Time

9 Hours
Working Time



 Press Button to Use

 No Bluetooth needed

Image: Detailed compatibility list for iPad models.

2. Charging the Stylus Pen

Before initial use, fully charge your stylus pen.

1. Connect the provided Type-C charging cable to the charging port on the stylus pen.
2. Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
3. The LED indicators will show charging progress. A full charge takes approximately 13 minutes, providing 9-10 hours of continuous use.




Image: Stylus pen connected to a Type-C charging cable, illustrating charging time and battery level indicators.

3. Powering On/Off


The DIGIROOT KC2 Stylus Pen is designed for ease of use without Bluetooth pairing.

- To turn on: **Single press** the side button.
- To turn off: **Single press** the side button again.

The pen will automatically shut down after 10 minutes of inactivity to conserve power.

Fine Tip Design

offer you smooth and pixel-perfect precision and tilt writing and drawing experience on the iPad



Rubber Tip Design

can operate on any capacitive touchscreen, and serve as a backup when your stylus pen runs out of power




Image: Instructions for powering on the stylus pen with a single button press.

OPERATING INSTRUCTIONS

1. Dual-Tip Design

The stylus features two distinct tips for versatile use:

- **Precision Fine Tip:** Located at the primary end, this tip offers pixel-perfect precision for writing, drawing, and detailed tasks on your iPad.
- **Rubber Tip:** Located at the opposite end, this tip can be used on any touchscreen device and serves as a backup if the fine tip runs out of power or is not suitable for a specific task.



Image: Illustration of the fine tip and rubber tip, highlighting their functions.

2. Palm Rejection

The stylus supports palm rejection, allowing you to rest your hand naturally on the iPad screen while writing or drawing without causing unintended marks. This feature enhances comfort and precision.




Image: Demonstration of palm rejection technology in action.

3. Tilt Sensitivity

The DIGIROOT KC2 Stylus Pen features tilt sensitivity, allowing you to vary line thickness and shading by changing the angle at which you hold the pen. This is particularly useful for artistic applications and note-taking.

- **90° Angle:** Ideal for precise writing and annotations.
- **60° Angle:** Suitable for drawing and coloring with smooth, consistent lines.
- **30° Angle:** Best for sketching and creating thicker lines or shading effects.



Image: Visual guide to tilt sensitivity at different angles.

4. Magnetic Attachment

The stylus pen can magnetically attach to the side of compatible iPad models for convenient storage and access. This magnetic attraction is designed to be strong and secure.

Note: This feature provides magnetic attachment only and does not support wireless charging.

5. Battery Level Indicators

The stylus pen features three LED indicators to display the remaining battery life:

- **Three Lights On:** 60% - 100% power (approximately 9 hours of use remaining).
- **Two Lights On:** 20% - 59% power (approximately 4 hours of use remaining).
- **One Light On:** Less than 20% power (approximately 0.5 hours of use remaining).

Monitor these indicators to know when to recharge your stylus.

MAINTENANCE

1. Replacing Tips

The stylus comes with replaceable fine tips and rubber tips. If a tip becomes worn or damaged, follow these steps to replace it:

1. Gently twist the old tip counter-clockwise to remove it.
2. Align the new tip with the stylus and twist clockwise until it is securely fastened.
3. Do not overtighten.

Refer to the "Dual-Tip Design" image in the Operating Instructions section for a visual guide on tip replacement.

2. Cleaning

To clean your stylus pen, gently wipe the body with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the pen's finish or internal components.

TROUBLESHOOTING

Problem: Stylus does not work after turning on.

Solution: Ensure your iPad's Bluetooth is turned off. The DIGIROOT KC2 Stylus Pen does not require Bluetooth

pairing and can conflict with previously paired Apple Pencils or other Bluetooth styluses.
To turn off Bluetooth: Go to **Settings > Bluetooth > Toggle Bluetooth Off**.

Problem: Stylus is unresponsive or has lag.

- **Solution 1:** Check the battery level. Recharge the stylus if the battery is low.
- **Solution 2:** Ensure the tip is securely fastened. Replace the tip if it appears worn or damaged.
- **Solution 3:** Restart your iPad and the stylus pen.

Problem: Palm rejection is not working correctly.

- **Solution 1:** Ensure your iPad model is listed as compatible.
- **Solution 2:** Close and reopen the application you are using.

SPECIFICATIONS

Model Number	KC2
Brand	Digiroot
Color	Black
Material	Conductive Material
Item Weight	0.09 Kilograms
Item Dimensions	16 x 1.6 x 1.4 Centimeters
Battery Type	1 Lithium Polymer battery (included)
Battery Average Life (Standby)	10 Hours
Charging Time	Approx. 13 minutes for full charge
Continuous Use Time	9-10 hours
Auto Shut-off	After 10 minutes of inactivity
Compatible Devices	iPad (2018-2024 models)
Country of Origin	China

WARRANTY

The DIGIROOT KC2 Stylus Pen comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, please refer to the official DIGIROOT website or contact customer support.

SUPPORT

For any questions, technical assistance, or support regarding your DIGIROOT KC2 Stylus Pen, please contact our customer service team:

- **Email:** sales@digirootlife.com
- **Manufacturer:** DIGIROOT

Our support team is available to assist you with any inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question