

Manuals.plus /
› Kitstorack /
› Kitstorack Pull Out Cabinet Organizer Instruction Manual (21"D x 12"-20"W)

Kitstorack Pull out Cabinet Organizer

Kitstorack Pull Out Cabinet Organizer Instruction Manual

Model: Pull out Cabinet Organizer (21"D x 12"-20"W)
Brand: Kitstorack

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Kitstorack Pull Out Cabinet Organizer. Designed for efficient kitchen and pantry organization, this expandable drawer system offers easy access to your items, enhancing convenience and maximizing storage space.

PRODUCT OVERVIEW

The Kitstorack Pull Out Cabinet Organizer is engineered for durability and ease of use. Key features include:

- **Expandable Design:** The rack adjusts from 12 inches to 20 inches in width to fit various cabinet sizes.
- **Heavy-Duty Construction:** Made from thickened carbon steel with a rust-resistant coating, ensuring long-lasting durability and a strong load capacity of up to 50 pounds.
- **Full Extension 3-Rail System:** Provides smooth, silent, and wobble-free sliding, allowing full access to cabinet contents. Tested for over 40,000 cycles.
- **Riser Pads:** Included for compatibility with both framed and frameless cabinets, accommodating frame edges up to 0.8 inches.
- **Installation Options:** Offers both adhesive nano film for drill-free installation and screws for permanent securing.



Effortless Access No More Bending or Kneeling!


Reaching into cabinets
shouldn't require discomfort
or strain



Figure 1: Effortless access to cabinet contents with the pull-out organizer.

Improved Full-pull Rails

Access all your cabinet contents effortlessly



Sturdy, Smooth Glide

Built to last with full extension

Kitstorack



Figure 2: Illustration of the improved full-extension 3-rail system for smooth operation.

Stronger Load Capacity

Made to handle your heaviest needs



Figure 3: The organizer's strong load capacity, capable of holding heavy items.



Figure 4: Construction details of the rust-resistant and thickened steel material.

SPECIFICATIONS


Feature	Detail
Specific Uses	Cabinet Organizer
Material	Thickened Carbon Steel
Special Features	Expandable, Full-Extension 3-Rails, Reliable Grip-Wider, Thickened Nano Films, Strong Weight Capacity, Thickened Carbon Steel
Color	White
Brand	Kitstorack

Feature	Detail
Mounting Type	Insert Mount
Product Dimensions (D x W x H)	21"D x 12"-20"W x 2.8"H (Expandable Width)
Item Weight	6.46 kg
Maximum Weight Recommendation	50 pounds
Number of Items	2 (for 2-pack)

Note

Don't forget to account for:
Hinges, plumbing, other obstructions



Please Measure Your Cabinet Before Ordered



Minimum Cabinet Opening (MCO): $\geq 13"$

Product Width (W): 12"-20"

Minimum Cabinet Depth (D): $\geq 22"$



SPECIFICATIONS

Figure 5: Detailed product and cabinet measurement guide.



Figure 6: Cabinet measurement and size selection guide for 12-20 inch wide organizers.

INSTALLATION GUIDE

Follow these steps for proper installation of your Kitstorack Pull Out Cabinet Organizer. Ensure your cabinet dimensions meet the product specifications before beginning.

Step 1: Measure Your Cabinet

Carefully measure the width and depth of your cabinet opening. Remember to account for any obstructions such as hinges, plumbing, or cabinet door edges. The minimum cabinet opening (MCO) should be at least 13 inches, and the minimum cabinet depth (D) should be at least 22 inches for this model.

Step 2: Prepare the Surface


Clean the cabinet surface where the organizer will be installed. Ensure it is dry and free of dust or grease for optimal adhesive performance.

Step 3: Adjust Width and Apply Riser Pads (if needed)

Adjust the organizer to the desired width. If installing in a framed cabinet with an edge height up to 0.8 inches, attach the provided riser pads to the bottom of the organizer's rails. These pads ensure proper clearance and smooth operation.

! Upgraded Raised Pad Design

Compatible with frameless cabinet & framed cabinets (lip heights up to 0.8 inches)



Compatible with frameless cabinets



Compatible with framed cabinets

Figure 7: Riser pads for framed and frameless cabinet compatibility.

Step 4: Choose Installation Method (Adhesive or Screws)

You have two options for securing the organizer:


- **Adhesive Nano Film (Drill-Free):** For quick and easy installation without drilling. The nano film provides a strong, firm grip. Ensure precise placement as the adhesive is very strong.
- **Screws (Provided):** For a more permanent and heavy-duty installation. Screws are included in the package.

Nano Glue & Screws Installation

Both options are at your disposal



Nano Glue Sticks Firmly:
Nail-free Installation+
No Need Drill Holes



Secured with Screws
(Provided)

Figure 8: Nano glue and screw installation options.

Step 5: Secure the Organizer

For Adhesive Installation: Remove the protective backing from the nano film. Carefully align the organizer within your cabinet and press firmly to secure it. Once placed, it is difficult to reposition due to the strong adhesive.

For Screw Installation: Mark the screw holes through the rails onto the cabinet surface. Pre-drill pilot holes if necessary. Secure the rails with the provided screws.

Installation Video Guide

Your browser does not support the video tag.

Video 1: Official Kitstorack installation guide for expandable drawer organizers. This video demonstrates the step-by-step process of installing the pull-out cabinet organizer, including how to secure the rails and adjust the drawer.

OPERATING INSTRUCTIONS

Using your Kitstorack Pull Out Cabinet Organizer is straightforward:

1. **Loading Items:** Place your pots, pans, small appliances, cleaning products, canned goods, or other items directly onto the organizer. Distribute weight evenly for optimal performance.
2. **Accessing Items:** Gently pull the organizer forward to extend it out of the cabinet. The full-extension rails allow for complete access to all items, even those at the back.
3. **Retracting:** Push the organizer back into the cabinet until it is fully closed. The smooth glide system ensures easy retraction.

Use in Multiple Scenarios



Figure 9: Examples of the organizer's versatile use in multiple scenarios.



Figure 10: The expandable pull-out cabinet organizer in use, maximizing kitchen and pantry storage.

MAINTENANCE

To ensure the longevity and smooth operation of your cabinet organizer, follow these maintenance tips:

- **Cleaning:** The organizer can be easily detached for cleaning. Pull the drawer out fully, then turn the bottom strip to release it from the rails. Clean with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Lubrication:** Periodically check the rails for smooth operation. If needed, apply a small amount of silicone-based lubricant to the sliding mechanisms.
- **Inspection:** Regularly inspect the adhesive or screws to ensure they remain securely fastened.

TROUBLESHOOTING

If you encounter any issues with your Kitstorrack Pull Out Cabinet Organizer, refer to the following common solutions:

Problem	Possible Cause	Solution
Organizer does not slide smoothly or gets stuck.	◦ Uneven installation. ◦ Rails are dirty or lack lubrication. ◦ Overloaded with excessive weight. ◦ Obstructions in the cabinet.	◦ Re-check installation for levelness and proper alignment. ◦ Clean rails and apply silicone lubricant. ◦ Reduce the weight of items in the organizer (max 50 lbs). ◦ Ensure no items or cabinet features are blocking the slide path.
Adhesive is not holding firmly.	◦ Surface was not clean or dry during installation. ◦ Insufficient pressure applied during installation. ◦ Adhesive applied to an unsuitable surface (e.g., rough, porous).	◦ Ensure surface is thoroughly cleaned with alcohol and dried before applying adhesive. ◦ Apply firm, even pressure for several seconds during installation. ◦ Consider using the provided screws for a more secure, permanent installation, especially for heavier loads or uneven surfaces.

Problem	Possible Cause	Solution
Organizer width does not fit cabinet.	◦ Incorrect measurement before purchase. ◦ Not fully expanded/contracted to fit.	◦ Verify cabinet dimensions against product specifications. ◦ Adjust the expandable width of the organizer to match your cabinet opening.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Kitstorack customer service directly. Refer to the product packaging or the Kitstorack official website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DNVR6BSW>

More documents and user manuals: <https://manuals.plus/>