Fumoi M4

Fumoi Self-Cleaning Litter Box M4 User Manual

Model: M4

Introduction

Thank you for choosing the Fumoi Self-Cleaning Litter Box M4. This automatic litter box is designed to provide a clean and convenient solution for cat owners, featuring advanced safety sensors, large capacity, and smart app integration. Please read this manual thoroughly before setup and operation to ensure optimal performance and safety for your pet.



Image: The Fumoi Self-Cleaning Litter Box M4, a sleek, modern automatic litter box.

Safety Information

Your pet's safety is our top priority. Please adhere to the following safety guidelines:

- **Infrared Motion Sensors:** The unit is equipped with infrared motion sensors that immediately pause cleaning cycles if a cat is detected entering or approaching the litter box.
- **Weight Sensors:** Integrated weight sensors detect your cat's presence, preventing operation while the cat is inside.
- **Anti-Pinch Design:** The design minimizes pinch points to protect curious paws.
- **Stable Placement:** Always place the litter box on a flat, stable surface to prevent tipping.
- **Children and Pets:** Keep children and small pets away from the unit during operation.
- **Power Supply:** Use only the provided power adapter. Disconnect power before cleaning or maintenance.



Image: Diagram illustrating the multiple safety sensors (Radar, Infrared, Weight) integrated into the Fumoi Self-Cleaning Litter Box for pet protection.

Package Contents

Verify that all items are present in your package:

- Fumoi Self-Cleaning Litter Box Unit
- Waste Collection Tray
- Washable Liner
- Power Adapter
- Garbage Bags (2 rolls)
- User Manual (this document)

Setup

1. **Unboxing:** Carefully remove all components from the packaging.
2. **Placement:** Place the main unit on a firm, level surface in a suitable location, ensuring adequate space around it for access and ventilation.
3. **Install Waste Tray:** Slide the waste collection tray into the designated slot at the bottom front of the unit.
4. **Insert Liner:** Place the washable liner inside the litter drum.
5. **Add Litter:** Fill the litter drum with clumping or silica-based cat litter. Ensure the litter level is between the MIN and MAX lines indicated inside the drum. *Avoid fine-grained litter as it may stick to the hopper.*
6. **Connect Power:** Plug the power adapter into the unit and then into a wall outlet. The unit will perform an initial calibration cycle.



Image: Visual representation of the Fumoi Litter Box dimensions and the removable waste tray, highlighting its large capacity.

App Integration

The Fumoi M4 offers smart control via a dedicated mobile application. This allows for remote monitoring and control of the litter box.

- **Download App:** Scan the QR code on the unit or search for the "Fumoi Smart" app in your device's app store.
- **Connect to Wi-Fi:** Ensure your home Wi-Fi network is 2.4G. Follow the in-app instructions to connect the litter box to your network.
- **Features:**
    - Control auto-cleaning cycles.
    - Schedule waste disposal.
    - Track litter usage and cat activity.
    - Receive real-time alerts for full bins or operational issues.
    - Adjust settings such as night mode and cleaning delays.



Image: Screenshot of the Fumoi app interface showing remote control options and operation logs for the litter box.

Operating Modes

The Fumoi M4 offers both automatic and manual operation:

- **Automatic Mode:** After initial setup, the unit will automatically detect when your cat uses the litter box and initiate a cleaning cycle after a set delay (adjustable via app).
- **Manual Mode:** You can manually trigger cleaning or emptying cycles using the buttons on the unit or through the app.
    - **Wi-Fi Connection Button:** Press for 3 seconds to hear a "beep" sound, indicating readiness to connect to Wi-Fi.
    - **Empty Litter Button:** Press for 3 seconds to hear a "beep" sound, initiating the litter emptying process.
    - **Clean Litter Button:** Press for 1 second to hear a "beep" sound, starting the cleaning cycle.




Image: Close-up of the Fumoi Litter Box control panel, showing the Wi-Fi, Empty, and Clean buttons for manual operation.

Maintenance & Cleaning

Regular maintenance ensures optimal performance and hygiene:

- **Waste Tray Emptying:** The 15L sealed waste compartment can hold waste for up to 15 days for one cat. Empty the waste bag when the app indicates it's full or when visually necessary. Simply pull out the tray, tie the bag, and dispose.
- **Washable Liner:** The internal liner is removable and washable for thorough cleaning. This reduces long-term costs and waste.
- **Drum Cleaning:** Periodically clean the interior of the litter drum. Disconnect power before cleaning.
- **Litter Type:** Compatible with clumping and silica-based litters. For best results and to prevent sticking, avoid very fine-grained litter.



Image: Illustration showing the compatibility of the Fumoi Litter Box with various litter types, including mixed, mineral, and bentonite.

Troubleshooting

If you encounter issues, refer to the following common solutions:

Problem	Possible Cause	Solution
Unit not cleaning	Cat detected, waste bin full, litter level incorrect, Wi-Fi issue.	Check for cat presence, empty waste bin, adjust litter level, verify Wi-Fi connection (2.4G).
Litter sticking to drum/hopper	Litter type too fine, high humidity.	Switch to a coarser clumping litter, ensure unit is in a dry area.
App connectivity issues	Incorrect Wi-Fi band, weak signal.	Confirm 2.4G Wi-Fi, move unit closer to router, restart unit and app.
Unresponsive unit	Temporary software glitch, full waste bin.	Unplug and replug the power cable to reset. Empty waste bin if full.

Specifications

- **Model:** M4
- **Dimensions (LxWxH):** 21.6 x 19.6 x 25.8 inches
- **Item Weight:** 33 pounds
- **Litter Drum Capacity:** 95L
- **Waste Compartment Capacity:** 15L
- **Noise Level:** ≤ 33dB (Whisper-quiet)
- **Connectivity:** Wi-Fi 2.4G (App-controlled)
- **Safety Features:** Infrared motion sensors, Weight sensors, Anti-pinch design
- **Compatible Litter:** Clumping, Silica-based



Image: The Fumoi Litter Box operating with low noise (≤ 33dB), ensuring minimal disturbance for both pets and owners.

Warranty & Support

Fumoi is committed to your satisfaction. For any questions or support needs, please contact us:

- **Warranty:** Please refer to the product packaging or the official Fumoi website for detailed warranty information.
- **Customer Support:** If you have any questions or require assistance, please reach out to Fumoi Direct. Response is typically within 24 hours.
- **Online Resources:** Visit the Fumoi Store on Amazon for additional product information and FAQs.

Image: The official Fumoi brand logo.

© 2025 Fumoi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What does the reset button do on the Fumoi M4 Self-Cleaning Litter Box?

Based on the Fumoi M4 manual, there is no single button labeled "Reset." Instead, the device uses specific buttons for different functions and a manual power cycle for a full system reset:To Reset the...

Read full answer