Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VIBOOS VIBOOS 24x12

VIBOOS Electric Heating Pad Instruction Manual

Model: VIBOOS 24x12 | Brand: VIBOOS

1. Introduction

Thank you for choosing the VIBOOS Electric Heating Pad. This device is designed to provide soothing heat therapy for various body parts, including the back, neck, shoulders, knees, abdomen, arms, and legs. Please read this manual thoroughly before use to ensure safe and effective operation.



Image: The VIBOOS Electric Heating Pad in Silver Gray, showing its soft quilted surface and attached controller.

2. Important Safety Information

Failure to follow these safety instructions may result in fire, electric shock, or injury.

- **DO NOT** let other objects (e.g., blankets, pillows, or your body) cover the heating pad during use.
- **DO NOT** use while sleeping.
- **DO NOT** use for children.
- **DO NOT** fold the heating pad when it is in operation.
- **DO NOT** use the heating pad pressed under the body.
- **DO NOT** dry or iron the heating pad.
- Never put the pad in a tumble dryer.
- Make sure that the product and the plug are completely dry before connecting the device.
- Do not use the pad if signs of damage are evident.



Image: Close-up of the heating pad material with a graphic indicating warm tips about not covering the pad during use.

3. Package Contents

Your VIBOOS Electric Heating Pad package should include:

- 1 x VIBOOS Electric Heating Pad (24"×12")
- 1 x Controller with Power Cord
- 1 x User Manual

4. Product Features

- **6 Temperature Levels:** Customize your heat therapy with settings ranging from 104°F (40°C) to 140°F (60°C).
- **4 Timer Functions:** Set the pad to automatically turn off after 30, 60, 90, or 120 minutes to conserve energy and prevent overheating.
- **Soft Flannel Material:** Made from premium, super soft flannel for enhanced comfort and better insulation.
- **Machine Washable:** The pad is easy to clean; simply disconnect the cable and machine wash below 86°F/30°C.
- **Versatile Use:** Suitable for various body parts including back, neck, shoulder, knee, abdomen, legs, and arms.



Image: A woman relaxing with the heating pad, highlighting its key features.

5. Setup

1. Ensure the heating pad is clean and dry before first use.
2. Connect the power cord to the heating pad securely. The connector is designed for easy attachment and detachment.
3. Plug the power cord into a standard electrical outlet.



Image: Illustration of connecting the detachable power cord to the heating pad.

6. Operating Instructions

The heating pad is controlled via a handheld unit with clear buttons and indicators.

1. **Power On/Off:** Use the ON/OFF switch on the controller to turn the device on or off. The heating LED will illuminate when powered on.
2. **Adjust Heat Settings:** Press the 'HEAT' button to cycle through the 6 temperature levels (1 to 6). The corresponding LED will indicate the selected heat level.
3. **Set Timer:** Press the 'TIMER' button to select an automatic shut-off time: 30, 60, 90, or 120 minutes. The timing LED will show the active timer setting.
4. The device will automatically shut off once the selected timer duration is complete.



Image: Close-up of the handheld controller, detailing the heat and timer settings.



Image: Visual representation of the 6 temperature levels and their corresponding Fahrenheit/Celsius values.

7. Maintenance and Cleaning

To ensure the longevity and hygiene of your heating pad:

- **Disconnect:** Always disconnect the power cord from the pad and the wall outlet before cleaning.
- **Washing:** The heating pad is machine washable. Wash below 86°F (30°C) on a gentle cycle. You may place it in a laundry bag for protection.
- **Spot Cleaning:** If only a part of the heating pad gets dirty, wipe it with a damp cloth to minimize washing and prolong its service life.
- **Drying:** Hang to air dry naturally. **DO NOT** use a dryer, dry clean, or iron the heating pad. Ensure it is completely dry before next use.



Image: Step-by-step guide for machine washing the heating pad.

8. Troubleshooting

If you encounter issues with your heating pad, please refer to the following common solutions:

- **Pad not heating or blinking lights:**
  - Ensure the power cord is securely connected to both the pad and the wall outlet.
  - Verify the ON/OFF switch on the controller is in the 'ON' position.
  - Check if the heat setting is selected (LEDs 1-6 should be illuminated).
  - Unplug the device for a few minutes and then plug it back in to reset.
- **Inconsistent heat:** Ensure the pad is not folded or bunched up during use, as this can affect heat distribution.
- **Pad feels too hot/cold:** Adjust the heat setting using the 'HEAT' button on the controller to find your preferred temperature.

If the problem persists after trying these steps, please contact customer support.

9. Specifications

Feature	Detail
Model	VIBOOS 24x12
Dimensions	24 inches × 12 inches
Material	Flannel
Heat Settings	6 levels (104°F/40°C to 140°F/60°C)
Timer Settings	30, 60, 90, 120 minutes (Auto Shut-Off)
Power Cord Length	Approximately 72.83 inches (185 cm)
Care Instructions	Machine washable (below 86°F/30°C), air dry only




Image: Dimensions of the heating pad and its power cord.

10. Warranty and Support

Your satisfaction is important to us. If you encounter any problems with your VIBOOS Electric Heating Pad, please contact us through your Amazon Order. We are committed to resolving any issues and ensuring your satisfaction.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

© 2025 VIBOOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNYZ6QCG

More documents and user manuals: **https://manuals.plus/**