

FROVOL FROVOL-541555-13

Nerunsa P66D Smartwatch Protective Case User Manual

Brand: FROVOL | **Model:** FROVOL-541555-13

1. INTRODUCTION

This user manual provides essential information for the installation, use, and maintenance of your FROVOL Protective Case for the Nerunsa P66D Smartwatch. This case is designed to offer comprehensive protection against scratches, collisions, and daily wear, extending the lifespan and preserving the aesthetic of your smartwatch.

2. PRODUCT OVERVIEW

The FROVOL Protective Case is crafted from a combination of durable PC (Polycarbonate) and tempered glass, ensuring robust protection while maintaining the original look and functionality of your Nerunsa P66D smartwatch.

Key Features:

- **Comprehensive Protection:** Effectively shields the smartwatch casing and screen from scratches, impacts, and daily wear.
- **Durable Materials:** Made from wear-resistant and scratch-resistant PC and tempered glass for long-lasting performance.
- **High Transparency:** The tempered glass screen protector maintains the original display effect and touch sensitivity of the smartwatch.
- **Slim and Lightweight Design:** Adds minimal bulk and weight to your smartwatch, ensuring comfortable daily wear.
- **Anti-Fingerprint:** Helps prevent fingerprints and smudges, keeping your smartwatch clean.
- **Precise Cutouts:** Ensures easy access to all buttons and sensors without removing the case.

Available Colors:

The protective case is available in various colors including Pink, Black, Blue, Green, White, and Transparent.



Figure 2.1: Assortment of protective cases in different colors.

3. INSTALLATION GUIDE (SETUP)

Follow these steps to correctly install the FROVOL Protective Case onto your Nerunsa P66D Smartwatch:

1. **Prepare Your Smartwatch:** Ensure your Nerunsa P66D smartwatch is clean and free of dust or smudges. Gently wipe the screen and body with a soft, lint-free cloth.
2. **Align the Case:** Carefully align the protective case with your smartwatch. The case is designed with precise cutouts for buttons, sensors, and the charging port.
3. **Snap into Place:** Gently press the smartwatch into the case, ensuring all edges snap securely into place.

Start by inserting one side of the smartwatch into the case, then gently push the other side until it clicks.

4. **Check Fit:** Once installed, ensure the case fits snugly around your smartwatch without any gaps. Verify that all buttons are accessible and the screen's touch sensitivity is unaffected.



Figure 3.1: Installation steps for the protective case.



Figure 3.2: Alternative view of the installation process.

4. USAGE (OPERATING)

Once installed, the FROVOL Protective Case allows for normal operation of your Nerunsa P66D Smartwatch. The integrated tempered glass screen protector ensures that the display's clarity and touch sensitivity are not compromised. All smartwatch functions, including button presses and sensor readings, remain fully accessible through the precise cutouts.



Figure 4.1: Smartwatch with black protective case installed.



Figure 4.2: Smartwatch with beige protective case installed.

5. CARE AND MAINTENANCE

To ensure the longevity and maintain the clear appearance of your FROVOL Protective Case, follow these simple care instructions:

- **Cleaning:** Regularly wipe the case with a soft, damp cloth to remove dust, fingerprints, and smudges. Avoid using harsh chemicals or abrasive materials, as these can damage the PC or tempered glass.
- **Avoid Extreme Conditions:** While the case is durable, avoid exposing it to extreme temperatures or direct sunlight for prolonged periods, which could affect its material integrity.

- **Proper Handling:** When removing or installing the case, do so gently to prevent undue stress on the materials.

6. TROUBLESHOOTING

If you encounter any issues with your FROVOL Protective Case, consider the following common solutions:

- **Reduced Touch Sensitivity:**
Ensure the case is installed correctly and there is no dust or debris trapped between the smartwatch screen and the case's tempered glass. Remove the case, clean both surfaces, and re-install.
- **Case Not Fitting Snugly:**
Double-check that you have the correct model case for your Nerunsa P66D smartwatch. Ensure all edges are properly aligned and snapped into place during installation.
- **Scratches or Damage to Case:**
While designed to be scratch-resistant, extreme impacts or abrasive materials can still cause damage. If the case is significantly damaged, it is recommended to replace it to ensure continued protection for your smartwatch.

7. SPECIFICATIONS

Feature	Detail
Product Name	Watch Protective Case
Brand	FROVOL
Model Number	FROVOL-541555-13
Applicable Model	Nerunsa P66D Smartwatch
Material	PC (Polycarbonate) + Tempered Glass
Product Weight	15 g (Gross Weight)
Available Colors	Black, Blue, Green, White, Pink, Transparent

8. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in this manual. Please refer to the product packaging or the retailer's website for details regarding warranty coverage and customer support. For any issues or inquiries not covered in this manual, please contact FROVOL customer service or your point of purchase.

