Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC Power Cord

onerbl AC Power Cord Replacement for AXV FR78 Vibration Plate Exercise Machine Instruction Manual

Essential Guide for Safe and Effective Use

1. Introduction

This instruction manual provides essential information for the safe and effective use of your onerbl AC Power Cord Replacement. This power cord is specifically designed as a compatible replacement for the AXV FR78 Slim Boat Vibration Plate Exercise Machine and similar models. Please read this manual thoroughly before use to ensure proper connection and operation.

2. Product Overview

The onerbl AC Power Cord is a durable, black, female-to-male power cable designed to supply 120 Volts (AC) to compatible exercise equipment. It features a standard NEMA 5-15P plug for wall outlets and an IEC C13 connector for the device input.



Image 1: The onerbl AC Power Cord. This image displays the black power cord coiled, showing both the standard two-prong wall plug (NEMA 5-15P) and the IEC C13 connector, which is typically used for connecting to electronic devices.

Compatibility: This power cord is compatible with the following models:

- AXV FR78 SLIM-GREEN Vibration Plate Exercise Machine
- AXV FR78 SLIM-BLACK Vibration Plate Exercise Machine

- AXV FR78 SLIM-GRAY Vibration Plate Exercise Machine
- AXV FR78 SLIM-BLUE Vibration Plate Exercise Machine
- AXV FR78 BOAT-BLUE Vibration Plate Exercise Machine
- AXV FR78 BOAT-GRAY Vibration Plate Exercise Machine
- Other devices requiring a 120V AC input with an IEC C13 power inlet.

3. Setup

1. **Inspect the Cord:** Before connecting, visually inspect the power cord for any signs of damage, such as cuts, frayed wires, or bent prongs. Do not use a damaged cord.
2. **Identify Device Input:** Locate the power input port on your AXV FR78 Vibration Plate Exercise Machine. This port is typically a three-pin receptacle designed to accept an IEC C13 connector.
3. **Connect to Device:** Firmly insert the IEC C13 (female) end of the power cord into the power input port of your exercise machine. Ensure it is fully seated.
4. **Connect to Power Outlet:** Plug the NEMA 5-15P (male) end of the power cord into a standard 120V AC wall outlet. Ensure the outlet is easily accessible and not overloaded.
5. **Verify Connection:** Confirm that both ends of the power cord are securely connected before attempting to power on your exercise machine.

4. Operating Instructions

Once the onerbl AC Power Cord is correctly connected to both your AXV FR78 Vibration Plate Exercise Machine and a live 120V AC power outlet, the machine is ready to receive power. You can then proceed to operate your exercise machine according to its own instruction manual.
Note: This power cord is a power supply component and does not have operational controls itself. Its function is to deliver electrical power to the connected device.

5. Maintenance

- **Regular Inspection:** Periodically inspect the power cord for any signs of wear, damage, or overheating.
- **Cleaning:** If necessary, gently wipe the cord with a dry, soft cloth. Do not use liquid cleaners or immerse the cord in water.
- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cord sharply, as this can damage the internal wires.
- **Safety:** Always unplug the cord from the wall outlet before performing any maintenance on the connected device or the cord itself.

6. Troubleshooting

If your AXV FR78 Vibration Plate Exercise Machine does not power on after connecting the onerbl AC Power Cord, consider the following:

- **No Power:**
  - Ensure both ends of the power cord are fully and securely plugged in.
  - Check if the wall outlet is functional by plugging in another device.

- Verify that the circuit breaker for the outlet has not tripped.
- Inspect the power cord for visible damage. If damaged, replace it immediately.

- **Loose Connection:**
  - Unplug and re-plug both ends of the power cord to ensure a firm connection.
- **Device Specific Issues:**
  - If the power cord appears functional, consult the instruction manual for your AXV FR78 Vibration Plate Exercise Machine for device-specific troubleshooting steps.

7. Specifications

Feature	Detail
Brand	onerbl
Color	Black
Connector Gender	Female-to-Male
Voltage Input	120 Volts (AC)
Manufacturer	Shenzhen Waweis Technology Co., Ltd
ASIN	B0DNZ3FM8N

8. Warranty and Support

For information regarding warranty coverage or technical support for your onerbl AC Power Cord, please refer to the seller's policies or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.
Manufacturer: Shenzhen Waweis Technology Co., Ltd

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ3FM8N

More documents and user manuals: **https://manuals.plus/**