Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl USB Charging Cable

onerbl USB Charging Cable for FLYLINKTECH BD10 Jump Starter

Instruction Manual

Introduction

This manual provides essential instructions for the proper use, setup, and maintenance of your onerbl USB Charging Cable. This cable is specifically designed as a replacement power supply cord for the **FLYLINKTECH BD10 Portable Car Jump Starter with Air Compressor Lithium Polymer Battery**. Please read this manual thoroughly before using the product to ensure safe and efficient operation.



Image: The onerbl USB Charging Cable, designed for the FLYLINKTECH BD10 Jump Starter. This image displays the cable's overall design and connectors.

Setup

Follow these steps to properly connect your USB charging cable to the FLYLINKTECH BD10 Jump Starter and a power source.

1. **Identify Connectors:** The cable features a standard USB-A connector on one end and a USB-C connector on the other. The USB-A end typically connects to the power adapter, and the USB-C end connects to the jump starter.
2. **Connect to Power Source:** Insert the USB-A end of the charging cable into a compatible USB wall adapter (not included) or a USB port on a computer or car charger. Ensure the power source provides sufficient output for charging.
3. **Connect to Jump Starter:** Locate the USB-C charging port on your FLYLINKTECH BD10 Jump Starter. Carefully insert the USB-C end of the charging cable into this port.
4. **Verify Connection:** Ensure both ends of the cable are securely plugged in. A loose connection may prevent proper charging.

Operating

Once the cable is connected, the FLYLINKTECH BD10 Jump Starter should begin charging. Observe the jump starter's indicators for charging status.

- **Charging Indication:** The FLYLINKTECH BD10 Jump Starter typically has LED indicators that show the charging progress or battery level. Refer to your jump starter's manual for specific details on its charging indicators.
- **Charging Time:** Charging time will vary depending on the power output of your USB adapter and the current battery level of the jump starter.
- **Safety Precautions:**
  - Do not use the cable if it appears damaged or frayed.
  - Avoid exposing the cable to extreme temperatures or moisture.
  - Ensure the charging environment is well-ventilated.

Maintenance

Proper care of your charging cable will extend its lifespan and ensure reliable performance.

- **Cleaning:** Gently wipe the cable with a dry, soft cloth to remove dust or dirt. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply, as this can damage the internal wires.
- **Inspection:** Periodically inspect the cable and connectors for any signs of wear, cuts, or damage. Discontinue use if any damage is observed.

Troubleshooting

If you encounter issues while charging, try the following troubleshooting steps:

- **Jump Starter Not Charging:**
  - Ensure both the USB-A and USB-C connectors are fully inserted into their respective ports.
  - Try a different USB wall adapter or power source to rule out an issue with the power supply.
  - Check the USB-C port on the FLYLINKTECH BD10 Jump Starter for any debris or damage.
  - Test the cable with another compatible device (if available) to confirm the cable's functionality.
- **Slow Charging:**
  - Ensure your USB wall adapter provides adequate power output (e.g., 5V/2A or higher for faster charging). Lower output adapters will result in slower charging times.
  - Avoid charging through unpowered USB hubs or older computer USB ports, which may provide insufficient power.

Specifications

Brand:	onerbl
Connector Type:	USB-A to USB-C
Cable Type:	USB

Compatible Devices:	FLYLINKTECH BD10 Jump Starter Portable Car Jump Starter with Air Compressor Lithium Polymer Battery
Special Feature:	Fast Charging
Color:	Black
Manufacturer:	Shenzhen Waweis Technology Co., Ltd

Warranty and Support

For warranty information or technical support regarding your onerbl USB Charging Cable, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase for any warranty claims.
For support related to the FLYLINKTECH BD10 Jump Starter itself, please consult the manual provided with that device or contact its manufacturer.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ3ZLHQ

More documents and user manuals: **https://manuals.plus/**