

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Ikarao](#) /

› [Ikarao Karaoke Machine Shell S1 -280W User Manual](#)

Ikarao Shell S1

Ikarao Karaoke Machine Shell S1 -280W User Manual

WELCOME

Thank you for choosing the Ikarao Karaoke Machine Shell S1 -280W. This manual provides essential information for setting up, operating, and maintaining your new karaoke system. Please read it thoroughly before use to ensure optimal performance and longevity of your device.

WHAT'S INCLUDED

Carefully unpack your Ikarao Karaoke Machine Shell S1 -280W and ensure all items listed below are present:

- 1 * Shell S1 Smart Karaoke Machine
- 2 * Bluetooth Wireless Microphones
- 1 * Portable Shoulder Strap
- 1 * Type C Cable (Without Charger)
- User Manual

PRODUCT OVERVIEW

The Ikarao Karaoke Machine Shell S1 -280W is a versatile and powerful portable karaoke system designed for an immersive audio experience. It features a 10.1-inch screen for lyrics display, 2 wireless self-charging microphones, and multiple connectivity options.

More Powerful Soundstage

280W soundwaves, rhythm, emotion, body,
unable to resist resonating with the music.



2.75-Inch
Full-Range Speaker

DSP
Control

280W
Peak Power

4X
Detail

Figure 1: Ikaroo Karaoke Machine Shell S1 - Front View with Microphones and Screen.

Key Features

- **Premium Stereo Sound:** 280W 2.2-channel stereo sound with dual 3.5" woofers and dual 1" tweeters angled at 15°.
- **Wireless Self-Charging Microphones:** Two Bluetooth microphones with 8 adjustable EQ sound effects and autotune. Magnetic self-charging design.
- **Integrated 10.1" Screen:** Built-in screen for lyrics display, preloaded with KaraFun (6-month membership included) and YouTube compatibility via Wi-Fi.
- **Versatile Connectivity:** HDMI, USB, AUX, Wi-Fi 2.4G/5G, and Bluetooth 5.3. Screen mirroring to TV supported.
- **Portable Design:** All-in-one unit with a portable shoulder strap for easy transport.

SETUP GUIDE

1. Initial Power-Up and Charging

1. Connect the provided Type C cable to the charging port on the back of the karaoke machine.
2. Plug the other end of the cable into a compatible USB charger (not included).
3. Allow the device to fully charge before first use. The battery indicator on the screen will show charging status.
4. To power on, press and hold the power button located on the front panel. The 10.1" screen will light up.

2. Microphone Setup

1. Open the top lid of the karaoke machine to reveal the microphone charging slots.
2. Ensure the two wireless microphones are placed in their respective slots to charge. An indicator light on the microphone will show charging status.
3. To power on a microphone, press and hold its power button. It will automatically pair with the karaoke machine.

Free Karaoke Streaming

Unlimited free lyrics videos on **YouTube** with WiFi.
And enjoy karaoke on TV via HDMI.



Figure 2: Wireless Microphones in Self-Charging Slots.

3. Connectivity Options

The Shell S1 offers various ways to connect your audio and video sources:

- **Wi-Fi:** Connect to your home Wi-Fi network via the on-screen settings to access online content like YouTube and KaraFun.
- **Bluetooth 5.3:** Pair your smartphone or other Bluetooth-enabled devices to stream music wirelessly.
- **HDMI:** Use an HDMI cable to connect the karaoke machine to a larger TV screen for a theater-style experience.
- **USB:** Plug in a USB drive to play local media files (music or video).

- **AUX:** Use an AUX cable for wired audio input from external devices.

Self-Charging Microphone

Mic with up to 20H battery life.
Automatically recharges when placed in the speaker slot.



Figure 3: Rear Connectivity Ports (HDMI, USB, AUX, Charging).

OPERATING INSTRUCTIONS

1. Basic Controls

- **Power Button:** Press and hold to turn the unit on/off.
- **Volume Knob:** Rotate the central knob on the front panel to adjust the main speaker volume.
- **Bass Button:** Press to toggle bass boost on/off.
- **Mode Button:** Cycles through different input modes (Bluetooth, AUX, Local Play).

2. Using the 10.1" Screen Interface

The touch screen provides access to all smart features:

- **Home Screen:** Displays quick access to Media Player, YouTube, and pre-installed songs.
- **App Section:** Tap 'APP' to view pre-installed applications like KaraFun and YouTube.
- **Settings:** Access display, sound, Wi-Fi, and other system settings.
- **Lighting Mode:** Adjust speaker lighting effects (Light, Romantic, Dynamic, Bright, Starlight).
- **Music Mode:** Select between Hi-Fi, Light, Outdoor, or Bass modes for optimized audio.

Your browser does not support the video tag.

Video 1: Demonstration of the Ikarao Karaoke Machine's screen interface and YouTube functionality.

3. Microphone Effects

The wireless microphones offer various voice effects:

- **Original:** Standard voice.
- **Karaoke:** Adds a reverb effect.
- **Super/Professional/Popular:** Enhanced vocal modes.
- **Monster/Cartoon:** Fun voice changers.
- **Custom:** Adjust reverb, treble, and bass manually.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior. Avoid liquid cleaners directly on the screen or speakers.
- **Storage:** Store the machine in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, fully charge the device before long periods of storage and recharge every 3-6 months.

TROUBLESHOOTING

- **No Power:** Ensure the device is fully charged or connected to a power source. Check the power button.
- **Microphone Not Connecting:** Ensure microphones are charged and powered on. Re-pair via Bluetooth settings if necessary.
- **No Sound:** Check main volume and microphone volumes. Ensure the correct input mode is selected.
- **Wi-Fi Issues:** Verify your Wi-Fi connection in the settings menu. Restart the device and your router if problems persist.
- **Screen Mirroring Failure:** Ensure your TV and karaoke machine are on the same Wi-Fi network and compatible with screen mirroring protocols.

SPECIFICATIONS

- **Model Number:** Shell S1
- **Dimensions:** 6.88 x 6.69 x 13.89 inches
- **Item Weight:** 11.68 pounds

- **Speaker Power:** 280W (Peak)
- **Speaker Configuration:** 2.2-Channel (Dual 3.5" woofers, Dual 1" tweeters)
- **Screen Size:** 10.1 inches
- **Connectivity:** HDMI, USB, AUX, Wi-Fi 2.4G/5G, Bluetooth 5.3
- **Battery Type:** Lithium Ion (1 Nonstandard Battery included)
- **Color:** Black

WARRANTY AND SUPPORT

Your Ikarao Karaoke Machine Shell S1 -280W comes with a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please refer to the contact information provided on the product packaging or the official Ikarao website.