



[Manuals.plus](#) /

> [cupsync](#) /

> cupsync 12-Cup Coffee Pot Replacement Manual

**cupsync 8080**

# cupsync 12-Cup Coffee Pot Replacement Manual

Model: 8080

## INTRODUCTION

This manual provides comprehensive instructions for the proper use and maintenance of your cupsync 12-Cup Coffee Pot Replacement. Designed for compatibility with specific Mr. Coffee 12-cup models, this carafe ensures a seamless fit and reliable performance.



Image: The cupsync 12-Cup Coffee Pot Replacement, a clear glass carafe with a black handle and lid, shown alongside a black coffee measuring spoon.

## Compatibility

This replacement coffee pot is specifically designed for Mr. Coffee 12-cup coffee makers from the RF, PC, SC, MMX, MSX, BVMC-RF300, BVMC-MSX23-NLY, BVMC-MMX23, BVMC-SC12BL1-2, BVMC-PL12BL1-NP, and BVMC-EM100 Series. Please verify your coffee maker's model number to ensure proper fit.



★ ★ ★  
**Only For**

Mr. Coffee 12 cups

RF, PC, SC, BVMC-RF300,

BVMC-MSX23-NLY, BVMC-SC12BL1-2,

BVMC-PL12BL1-NP Series

**Do not buy it if your model not listed here!**



Image: A visual guide indicating compatibility with various Mr. Coffee 12-cup models, including RF, PC, SC, BVMC-RF300, BVMC-MSX23-NLY, BVMC-SC12BL1-2, and BVMC-PL12BL1-NP Series. Several Mr. Coffee machines are pictured below the compatibility text.

There are 2 different hight Carafe Replacement to fit Mr. Coffee different sereis,  
This Carafe only Compatible RF, PC, SC, BVMC-RF300,



BVMC-MSX23-NLY, BVMC-SC12BL1-2,  
BVMC-PL12BL1-NP Series

Pls check carefully before ordering!

! If Your Original Pot looks like this one,  
feel free to purchase



! If Your Original Pot looks like this one, do not buy this link

Image: A side-by-side comparison of two coffee carafes, illustrating the height difference between a 5.8-inch carafe (marked with an 'X' for incompatibility) and the 6.2-inch cupsync carafe (marked with a checkmark for compatibility). This image emphasizes the importance of checking the original carafe's height.

## SETUP

1. **Unpacking:** Carefully remove the coffee pot and any included accessories from the packaging. Inspect for any signs of damage.
2. **Initial Cleaning:** Before first use, wash the coffee pot and lid thoroughly with warm, soapy water. Rinse completely and dry.
3. **Placement:** Ensure your Mr. Coffee machine is on a stable, level surface. Place the clean cupsync coffee pot onto the warming plate of your coffee maker.

## OPERATING INSTRUCTIONS

The cupsync 12-Cup Coffee Pot Replacement functions identically to your original Mr. Coffee carafe. Follow your coffee maker's specific brewing instructions.

1. **Filling:** Fill the coffee pot with the desired amount of fresh, cold water. The carafe has markings for 4, 6, 8, 10, and 12 cups to assist with measurement.
2. **Adding Coffee Grounds:** Place the appropriate amount of coffee grounds into your coffee maker's filter basket. Use the included coffee spoon for accurate measurement if desired.
3. **Brewing:** Ensure the lid is securely placed on the coffee pot and the pot is correctly positioned on the warming plate. Initiate the brewing cycle on your Mr. Coffee machine.
4. **Serving:** Once brewing is complete, carefully remove the coffee pot from the warming plate. The ergonomic handle provides a comfortable and secure grip for pouring.

Ergonomically design comfortable grip




Close Handle easy to carry

Image: A close-up view of the coffee pot's black handle, highlighting its ergonomic design for comfortable and secure gripping and easy carrying.

## MAINTENANCE

Regular cleaning will ensure the longevity and optimal performance of your cupsync coffee pot.

- **Daily Cleaning:** After each use, empty any remaining coffee. Wash the coffee pot and lid with warm, soapy water. Use a soft sponge or cloth to prevent scratching. Rinse thoroughly.
- **Dishwasher Safe:** The cupsync coffee pot is dishwasher safe for convenient cleaning. Place it on the top rack of your dishwasher.
- **Stain Removal:** For stubborn coffee stains, a mixture of baking soda and water or a specialized coffee pot cleaner can be used. Follow the cleaner's instructions.
- **Storage:** Store the clean and dry coffee pot in a safe place to prevent accidental breakage.



Upgrade your coffee experience

Image: The cupsync coffee pot filled with coffee, accompanied by icons indicating it is Dishwasher Safe, BPA Free, and made from Borosilicate 3.3 Glass, emphasizing its material quality and ease of cleaning.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Carafe does not fit coffee maker.	Incorrect model compatibility or carafe height.	Verify your Mr. Coffee model number against the compatible series listed in the Introduction. Ensure your original carafe's height matches the 6.2-inch height of this replacement.
Coffee leaks from carafe.	Lid not properly seated or carafe is damaged.	Ensure the lid is securely and correctly placed on the carafe. Inspect the carafe for any cracks or damage.

Problem	Possible Cause	Solution
Carafe appears cloudy or stained.	Mineral buildup or coffee residue.	Clean thoroughly with warm, soapy water. For stubborn stains, use a mixture of baking soda and water or a specialized coffee pot cleaner.

## SPECIFICATIONS

- **Brand:** cupsync
- **Model Name:** 8080
- **Capacity:** 12 Cups
- **Material:** Borosilicate 3.3 Glass (Break Resistant)
- **Color:** Clear
- **Product Dimensions:** 8 inches (W) x 6.5 inches (H)
- **Item Weight:** 6.4 ounces
- **Included Components:** Coffee Carafe, Lid, Coffee Spoon
- **Special Features:** Compatible with Mr. Coffee, Replacement Carafe, Dishwasher Safe, BPA Free
- **Manufacturer:** DZ TECH

## WARRANTY & SUPPORT

For any questions regarding your cupsync 12-Cup Coffee Pot Replacement, please refer to the seller's return policy on the product page or contact the manufacturer, DZ TECH, directly for support.

The product has a standard return policy of 30 days from the date of purchase for refund or replacement, as per Amazon's policy.