Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl B0DNZ5QBXV

onerbl AC-DC Adapter for SYNOSHI Electric Spin Scrubber Instruction Manual

Introduction

This instruction manual provides essential information for the safe and effective use of your onerbl AC-DC Adapter. This adapter is specifically designed to power and charge compatible SYNOSHI Electric Spin Scrubber models. Please read this manual thoroughly before use and retain it for future reference.

Setup Instructions

Follow these steps to properly set up your AC-DC adapter:

1. **Verify Compatibility:** Ensure your device is compatible with a 5V DC power input and uses a barrel connector. This adapter is compatible with SYNOSHI Synoshi Electric Brush Electric Spin Scrubber Cordless Shower models requiring 5V DC power.
2. **Connect to Device:** Insert the barrel connector end of the adapter cable firmly into the charging port of your SYNOSHI Electric Spin Scrubber.
3. **Connect to Power Outlet:** Plug the AC plug of the adapter into a standard 110V AC electrical wall outlet.
4. **Power Indicator (if applicable):** Some adapters may have an LED indicator to show when power is supplied. Observe if any indicator light illuminates.



Image showing the onerbl AC-DC adapter with its barrel connector, designed for charging the SYNOSHI Electric Spin Scrubber.

Operating Instructions

Once connected, the adapter will begin to supply power to your device or charge its internal battery.

- **Charging:** If your SYNOSHI Electric Spin Scrubber has a rechargeable battery, the adapter will charge it when connected to a power outlet. Refer to your scrubber's manual for specific charging indicators and times.
- **Direct Power:** The adapter can also provide direct power to operate your device if it supports this function while plugged in.
- **Important Note on Batteries:** Rechargeable batteries have a finite lifespan, typically 1 to 3 years. If your device's battery is old or depleted beyond its capacity, it may not accept a charge, even with a functional adapter. This is a battery issue, not an adapter malfunction. To verify if the adapter is working, a voltmeter can be used to check its output voltage.

Maintenance

Proper care will extend the life of your AC-DC adapter:

- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid extreme temperatures.
- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Wipe the exterior with a soft, dry cloth. Do not use liquid cleaners or immerse the adapter in water.
- **Cable Care:** Avoid bending or kinking the cable excessively, especially near the connectors, as this can damage internal wires. Do not place heavy objects on the cable.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires, cracked casing, or bent pins. If damage is found, discontinue use immediately.

Troubleshooting

If you encounter issues with your adapter, consider the following:

- **Device Not Charging/Powering On:**
  - Ensure the adapter is securely plugged into both the wall outlet and your device.
  - Check if the wall outlet is functional by plugging in another device.
  - Verify that your device's battery is not at the end of its lifespan. As noted, old or dead batteries will not accept a charge.
  - Confirm the adapter's specifications (5V DC output) match your device's requirements.
- **Adapter Feels Hot:** It is normal for power adapters to feel slightly warm during operation. If the adapter becomes excessively hot, disconnect it immediately and contact support.
- **Visible Damage:** If the adapter or cable shows any signs of physical damage, discontinue use to prevent electrical hazards.

Specifications

Brand	onerbl
Model (ASIN)	B0DNZ5QBXV
Input Voltage	110 Volts (AC)
Output Voltage	5V DC
Compatible Devices	SYNOSHI Synoshi Electric Brush Electric Spin Scrubber Cordless Shower 1200mAh 1.2Ah Lithium Battery 5V DC5V 5VDC 5.0V
Connector Type	Barrel Connector
Special Feature	Short Circuit Protection
Color	Black
Manufacturer	Shenzhen Waweis Technology Co., Ltd

Warranty Information

Specific warranty details for this product may vary. Please refer to the product packaging or the retailer's website for the most accurate and up-to-date warranty information. Generally, power adapters are covered against manufacturing defects for a limited period from the date of purchase.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact the retailer or manufacturer directly. You may find contact information on your purchase receipt, product packaging, or the official onerbl website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ5QBXV

More documents and user manuals: **https://manuals.plus/**