Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC-DC Adapter

onerbl AC-DC Adapter for PULITUO DC83933-L Cordless Electric Ratchet Wrench User Manual

Model: AC-DC Adapter

Introduction

This manual provides essential instructions for the safe and effective use of your onerbl AC-DC Adapter. This adapter is designed as a replacement power supply for the PULITUO DC83933-L and DC83933L Cordless Electric Ratchet Wrench, specifically for charging its 12V 1.3Ah battery.
Please read this manual thoroughly before using the product and retain it for future reference.

Important Safety Information

- **Power Source:** Only connect the adapter to an AC outlet with the specified voltage range (AC 100-240V, 50/60Hz).
- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose to rain, moisture, or extreme temperatures.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloths or other materials.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact customer support for assistance.
- **Compatibility:** This adapter is specifically designed for the PULITUO DC83933-L/DC83933L Cordless Electric Ratchet Wrench. Using it with incompatible devices may cause damage.
- **Battery Condition:** Note that rechargeable batteries have a limited lifespan (typically 1 to 3 years). If the battery of your tool is damaged or no longer accepts a charge, this is not an issue with the charger itself.
- **Children:** Keep the adapter out of reach of children.

Package Contents

Verify that all items are present:

- 1 x onerbl AC-DC Adapter (Power Supply Unit)
- 1 x Power Cord (if separate)



Figure 1: onerbl AC-DC Adapter and Cable. The image displays a black AC-DC wall adapter with a USB-A output port and a separate black cable with a standard USB-A connector on one end and a micro-USB connector on the other. Please note that the actual product for the PULITUO DC83933-L uses a barrel connector, not USB.

Setup and Connection

1. **Inspect:** Before connecting, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
2. **Connect to Tool:** Locate the charging port on your PULITUO DC83933-L/DC83933L Cordless Electric Ratchet Wrench. Insert the barrel connector of the adapter's power cable firmly into the tool's charging port.
3. **Connect to Power Outlet:** Plug the AC-DC adapter into a standard wall power outlet (AC 100-240V).
4. **Verify Connection:** Ensure all connections are secure. The tool's charging indicator (if present) should activate, indicating that charging has begun.

Operating Instructions

This onerbl AC-DC Adapter functions as a power supply and battery charger for your compatible PULITUO cordless electric ratchet wrench.

- **Charging:** Once connected as described in the "Setup and Connection" section, the adapter will begin charging the tool's 12V 1.3Ah battery.
- **Charging Time:** Refer to your PULITUO tool's original manual for estimated charging times. Disconnect the adapter once the battery is fully charged to prevent overcharging, if the tool's battery management system does not automatically stop charging.
- **Powering the Tool:** The adapter can also provide power to the tool directly if the battery is removed or fully discharged, allowing for corded operation if the tool supports it.

Care and Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and the tool before cleaning. Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cable too tightly around the adapter to prevent damage.

- **Cable Care:** Do not bend, twist, or pinch the power cable excessively. Avoid placing heavy objects on the cable.

Troubleshooting

Problem	Possible Cause	Solution
Adapter not charging the tool.	No power from outlet. Loose connection. Damaged adapter or cable. Tool's battery is faulty.	Test the outlet with another device. Ensure the adapter is fully plugged into the outlet and the tool. Inspect for visible damage. If damaged, discontinue use. As noted, if the tool's battery is old or damaged, it may not accept a charge. This is not an adapter fault.
Adapter feels hot during use.	Normal operation (slight warmth). Poor ventilation. Overload or internal fault.	A slight warmth is normal. Ensure the adapter is not covered and has airflow. If excessively hot or emitting smoke/smell, immediately unplug and discontinue use.

Specifications

- **Brand:** onerbl
- **Input:** AC 100-240V, 50/60Hz (Worldwide AC Input)
- **Output:** DC 12V (Specific amperage not provided, but implied for 1.3Ah battery charging)
- **Connector Type:** Barrel Connector (as per product specifications)
- **Compatible Devices:** PULITUO DC83933-L, DC83933L Cordless Electric Ratchet Wrench 3/8" 12V 1.3Ah Battery
- **Special Feature:** Short Circuit Protection
- **Color:** Black

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ5RDGZ

More documents and user manuals: **https://manuals.plus/**