

[Manuals.plus](#) /

› [onerbl](#) /

› onerbl AC-DC Adapter User Manual for YKYI RJ152 ANS-8051A Electric Spin Scrubber

onerbl AC-DC Adapter (ASIN: B0DNZ62NZ1)

onerbl AC-DC Adapter User Manual

For YKYI RJ152 ANS-8051A ANS8051A Electric Spin Scrubber

1. PRODUCT OVERVIEW

The onerbl AC-DC Adapter is designed to provide reliable power to your compatible devices, specifically the YKYI RJ152 ANS-8051A ANS8051A Electric Spin Scrubber. This adapter converts standard AC wall power into the DC power required by your device, enabling both operation and battery charging. It features a robust design for consistent performance.



Image showing the onerbl AC-DC Adapter, featuring its power brick and connector cable.

Key Features:

- Converts AC power to 5V DC power.
- Compatible with YKYI RJ152 ANS-8051A ANS8051A Electric Spin Scrubber.
- Equipped with short circuit protection.
- Designed for durability and consistent performance.

2. SETUP INSTRUCTIONS

1. **Verify Compatibility:** Ensure your device is the YKYI RJ152 ANS-8051A ANS8051A Electric Spin Scrubber or another device requiring a 5V DC input with a compatible barrel connector.
2. **Connect to Device:** Insert the barrel connector end of the AC-DC adapter cable firmly into the charging port of your electric spin scrubber.
3. **Connect to Power Outlet:** Plug the AC plug of the adapter into a standard 110V AC electrical wall outlet.
4. **Power Indicator (if applicable):** If your adapter or device has a power indicator light, observe it to confirm power connection.

The adapter is now ready to power your device or charge its battery.

3. OPERATING INSTRUCTIONS

Once properly connected, the onerbl AC-DC Adapter will automatically begin supplying power to your electric spin scrubber. If the device's battery is depleted, the adapter will initiate the charging process.

Important Notes on Battery Charging:

- Rechargeable batteries have a finite lifespan, typically lasting 1 to 3 years depending on usage.
- An old or dead battery may not accept a charge, which is a battery issue, not an adapter malfunction.
- To determine if the charger is functioning correctly, a voltmeter is required to test its output voltage.
- Always ensure the adapter is used in a well-ventilated area.

4. MAINTENANCE

Proper care of your AC-DC adapter will ensure its longevity and safe operation.

- **Cleaning:** Disconnect the adapter from both the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Avoid dropping the adapter or subjecting it to strong impacts. Do not pull the cable to disconnect it from the wall outlet or device; always grasp the plug or connector.
- **Moisture:** Keep the adapter away from water and other liquids. Do not operate if the adapter or its cables appear wet or damaged.

5. TROUBLESHOOTING

If you encounter issues with your onerbl AC-DC Adapter, refer to the following common troubleshooting steps:

- **Device Not Powering On/Charging:**
 - Ensure the adapter is securely plugged into both the wall outlet and the device.
 - Check if the wall outlet is functional by plugging in another device.
 - Inspect the adapter cable and connector for any visible damage (frays, bends). If damaged, discontinue use.
 - As noted in Section 3, if the device's battery is old or dead, it may not accept a charge. This is a battery issue, not an adapter fault.
 - If you suspect the adapter is faulty, use a voltmeter to test its output voltage. The output should be approximately 5V DC.
- **Adapter Overheating:**
 - A slight warmth is normal during operation. However, if the adapter becomes excessively hot to the touch, disconnect it immediately.
 - Ensure the adapter is in a well-ventilated area and not covered.
 - Verify that the device connected is compatible and not drawing excessive power.
- **Intermittent Power:**
 - Check for loose connections at both the wall outlet and the device.
 - Examine the cable for internal breaks by gently flexing it while connected (if safe to do so).

If these steps do not resolve the issue, contact customer support for further assistance.

6. TECHNICAL SPECIFICATIONS

Specification	Detail
Brand	onerbl
Model (ASIN)	B0DNZ62NZ1
Input Voltage	110V AC
Output Voltage	5V DC
Connector Type	Barrel Connector
Compatible Devices	YKYI RJ152 ANS-8051A ANS8051A Electric Spin Scrubber 2500mAh 2.5Ah Product Specific Battery 5V DC5V 5VDC 5.0V
Special Features	Short Circuit Protection
Color	Black
Manufacturer	Shenzhen Waweis Technology Co., Ltd

7. WARRANTY AND SUPPORT

This onerbl AC-DC Adapter is manufactured to high-quality standards. For specific warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. In general, products are subject to a return policy, typically 30 days from the date of purchase, for refunds or replacements.

Customer Support:

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact the seller or manufacturer directly. Refer to your purchase records for contact details.

© 2026 onerbl. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question