onerbl AC-DC Adapter for CACULE JY-6010

onerbl AC-DC Adapter Instruction Manual

Model: AC-DC Adapter for CACULE JY-6010 Electric Spin Scrubber

1. Introduction

This instruction manual provides important information for the safe and efficient use of your onerbl AC-DC Adapter. This adapter is specifically designed as a replacement power supply for the CACULE JY-6010 Electric Spin Scrubber, providing the necessary DC 5V power for operation and battery charging. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Do not expose the adapter to water or moisture.** This is an electrical device and should be kept dry.
- **Do not disassemble or modify the adapter.** Unauthorized modifications can lead to electric shock or fire.
- **Use only with compatible devices.** This adapter is designed for the CACULE JY-6010 Electric Spin Scrubber. Using it with incompatible devices may cause damage.
- **Ensure proper ventilation.** Do not cover the adapter during use to prevent overheating.
- **Keep out of reach of children.**
- **Unplug the adapter from the power outlet when not in use for extended periods.**

3. Package Contents

Your package should contain the following item:

- 1 x onerbl AC-DC Adapter (DC 5V)



Image 1: The onerbl AC-DC Adapter. This image shows the compact black adapter with its power cord and barrel connector.

4. Setup

Follow these steps to set up your AC-DC adapter:

1. **Identify the charging port** on your CACULE JY-6010 Electric Spin Scrubber.
2. **Connect the barrel connector** of the onerbl AC-DC Adapter firmly into the charging port of the spin scrubber.
3. **Plug the AC power cord** of the adapter into a standard AC 100-240V wall outlet.
4. Ensure all connections are secure before use.

5. Operating Instructions

Once connected, the adapter will provide power to your CACULE JY-6010 Electric Spin Scrubber. If the scrubber has a rechargeable battery, the adapter will also initiate the charging process.

- **Powering the Device:** With the adapter plugged in, your spin scrubber can be operated directly from the wall outlet.
- **Charging the Battery:** The adapter will charge the scrubber's internal battery. Refer to your spin scrubber's manual for charging indicators (e.g., LED lights).

- **Important Note on Batteries:** Rechargeable batteries have a finite lifespan, typically 1 to 3 years. If your scrubber's battery is damaged or has reached the end of its life, it may not accept a charge, even with a functional adapter. This is a characteristic of the battery itself, not a fault of the charger.

6. Maintenance

Proper maintenance ensures the longevity of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

7. Troubleshooting

If you encounter issues with your adapter, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device not powering on/charging	Adapter not properly connected to outlet or device.	Ensure the adapter is securely plugged into both the wall outlet and the CACULE JY-6010 Electric Spin Scrubber. Try a different wall outlet.
Device not charging (even with adapter connected)	Damaged or worn-out rechargeable battery in the spin scrubber.	Rechargeable batteries have a limited lifespan. If the battery is old or damaged, it may no longer accept a charge. This is a device battery issue, not an adapter fault. Consider replacing the spin scrubber's battery if possible, or the scrubber itself.
Adapter feels hot during use	Normal operation, or poor ventilation.	A slight warmth is normal. Ensure the adapter is not covered and has adequate airflow. If it becomes excessively hot, unplug it immediately and contact support.

8. Specifications

Feature	Detail
Brand	onerbl
Input Voltage	AC 100-240V, 50/61Hz (Worldwide Auto Input)
Output Voltage	DC 5V
Compatible Devices	CACULE JY-6010 JY6010 Electric Spin Scrubber 3000mAh A Battery DC5V 5VDC 5.0V
Connector Type	Barrel Connector
Special Feature	Short Circuit Protection
Color	Black

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer directly. Keep your proof of purchase for any warranty claims.

© 2024 onerbl. All rights reserved.