Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl BD-001

Onerbl AC-DC Adapter Instruction Manual

Model: BD-001

Brand: onerbl

1. Introduction

This Onerbl AC-DC Adapter is designed to provide reliable power to your YUEWXTER BD-001 Electric Weed Eater and 4-in-1 Grass Trimmer. It efficiently converts standard AC electrical power into the DC power required by your device, enabling both direct operation and battery charging. This adapter has been tested to ensure compatibility and performance with the specified devices.

2. Safety Information

- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the wall outlet voltage matches the adapter's input requirements (100-240V AC).
- **Avoid Damage:** Do not use the adapter if the cord or plug is damaged. Avoid bending, twisting, or crimping the cable excessively.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use or during electrical storms.
- **No Disassembly:** Do not attempt to open or repair the adapter. Refer all servicing to qualified personnel.
- **Keep Dry:** Always handle the adapter with dry hands.

Caution: *For indoor use only.*

3. Package Contents

- 1 x Onerbl AC-DC Adapter (Model BD-001)

4. Setup

1. **Connect to Device:** Insert the barrel connector of the Onerbl AC-DC Adapter firmly into the power input port of your YUEWXTER BD-001 Electric Weed Eater or 4-in-1 Grass Trimmer.
2. **Connect to Power Outlet:** Plug the adapter's two-prong plug into a standard 110V AC electrical wall outlet.



Figure 1: The Onerbl AC-DC Adapter connected to a wall outlet, ready for use.

5. Operating Instructions

Once the adapter is correctly connected to both your device and a functional power outlet, your YUEWXTER BD-001 device should either power on directly or begin charging its battery, indicated by the device's charging indicator (if applicable).

Important Note on Batteries: Rechargeable batteries have a limited lifespan, typically lasting 1 to 3 years. If your device's battery is old or depleted, it may not accept a charge, even with a functional adapter. This is a battery issue, not a fault with the charger. If you are uncertain whether the battery or the charger is the cause of a charging problem, a voltmeter can be used to test the charger's output voltage.

6. Maintenance

- **Cleaning:** Keep the adapter clean and dry. Use a soft, dry cloth to wipe off any dust or dirt. Do not use liquid cleaners.
- **Cable Care:** Avoid sharp bends or kinks in the power cord. Do not place heavy objects on the cord.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use.

7. Troubleshooting

- **Device Not Powering On or Charging:**
  - Ensure the adapter's barrel connector is fully inserted into the device.
  - Verify the adapter is securely plugged into a working wall outlet. Test the outlet with another device if necessary.
  - Refer to the **Important Note on Batteries** in Section 5. An old or dead battery will not charge.
  - If the issue persists and you've ruled out battery problems, use a voltmeter to check the adapter's output voltage.
- **Adapter Getting Warm:** It is normal for the adapter to become slightly warm during operation. If it becomes excessively hot to the touch or emits a burning smell, immediately unplug it from the wall outlet and discontinue use.

8. Specifications

Feature	Specification
Brand	onerbl
Model	BD-001
Input Voltage	100-240V AC, 50/60Hz
Output Voltage	DC21V
Output Current	4.0A - 6.0A
Connector Type	Barrel Connector
Special Feature	Short Circuit Protection
Cable Length	76 inches (approx. 193 cm)
Dimensions (Adapter Body)	3.1 inch (length) x 2.1 inch (width) x 1.2 inch (thickness)
Compatible Devices	YUEWXTER BD-001 BD001 YUE10854 Electric Weed Eater 4-in-1 Grass Trimmer



Figure 2: Physical dimensions of the Onerbl AC-DC Adapter.



Figure 3: Adapter specifications and cable length.

9. Warranty and Support

For product support, technical assistance, or warranty inquiries, please contact the retailer from whom you purchased this product or the manufacturer directly. Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ6GFS6

More documents and user manuals: **https://manuals.plus/**