

ANGELBLISS BC666-1

ANGELBLISS BC666-1 3-in-1 Baby Bassinet Instruction Manual

Model: BC666-1

INTRODUCTION

Thank you for choosing the ANGELBLISS BC666-1 3-in-1 Baby Bassinet. This versatile product is designed to provide a safe, comfortable, and convenient sleeping solution for your newborn. Please read this instruction manual thoroughly before assembly and use to ensure proper operation and the safety of your child.

Key Features:

- **Versatile 3-in-1 Design:** Functions as a standalone bassinet, a bedside sleeper, and a portable nest.
- **Calming Rocking Motion:** Features a manual rocking function to gently soothe your baby.
- **Breathable Mesh Walls:** Ensures optimal ventilation and visibility for enhanced safety and interaction.
- **Comfortable Mattress:** Includes a cozy mattress for a restful sleep environment.
- **Adjustable Height:** Multiple height settings to align with various bed heights for bedside use.
- **Lightweight & Portable:** Easy to detach from the base and includes a travel bag for convenient transport.
- **Integrated Storage:** A convenient storage basket is located beneath the bassinet for baby essentials.

IMPORTANT SAFETY WARNINGS

FAILURE TO FOLLOW THESE WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

- **SUFFOCATION HAZARD:** Infants can suffocate in gaps between extra padding and the side of the bassinet, or on soft bedding. Use **ONLY** the mattress provided by the manufacturer. **NEVER** add a pillow, comforter, or another mattress for padding.
- **FALL HAZARD:** To prevent falls, do **NOT** use this product once the infant begins to push up on hands and knees, or has reached 20 lbs (9 kg), or is 5 months old, whichever comes first.
- **ALWAYS** ensure the bassinet is securely attached to the adult bed when used in bedside sleeper mode.
- **NEVER** use the bassinet if any parts are missing, damaged, or broken. Contact customer service for

replacement parts.

- Keep all assembly hardware out of reach of children.
- Ensure all straps are properly secured and tightened before each use.

SETUP AND ASSEMBLY

Carefully unpack all components and ensure all parts are present before beginning assembly. No additional tools are required.

Assembly Steps:

1. Unfold the main frame and lock the legs into position.
2. Attach the bassinet basket to the frame, ensuring all connection points are secure.
3. Insert the mattress into the bassinet basket.
4. Attach the under-bassinet storage basket to the designated hooks on the frame.



Figure 1: All components of the ANGELBLISS bassinet ready for assembly.

Installation Video:

Your browser does not support the video tag.

Video 1: Step-by-step installation process for the ANGELBLISS 3-in-1 Portable Bassinet.

OPERATING INSTRUCTIONS

1. Standalone Bassinet Mode

Use the bassinet independently in any room. Ensure all four legs are fully extended and locked, and the rocking function is disengaged if a stationary position is desired.



Figure 2: The ANGELBLISS bassinet in standalone mode.

2. Bedside Sleeper Mode

To use as a bedside sleeper, adjust the bassinet height to match your adult bed. Unzip and lower one side of the bassinet for easy access to your baby. Secure the bassinet to your bed using the provided attachment straps to prevent gaps and ensure stability.

Your browser does not support the video tag.

Video 2: Demonstrating the ANGELBLISS Baby Bassinet in bedside sleeper mode, highlighting its features and proximity to an adult bed.

3. Portable Nest Mode

The bassinet basket can be detached from the base to be used as a portable nest. This allows you to keep your baby

close in different rooms of your home or when traveling. Ensure the portable nest is placed on a flat, stable surface.



Figure 3: The bassinet in portable nest mode, ideal for use around the house.

4. Rocking Function

The bassinet features a manual rocking motion to help soothe your baby. To activate the rocking function, ensure the bassinet is on a flat surface and gently push it from side to side. To stop the rocking, engage the locking mechanism on the base.

ROCKING BASSINET

Side to side motion to help soothe your baby



Figure 4: Visual representation of the rocking motion feature.

5. Height Adjustment

The bassinet offers multiple height settings. To adjust the height, locate the adjustment buttons on the side of the frame, press them, and slide the bassinet up or down to the desired level. Ensure both sides are adjusted evenly and securely locked before placing your baby inside.

6. Tilt Function (for Reflux)

The bassinet can be slightly tilted to help alleviate reflux symptoms. Adjust one side of the bassinet to a higher setting

than the other, creating a gentle incline. Ensure the incline is minimal and safe for your baby.

7. Portability and Storage

The bassinet is designed for easy portability. It features wheels for moving it between rooms. The wheels can be locked for stability. For travel or compact storage, the bassinet can be folded down and placed in the included travel bag.



Figure 5: The convenient storage basket located beneath the bassinet.

Your browser does not support the video tag.

Video 3: Overview of the ANGELBLISS 3-in-1 Portable Bassinet's various modes and features.

MAINTENANCE

Cleaning Instructions:

- **Fabric Components:** The fabric parts of the bassinet are machine washable. Remove all fabric components from

the frame before washing. Use a gentle cycle with cold water and mild detergent. Do not bleach. Air dry or tumble dry on low heat.

- **Frame:** Wipe the metal and plastic parts of the frame with a damp cloth and mild soap. Dry thoroughly.
- **Mattress:** The mattress cover can be removed and machine washed. The foam insert can be spot cleaned with a damp cloth and mild soap. Ensure the mattress is completely dry before reinserting into the bassinet.

TROUBLESHOOTING

Common Issues and Solutions:

- **Bassinet feels unstable:** Ensure all frame components are fully extended and locked into place. Check that the height adjustment mechanisms are securely engaged on both sides.
- **Difficulty with rocking motion:** Verify that the rocking lock is disengaged. Ensure the bassinet is on a flat, even surface.
- **Side not lowering/raising smoothly:** Check for any obstructions in the zipper or sliding mechanism. Ensure buttons are fully pressed during adjustment.
- **Wheels not rolling:** Check if the wheel locks are engaged. Disengage them to allow free movement.

If you encounter any issues not listed here or require further assistance, please contact ANGELBLISS customer support.

SPECIFICATIONS

Feature	Detail
Brand	ANGELBLISS
Model Number	BC666-1
Color	Grey
Product Dimensions	32.68"L x 16.93"W x 30.31"H
Frame Material	Alloy Steel
Item Weight	15.2 Pounds
Assembly Required	Yes
Product Care Instructions	Machine Wash (fabric)

WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the warranty card included with your purchase or visit the official ANGELBLISS website. You may also contact ANGELBLISS customer service directly for assistance.