



[Manuals.plus](#) /

> [kleankin](#) /

> kleankin Under Sink Cabinet 834-542V00WT Instruction Manual

kleankin 834-542V00WT

kleankin Under Sink Cabinet Instruction Manual

Model: 834-542V00WT

1. INTRODUCTION

Thank you for choosing the kleankin Under Sink Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new bathroom vanity unit. Please read these instructions carefully before beginning assembly and retain them for future reference.

This under sink cabinet is designed to maximize storage space in your bathroom, featuring a U-shaped cutout to accommodate most washbasin pipes. It includes a double-door cabinet and an open niche for organizing hygiene products, supplies, or towels.

2. SAFETY INFORMATION

- Always follow assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- To prevent tipping, especially in households with children or pets, always install the provided anti-tip straps. Secure the cabinet to a wall stud using appropriate hardware.
- Do not overload the cabinet. Refer to the 'Specifications' section for maximum weight capacities.
- Keep small parts and packaging materials away from children to avoid choking hazards.
- Avoid exposing the cabinet to excessive moisture or direct water contact for prolonged periods, as this can damage the engineered wood material.



CONCEPTION ANTI-BASCULEMENT

Pour plus de stabilité



Image: Detail of the anti-tip strap attachment point, showing how it secures the cabinet for stability.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (top, bottom, sides, back)
- Double Doors
- Handles
- Shelves (if applicable)
- Assembly Hardware (screws, dowels, cam locks, hinges, etc.)
- Anti-tip Straps and Wall Anchors
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches. Two people are recommended for assembly.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list (usually provided in a separate diagram within the package) to ensure everything is present.
2. **Assemble the Main Frame:** Follow the step-by-step diagrams provided in your package to connect the side panels, bottom panel, and any internal shelves using the provided hardware (dowels, screws, cam locks). Ensure the U-shaped cutout on the top panel is correctly oriented for your washbasin.
3. **Attach the Back Panel:** Secure the back panel to the assembled frame using small nails or screws.
4. **Install Doors and Handles:** Attach the hinges to the cabinet doors and then to the main frame. Adjust hinges as needed for proper door alignment. Secure the handles to the front of the doors.
5. **Install Anti-Tip Device:** Locate a suitable wall stud behind the cabinet's intended position. Secure one end of the anti-tip strap to the top rear of the cabinet and the other end to the wall stud using the provided screws and anchors. This step is crucial for safety.
6. **Position the Cabinet:** Carefully slide the assembled cabinet into position under your washbasin, ensuring the U-shaped cutout fits around the sink's pedestal or plumbing.




Image: Dimensional diagram of the cabinet, highlighting the overall size and the U-shaped cutout for sink compatibility.

TYPES D'ÉVIERS ADAPTÉS

Remarque : L'évier n'est pas inclus



Évier avec socle



Évier sans socle

Image: Illustration demonstrating the cabinet's compatibility with various washbasin types, including those with and without pedestals, due to its U-shaped design.

5. OPERATING INSTRUCTIONS

The kleankin Under Sink Cabinet provides versatile storage options for your bathroom:

- **Double-Door Cabinet:** Use the enclosed cabinet space for storing items you wish to keep out of sight, such as cleaning supplies, extra toilet paper, or personal hygiene products. The doors help protect contents from dust and moisture.
- **Open Niche:** The open shelf above the cabinet is ideal for frequently accessed items, decorative accents, or neatly folded towels.

Vous pouvez ranger lesserviettes, les produits d'hygiène quotidienne et les produits de nettoyage



Étagère ouverte

Armoire avec étagère

Image: The cabinet interior, showcasing the open niche and the double-door compartment used for storing various bathroom items.



Image: Close-up view of the interior shelf, demonstrating its capacity for items like toilet paper rolls.

6. MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive water, as these can damage the melamine finish.
- **Spills:** Immediately wipe up any water spills or moisture to prevent damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Anti-Tip Straps:** Regularly inspect the anti-tip straps and wall anchors for any signs of wear or loosening. Ensure they are securely attached.

7. TROUBLESHOOTING

- **Cabinet is Wobbly:**
 - Ensure all assembly screws and fasteners are fully tightened.
 - Verify the cabinet is placed on a level surface.

- Confirm the anti-tip straps are securely installed and tightened to the wall.
- **Doors Do Not Align Properly:**
 - Check that the hinges are correctly installed and tightened.
 - Adjust the hinge screws to align the doors. Refer to hinge adjustment guides if needed.
- **U-shaped Cutout Does Not Fit Sink:**
 - Review the dimensions provided in the 'Specifications' section and compare them to your washbasin's dimensions before purchase.
 - Ensure the cabinet is positioned correctly under the sink.

8. SPECIFICATIONS

Feature	Detail
Brand	kleankin
Model Number	834-542V00WT
Color	White
Material	Engineered Wood
Product Dimensions (D x W x H)	11.81"D x 23.62"W x 23.62"H (30D x 60W x 60H cm)
U-shaped Cutout Dimensions (W x D)	20W x 22D cm
Recommended Washbasin Width	Up to 50 cm
Maximum Weight Capacity (Total)	50 kg (110 lbs)
Number of Doors	2
Assembly Required	Yes
Mounting Type	Floor Mount (with anti-tip straps for wall attachment)

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. You may also visit the official kleankin website for further assistance.

Please have your model number (834-542V00WT) and purchase date ready when contacting support.