



Manuals.plus /

› HP /

› HP 17 Laptop User Manual

## HP HP 17 Laptop

# HP 17 Laptop User Manual

Model: HP 17 Laptop

Introduction	What's in the Box	Setup Specifications	Operating the Laptop Warranty & Support	Maintenance	Troubleshooting
--------------	-------------------	----------------------	---	-------------	-----------------

## 1. INTRODUCTION

---

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP 17 Laptop. The HP 17 Laptop features a 17.3-inch Full HD display, an AMD Ryzen 5 Processor, 16GB of RAM, and a 1TB SSD, running on Windows 11 Home. It is designed for reliable performance across various tasks.

## 2. WHAT'S IN THE BOX

---

Carefully unpack all items and ensure the following components are present:

- HP 17 Laptop
- AC Power Adapter
- Alpacatec Accessories (if included with your specific package)

## 3. SETUP

---

### 3.1 Initial Power-On

1. Connect the AC power adapter to the laptop's power port and then to a power outlet.
2. Open the laptop lid. The laptop may power on automatically, or you may need to press the power button located on the keyboard.
3. Follow the on-screen instructions to complete the Windows 11 Home setup, including language, region, network connection, and user account creation.



Image: The HP 17 Laptop showcasing its powerful AMD Ryzen 5 processor and Radeon Graphics, along with the Windows 11 Home operating system.

### 3.2 Connecting Peripherals

Utilize the available ports to connect external devices:

- **USB Devices:** Connect USB drives, mice, or keyboards to the USB Type-A or USB Type-C ports.
- **External Display:** Use the HDMI port to connect an external monitor or projector.
- **Audio:** Plug headphones or external speakers into the Headphone/Microphone combo jack.



Image: A visual representation of the HP 17 Laptop's various ports, including USB Type-A, AC smart pin, HDMI, and Headphone/Microphone combo, along with its dimensions.

## 4. OPERATING THE LAPTOP

---

### 4.1 Power Management

- **Power On:** Press the power button.
- **Sleep Mode:** Close the lid or select 'Sleep' from the Start menu.
- **Shut Down:** Select 'Shut down' from the Start menu.

### 4.2 Using the Keyboard and Touchpad

The laptop features a full-size keyboard with a dedicated numeric keypad for efficient data entry. The touchpad supports multi-touch gestures for navigation.

### 4.3 Display Features

Your HP 17 Laptop is equipped with a 17.3-inch Full HD (1920 x 1080) IPS Micro-Edge, Anti-glare Display, providing clear visuals and reduced reflections.



Image: A close-up view of the HP 17 Laptop's 17.3-inch Full HD display, highlighting its clear visual capabilities.

### 4.4 Wireless Connectivity

The laptop supports Wi-Fi 6 for fast internet access and Bluetooth 5.0 for connecting wireless accessories like headphones or mice.

# Ports & Connectivity



Image: The HP 17 Laptop displayed alongside icons representing its Wi-Fi, Bluetooth, and long battery life features.

## 4.5 Battery Life and Charging

The laptop offers up to 9 hours of battery life. HP Fast Charge technology allows you to charge the battery from 0 to 50% in approximately 45 minutes.

## 5. MAINTENANCE

### 5.1 Cleaning

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Keyboard and Chassis:** Use a soft, dry cloth. For dust, use compressed air.

### 5.2 Software Updates

Regularly check for and install Windows updates to ensure optimal performance and security. Go to **Settings**

> Windows Update.

### 5.3 Battery Care

To prolong battery life, avoid extreme temperatures and fully discharging the battery frequently. Store the laptop in a cool, dry place when not in use for extended periods.

### 5.4 Storage Management

The 1TB PCIe Solid State Drive provides ample storage. Regularly delete unnecessary files and empty the recycle bin to maintain performance. Consider cloud storage for backups.



Image: Two HP 17 Laptops, one open and one closed, demonstrating the sleek design and highlighting the high-speed memory and large capacity storage for smooth operation.

## 6. TROUBLESHOOTING

---

If you encounter issues with your HP 17 Laptop, try the following basic troubleshooting steps:

- **No Power:** Ensure the AC adapter is securely connected to both the laptop and a working power outlet. Try a different outlet.
- **Display Issues:** If the screen is blank, try pressing the brightness keys (usually F2/F3 or similar) or connecting an external monitor to check if the display output works.
- **No Wi-Fi/Bluetooth:** Check if Wi-Fi or Bluetooth is enabled in Windows settings. Restart the laptop and your router.
- **Slow Performance:** Close unnecessary applications, check for background updates, and ensure sufficient free storage space.
- **System Freeze:** If the system is unresponsive, press and hold the power button for 10-15 seconds to force a shutdown, then restart.

For more complex issues, refer to the HP support website or contact customer service.

## 7. SPECIFICATIONS

Feature	Detail
Processor	AMD Ryzen 5 (6 cores, up to 4.3 GHz burst frequency)
Graphics	AMD Radeon Graphics (Integrated)
RAM	16GB DDR4 SDRAM
Storage	1TB PCIe Solid State Drive (SSD)
Display	17.3-inch Full HD (1920 x 1080) IPS Micro-Edge, Anti-glare
Operating System	Windows 11 Home
Ports	1x USB Type-C 3.0, 2x USB Type-A 3.0, 1x HDMI, 1x Headphone/Microphone combo, 1x AC smart pin
Wireless Connectivity	Wi-Fi 6 (802.11ax), Bluetooth 5.0
Webcam	HP True Vision 720p HD camera with privacy shutter, Temporal noise reduction
Battery Life	Up to 9 hours (HP Fast Charge: 0 to 50% in approx. 45 minutes)
Dimensions (H x W x D)	0.78 x 15.78 x 10.15 Inches
Weight	4.6 pounds
Model Year	2021
UPC	197961772593

## **8. WARRANTY & SUPPORT**

---

### **8.1 Limited Warranty**

Your HP 17 Laptop comes with a limited manufacturer's warranty. Please refer to the warranty documentation included with your product for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

### **8.2 Customer Support**

For technical assistance, driver downloads, or further information, please visit the official HP support website. You can typically find support resources by searching for your specific laptop model on the HP website.