

[Manuals.plus](#) /

› [Sealy](#) /

› Sealy Portable Sound Machine Night Light & Bluetooth Speaker User Manual

Sealy SL-HW-SN-122-WT

Sealy Portable Sound Machine User Manual

Model: SL-HW-SN-122-WT

INTRODUCTION

Thank you for choosing the Sealy Portable Sound Machine Night Light & Bluetooth Speaker. This device is designed to provide a soothing audio and visual environment for relaxation, sleep, and focus. With 40 unique sound modes, adjustable brightness, and multicolor lighting options, it offers a customizable experience for users of all ages. Its portable design and rechargeable battery make it ideal for use at home or on the go. Please read this manual carefully to ensure proper use and maintenance of your device.

PRODUCT OVERVIEW

Key Features

- **40 Soothing Sound Modes:** Includes white noise, natural environments, and machine tones for diverse preferences.
- **Dynamic Lighting Options:** Features 7 vibrant multicolor mood lights and 2 calming breathing light modes.
- **Adjustable Brightness:** Offers 4 levels of brightness for the night light function.
- **Portable & Rechargeable:** Compact design with a strap hook for easy transport, powered by a rechargeable battery via Type-C USB.
- **Versatile Timer Settings:** Four time options (30, 60, 90, 120 minutes) for automatic shutoff.
- **Bluetooth-Enabled Speaker:** Connects wirelessly to your devices for music, audiobooks, or calls with crisp sound quality.

What's in the Box

- Sealy Portable Sound Machine Night Light & Bluetooth Speaker
- Type-C USB Charging Cable
- User Manual


Product Visuals



Front view of the Sealy Portable Sound Machine, showcasing its compact, spherical design and illuminated base.



Side view highlighting the portable strap hook and key features like 40 sound modes and Type-C USB charging.



Visual representation of the three adjustable brightness levels for the night light function.



Display of the seven different multicolor light modes available on the device.



Image illustrating the four timer options (30, 60, 90, 120 minutes) for automatic shutoff.

Product Video



Official product video demonstrating the features and portability of the Sealy Portable Sound Machine, including its use for babies in strollers.

SAFETY INFORMATION

Always follow the instructions provided with this product. Keep the device away from liquids and avoid exposing it to excessive heat. Do not use this device while sleeping to prevent the risk of overheating. This device is not intended for use by children. Always observe safe noise levels to protect your hearing.

SETUP

Charging the Device

1. Locate the Type-C USB charging port on the device.
2. Connect the provided Type-C USB cable to the device and the other end to a compatible USB power adapter (not included) or a computer USB port.
3. The charging indicator lights will illuminate to show charging status. A full charge typically takes approximately 2-3 hours.
4. Once fully charged, the indicator lights may change or turn off. Disconnect the charging cable.



The Type-C USB charging port, located on the side of the device for convenient charging.

OPERATING INSTRUCTIONS

Power On/Off

- To power on the device, slide the ON/OFF switch to the "ON" position.

- To power off the device, slide the ON/OFF switch to the "OFF" position.

Sound Modes

- The device features 40 unique sound modes, including white noise, nature sounds (e.g., rain, waves, birds), and calming tones (e.g., lullabies, heartbeat, meditation).
- Press the **Sound Mode** button (represented by musical notes or sound waves icon) to cycle through the available sound categories.
- Use the **Volume Up** and **Volume Down** buttons to adjust the sound level.




A visual guide to the various sound categories available, including white noise, nature, and calming tones.

Night Light and Mood Lights

- Press the **Light Mode** button (represented by a sun icon) to turn on the night light.
- Continue pressing the Light Mode button to cycle through the 7 multicolor mood lights and 2 calming breathing light modes.
- To adjust the brightness of the night light, press the **Brightness** button (represented by a sun with plus/minus signs). There are 4 adjustable brightness levels.



Demonstration of the adjustable brightness levels for the night light.



Visual display of the seven distinct multicolor light modes.

Timer Settings

- The device offers four timer options for automatic shutoff: 30, 60, 90, and 120 minutes.
- Press the **Timer** button (represented by a clock icon) to select your desired duration. The corresponding indicator light will illuminate.
- The device will automatically turn off after the selected time.




Illustration of the 30, 60, 90, and 120-minute timer options.

Bluetooth Connection

- To connect via Bluetooth, ensure the device is powered on.
- The device will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth icon or light.
- On your smartphone or other Bluetooth-enabled device, search for "Sealy Sound Machine" (or similar name) in the Bluetooth settings.
- Select the device to pair. Once connected, a confirmation sound may play, and the Bluetooth indicator light will become solid.
- You can now play audio from your connected device through the Sealy Sound Machine.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, fully charge the device before first use and recharge it regularly, even if not used frequently. Avoid completely draining the battery.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device using the provided USB-C cable.
No sound from the speaker.	Volume is too low or muted; incorrect sound mode selected.	Increase the volume. Cycle through sound modes to ensure one is active.
Cannot connect via Bluetooth.	Device is not in pairing mode; too far from source device; interference.	Ensure the sound machine is powered on and in pairing mode. Move closer to the source device. Turn off other Bluetooth devices nearby.
Night light is not working.	Light mode is off or brightness is set to minimum.	Press the Light Mode button to activate the light. Adjust brightness using the Brightness button.

SPECIFICATIONS

Feature	Detail
Model Name	SL-HW-SN-122-WT
Product Dimensions	4.9 x 4.8 x 1.75 inches
Item Weight	7.2 ounces
Color	Grey
Power Source	Battery Powered (Rechargeable via Type-C USB)
Sound Modes	40 (White Noise, Nature, Calming Tones)
Light Modes	7 Multicolor Mood Lights, 2 Breathing Light Modes
Brightness Levels	4
Timer Options	30, 60, 90, 120 minutes
Bluetooth Range	Up to 33 ft
Manufacturer	Bytech NY

WARRANTY & SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the packaging or contact the manufacturer directly. If you experience any issues or have questions regarding your Sealy Portable Sound Machine, please contact our customer support team for assistance.

Manufacturer: Bytech NY

For support, please visit the official Sealy website or contact their customer service as indicated on the product packaging.

© 2024 Sealy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DP1SWC5V>

More documents and user manuals: <https://manuals.plus/>